

TESTRANO 600

User Manual



Manual version: ENU 1161 05 08

© OMICRON electronics GmbH 2020. All rights reserved.

This manual is a publication of OMICRON electronics GmbH.

All rights including translation reserved. Reproduction of any kind, for example, photocopying, microfilming, optical character recognition and/or storage in electronic data processing systems, requires the explicit consent of OMICRON. Reprinting, wholly or in part, is not permitted.

The product information, specifications, and technical data embodied in this manual represent the technical status at the time of writing and are subject to change without prior notice.

We have done our best to ensure that the information given in this manual is useful, accurate and entirely reliable. However, OMICRON does not assume responsibility for any inaccuracies which may be present.

The user is responsible for every application that makes use of an OMICRON product.

OMICRON translates this manual from the source language English into a number of other languages. Any translation of this manual is done for local requirements, and in the event of a dispute between the English and a non-English version, the English version of this manual shall govern.

Contents

	About this manual	7
	Safety symbols used	7
1	Safety instructions	8
	1.1 Operator qualifications	8
	1.2 Safety standards and rules	8
	1.2.1 Safety standards	8
	1.2.2 Safety rules	8
	1.2.3 Safety accessories	9
	1.3 Operating the measurement setup	9
	1.4 Orderly measures	11
	1.5 Disclaimer	11
	1.6 Grounding	12
	1.7 Power supply	12
	1.8 Compliance statement	13
	1.9 Recycling	14
2	Introduction	15
	2.1 Designated use	15
	2.2 Device variants	15
3	Hardware overview	16
	3.1 <i>TESTRANO 600</i>	16
	3.1.1 <i>TESTRANO 600</i> front panel	16
	3.1.2 <i>TESTRANO 600</i> side panel	17
	3.1.3 Safety and warning indicators	18
	3.1.4 Emergency Stop button	19
	3.1.5 <i>TESTRANO 600</i> measuring cables	20
	3.2 <i>CP TD1</i>	22
	3.2.1 Grounding terminal and booster input	22
	3.2.2 Serial interface connector and measuring inputs	22
	3.2.3 High-voltage connector	22
	3.3 <i>CP TD12/15</i>	23
	3.3.1 <i>CP TD12/15</i> grounding terminal and Booster input	23
	3.3.2 <i>CP TD12/15</i> serial interface connector and measuring inputs	23
	3.3.3 <i>CP TD12/15</i> high-voltage connector	24
	3.3.4 Safety and interlock functions	24
	3.4 Cleaning	24
4	Functional scheme	25
5	Application	27
	5.1 Safety precautions in the substation	27
	5.2 Preparing the test setup	28
	5.3 Connecting to the transformer	29
	5.3.1 Preparing the software	29
	5.3.2 Connecting to the transformer	30
	5.4 Measurement	32
	5.5 Disconnection	33
6	<i>TESTRANO 600 TouchControl</i>	34
	6.1 Explorer functions	35
	6.1.1 Open test list	35
	6.1.2 Open predefined jobs	35
	6.2 Side bar	36

TESTRANO 600 User Manual

6.2.1	Test list functions	37
6.2.2	Edit asset	38
6.3	Status indicators	39
6.4	<i>TouchControl</i> settings	39
6.4.1	General	39
6.4.2	Legal	40
6.4.3	Version	41
6.4.4	Time and date	41
6.4.5	Logging	41
6.5	Software lock	41
7	Testing with <i>TouchControl</i>	43
7.1	Getting started	43
7.2	Test views	44
7.3	Measurement view	47
7.3.1	Plot view	47
7.3.2	Wiring diagram	47
7.4	Actual measurement	49
8	<i>TouchControl</i> tests	50
8.1	Demagnetization	51
8.1.1	Demagnetization – Settings	51
8.1.2	Demagnetization – Measurement view	52
8.2	Turns ratio	55
8.2.1	Turns ratio – Settings	55
8.2.2	Turns ratio – Measurement view	57
8.3	Winding resistance	59
8.3.1	Winding resistance – Settings	59
8.3.2	Winding resistance – Measurement view	62
8.4	Dynamic OLTC-Scan (DRM)	64
8.4.1	Dynamic OLTC-Scan – Settings	64
8.4.2	Dynamic OLTC-Scan – Measurement view	67
8.5	Leakage reactance/Short-circuit impedance	69
8.5.1	Short-circuit impedance – Settings	69
8.5.2	Short-circuit impedance – Measurement view	71
8.6	Tan Delta	74
8.6.1	Tan Delta – Settings	74
8.6.2	Tan Delta – Measurement view	76
8.7	Exciting current test	78
8.7.1	Exciting current test – Settings	78
8.7.2	Exciting current – Measurement view	80
8.8	High voltage turns ratio	82
8.8.1	High voltage turns ratio – Settings	82
8.8.2	High voltage turns ratio – Measurement view	85
8.9	Power losses at low voltage	87
8.9.1	Power losses at low voltage – Settings	87
8.9.2	Power losses at low voltage – Measurement	88
8.10	Quick	90
8.10.1	Quick – Settings	90
8.10.2	Quick – Measurement	92
8.11	Vector group check	93
8.11.1	Vector group check – Settings	93
8.11.2	Vector group check – Measurement	94
	Errors during the test	95
8.1	Cooldown	96
8.1.1	Cooldown – Settings	96

8.1.2	Cooldown – Measurement view	98
9	Primary Test Manager	100
9.1	Introduction	100
9.2	Installing <i>Primary Test Manager</i>	100
9.3	Software start and device update	101
9.3.1	Connecting to <i>TESTRANO 600</i>	101
9.3.2	Firewall configuration	102
9.3.3	Updating the <i>TESTRANO 600</i> embedded software	104
9.3.4	Upgrading the <i>TESTRANO 600</i> firmware	104
9.3.5	Device web interface	105
9.4	<i>Primary Test Manager</i> licensing	105
9.5	<i>Primary Test Manager</i> system requirements	106
9.6	Home view	107
9.6.1	Settings	110
9.6.2	Send data to Technical Support	117
9.6.3	About	118
9.6.4	Manage connection to the test system	119
9.6.5	Synchronize data	120
9.6.6	Import data	122
9.6.7	Back up and restore data	122
9.6.8	Status bar	123
9.7	Jobs	125
9.7.1	Guided test workflow	125
9.7.2	Job overview	128
9.7.3	Location view	130
9.7.4	Asset view	132
9.7.5	Test view	141
9.7.6	Handling results	151
9.7.7	Create new manual jobs	155
9.7.8	Open jobs	157
9.7.9	Test reports	157
9.8	Manage objects	159
10	Testing with Primary Test Manager	165
10.1	Getting started	165
10.2	Measurement	166
11	PTM Asset data	167
11.1	Transformer data	167
11.1.1	Bushing data	168
11.1.2	Tap changer data	169
11.1.3	Surge arrester	169
11.2	Spare bushing data	170
12	PTM Transformer tests	171
12.1	Overall PF & Cap test	173
12.2	Bushing PF & CAP – C1 test	178
12.3	Bushing PF & CAP – C2 test	183
12.4	Bushing – Energized Collar test	187
12.5	Exciting Current test	189
12.6	Insulating Fluids PF & CAP test	191
12.7	Surge Arrester Watt Losses test	193
12.8	HV TTR test	195
12.9	Leakage Reactance test	198
12.10	TTR test	201
12.11	DC Winding Resistance test	204

TESTRANO 600 User Manual

12.12	Dynamic OLTC-Scan (DRM) test	208
12.13	Demagnetization test	211
12.14	Vector Group Check test	213
12.15	Manual Demagnetization test	214
12.16	Manual Power losses at low voltage test	216
12.17	Manual TTR test	217
12.18	Manual Exciting Current test	221
12.19	Manual HV TTR test	223
12.20	Manual DC Winding Resistance test	226
12.21	Manual Dynamic OLTC-Scan (DRM)	230
12.22	Manual Leakage Reactance test	232
12.23	Manual Tan Delta test	235
12.24	Manual Vector Group Check	238
12.25	Quick test	239
12.26	Manual Cooldown test	241
13	PTM Bushing tests	244
13.1	Spare bushing tests	244
14	Device-independent PTM tests	248
14.1	Oil Analysis	248
14.2	Insulation Resistance test	254
14.3	Inspection	255
15	Technical data	257
15.1	Output specifications	258
15.2	Input specifications	263
15.3	Interfaces	266
15.4	SAFETY connectors	267
15.4.1	Safety Connector Dongle	269
15.5	Display	270
15.6	Combined values	271
15.7	Power supply specifications	273
15.8	Environmental conditions	274
15.9	Mechanical data	274
15.10	Standards	275
	Support	276

About this manual

This User Manual provides information on how to use the *TESTRANO 600* test system safely, properly and efficiently. The *TESTRANO 600* User Manual contains important safety rules for working with *TESTRANO 600* and gets you familiar with operating *TESTRANO 600*. Following the instructions in this User Manual will help you to prevent danger, repair costs, and avoid possible down time due to incorrect operation.

The *TESTRANO 600* User Manual always has to be available on the site where *TESTRANO 600* is used. The users of *TESTRANO 600* must read this manual before operating *TESTRANO 600* and observe the safety, installation, and operation instructions therein.

Reading the *TESTRANO 600* User Manual alone does not release you from the duty to comply with all national and international safety regulations relevant to working on high-voltage equipment.

Safety symbols used

In this manual, the following symbols indicate safety instructions for avoiding hazards.

DANGER

Death or severe injury will occur if the appropriate safety instructions are not observed.

WARNING

Death or severe injury can occur if the appropriate safety instructions are not observed.

CAUTION

Minor or moderate injury may occur if the appropriate safety instructions are not observed.

NOTICE

Equipment damage or loss of data possible

1 Safety instructions

1.1 Operator qualifications

Working on high-voltage assets can be extremely dangerous. Only authorized personnel who are qualified, skilled and regularly trained in electrical engineering are allowed to operate the *TESTRANO 600* and its accessories. Before starting to work, clearly establish the responsibilities.

Personnel receiving training, instructions, directions, or education on *TESTRANO 600* must be under constant supervision of an experienced operator while working with the equipment. The supervising operator must be familiar with the equipment and the regulations on site.

1.2 Safety standards and rules

1.2.1 Safety standards

Testing with *TESTRANO 600* must comply with the internal safety instructions and additional safety-relevant documents.

In addition, observe the following safety standards, if applicable:

- EN 50191 (VDE 0104) "Erection and Operation of Electrical Test Equipment"
- EN 50110-1 (VDE 0105 Part 100) "Operation of Electrical Installations"
- IEEE 510 "IEEE Recommended Practices for Safety in High-Voltage and High-Power Testing"

Moreover, observe all applicable regulations for accident prevention in the country and at the site of operation.

Before operating *TESTRANO 600* and its accessories, read the safety instructions in this User Manual carefully.

Do not turn on or operate *TESTRANO 600* if you do not understand the safety information in this manual. If you have questions or do not understand some safety instructions, contact OMICRON before proceeding.

Maintenance and repair of *TESTRANO 600* and its accessories is only permitted by qualified experts at OMICRON service centers (see "Support" on page 276).

1.2.2 Safety rules

Always observe the five safety rules:

- ▶ Disconnect completely.
- ▶ Secure against re-connection.
- ▶ Verify that the installation is dead.
- ▶ Carry out grounding and short-circuiting.
- ▶ Provide protection against adjacent live parts.

1.2.3 Safety accessories

OMICRON offers a range of accessories for added safety during the operation of our test systems. For further information and specifications, refer to the corresponding Supplementary Sheet or contact OMICRON Support (see "Support" on page 276).

1.3 Operating the measurement setup

Note: The *CP TD1*, *CP TD12* or *CP TD15* works as an add-on device to the *TESTRANO 600*. These three add-on devices are collectively named *CP TD* if no specific device is referred to.

- ▶ Before connecting or disconnecting test objects and/or cables, make sure that *TESTRANO 600* is turned off. Either use the power switch or press the **Emergency Stop** button.
- ▶ Do not connect or disconnect a test object while the outputs are active.
- ▶ After switching off *TESTRANO 600*, wait until the red warning light on the front panel has switched off (see 3.1.1 "*TESTRANO 600* front panel" on page 16). As long as this warning light is on, there is still voltage and/or current potential on one or more of the outputs.
- ▶ Make sure that the test object's terminals to be connected to *TESTRANO 600* do not carry any voltage potential.
- ▶ Make sure that during a test, *TESTRANO 600* is the only power source for a test object.
- ▶ Leave the high-voltage test area before performing a test with *TESTRANO 600*.
- ▶ Before operating *TESTRANO 600*, ground it as described in section 1.6 "Grounding" on page 12.
- ▶ Do not connect any cable to the test object without a visible grounding of the test object.
- ▶ Do not remove any cables from *TESTRANO 600* or the test object during a test.
- ▶ Do not use inadequately rated supply cords.
- ▶ Before connecting cables to *TESTRANO 600*'s high-voltage or current outputs, or other conducting parts that are not protected against accidental contact, press the **Emergency Stop** button. Do not release it unless an output signal is absolutely necessary for the test.
- ▶ Before switching on the high voltage, leave the high-voltage test area.
- ▶ Do not stand right next to or directly underneath a connection point. The clamps may fall off and hit you.

The red warning light on the *TESTRANO 600* front panel indicates hazardous voltage and/or current levels on the outputs. The green light indicates that the *TESTRANO 600* outputs are not active.

Note: If none or both lights on the front panel are on, *TESTRANO 600* is either not supplied by mains or it is defective. In this case do not use it anymore.

- ▶ Always lock connectors properly.
- ▶ The counterpart of the sockets are locking connectors. To lock these connectors safely, insert them carefully and turn clockwise until you feel them click into place. Check if they are locked by trying to turn counterclockwise without pulling the silver latch.
- ▶ To remove the locking connectors, unlock them by pulling the silver latch.
- ▶ Do not insert any objects into any input/output socket.
- ▶ Do not operate *TESTRANO 600* under ambient conditions that exceed the temperature and humidity limits listed in chapter 15 "Technical data" on page 257.

TESTRANO 600 User Manual

- ▶ Before use check that the environmental conditions are suitable for any additional equipment such as your laptop.
- ▶ Use dry and clean cables. In dusty regions, use protective caps. To avoid leakage current, make sure that the cables have ground contact.
- ▶ Only use cables supplied by OMICRON.
- ▶ Position the measurement setup in a way that you can easily disconnect *TESTRANO 600* from mains. If permanently connected, make sure that the measurement setup is positioned in a way that the switch or circuit breaker can be easily reached.
- ▶ Do not operate *TESTRANO 600* and its accessories in the presence of explosives, gas or vapors.
- ▶ If *TESTRANO 600* or its accessories do not seem to function properly (for example, in case of cable damages, abnormal warming or overheating of components), stop using them and contact OMICRON support (see "Support" on page 276).
- ▶ Observe the high-voltage areas.
- ▶ Always obey the internal safety instructions for working in areas with high voltage to avoid injury.




Figure 1-1: Illustration of work area and high-voltage area established for working with *TESTRANO 600* and *CP TD*

1.4 Orderly measures

The *TESTRANO 600* User Manual or alternatively the e-book always has to be available on the site where *TESTRANO 600* is operated.

The users of *TESTRANO 600* must read this manual before operating *TESTRANO 600* and observe the safety, installation, and operation instructions therein.

TESTRANO 600 and its accessories may only be used in accordance with the user documentation (including but not limited to User Manuals, Reference Manuals, Getting Started manuals and manufacturer manuals).

Opening *TESTRANO 600* or its accessories without authorization invalidates all warranty claims. Any kind of maintenance, calibration or repair on the device itself may only be carried out by persons authorized by OMICRON.

1.5 Disclaimer

Using *TESTRANO 600* in any way differing from the one mentioned above is considered improper use, and will invalidate all customer warranty claims and exempt the manufacturer from any liability to recourse.

If the equipment is used in a manner not described in the user documentation, the protection provided by the equipment may be impaired.

Automatic assessment

The applied auto-assessment rules (for example, indicated colors, indications) and limits within the Program are defined according to industry standards and/or are based on the experience of industry experts. The purpose of the auto-assessment is to indicate to the person that uses the Program – "User" any deviation of the measured parameters from the expected values based on the recommended limits provided by OMICRON or defined by the User. Any decision to return the apparatus to service or remove the apparatus from service cannot be based on the results of the auto-assessment alone. This decision is the sole responsibility of the owner or end user of the apparatus.

1.6 Grounding

Operating the device without PE and ground connection is life-threatening and not permitted.

- ▶ Only operate the *TESTRANO 600* with a mains power supply connected to protective earth (PE).
- ▶ Make sure that both the PE connection of the power supply and the ground connector of the *TESTRANO 600* have a solid and low-impedance connection to the grounding system on site. This also applies to all other test devices and accessories in the test setup.
- ▶ Make sure that the grounding clamp has a good electrical contact to the grounding system on site and avoid connecting it to corroded or painted surfaces.
- ▶ Make sure that the grounding terminal connections of all grounded devices in use remain intact during the whole measurement procedure, and are not accidentally disconnected.
- ▶ Only use ground and supply cables provided by OMICRON.



Connect the *TESTRANO 600* grounding terminal to the grounding system on site.

1.7 Power supply

Operating the *TESTRANO 600* without PE and ground connection is life-threatening and not permitted.

- ▶ Only operate the *TESTRANO 600* with a mains power supply connected to protective earth (PE).

Power supply from grounded grids (TN/TT)

Before a measurement is started, the *TESTRANO 600* automatically verifies the PE connection in grounded grids (TN/TT).

- ▶ If this check fails, check the power cord and power supply.

If the error message persists, there is no intact connection to protective earth (PE).

This is life-threatening. In this case measurements are not permitted and cannot be performed.

Power supply from isolated grids (IT)

An IT grid is a grid structure where none of the active conductors are galvanically connected to ground. In an IT grid, only the PE is connected to ground.

In IT grids the check fails – even if there is a PE connection. This can be the case when the *TESTRANO 600* is powered by a generator. Since every operation mandates a PE connection, you need to manually verify this.

If the *TESTRANO 600* is supplied by a generator, the equipotential ground or PE of the generator has to be grounded properly.

- ▶ If this is not possible, measurements are not permitted and cannot be performed.

Additional information

Instead of supplying the *TESTRANO 600* from phase-neutral (L1-N, A-N), it may also be supplied from phase-phase (for example, L1-L2; A-B).

- ▶ Make sure that the voltage does not exceed 240V AC.
- ▶ Make sure that the power supply is fuse-protected (16 A automatic circuit breaker).
- ▶ Do not use an extension cable on a cable reel to prevent an overheating of the cord; run out the extension cord.
- ▶ Keep extension cables as short as possible to prevent power loss.

External Booster

- ▶ Handle the **Ext. Booster** connector with extreme caution.
- ▶ Only use booster cables supplied by OMICRON.
- ▶ Do not use booster cables that are frayed or damaged in any way.

1.8 Compliance statement

Declaration of conformity (EU)

The equipment adheres to the guidelines of the council of the European Community for meeting the requirements of the member states regarding the electromagnetic compatibility (EMC) directive, the low voltage directive (LVD) and the RoHS directive.

FCC compliance (USA)

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Declaration of compliance (Canada)

This Class A digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

1.9 Recycling



This test set (including all accessories) is not intended for household use. At the end of its service life, do not dispose of the test set with household waste!

For customers in EU countries (incl. European Economic Area)

OMICRON test sets are subject to the EU Waste Electrical and Electronic Equipment Directive 2012/19/EU (WEEE directive). As part of our legal obligations under this legislation, OMICRON offers to take back the test set and ensure that it is disposed of by authorized recycling agents.

For customers outside the European Economic Area

Please contact the authorities in charge for the relevant environmental regulations in your country and dispose the OMICRON test set only in accordance with your local legal requirements.

2 Introduction

2.1 Designated use

In combination with the *CP TD* or as a stand-alone unit, *TESTRANO 600* is a multi-purpose power transformer test system for routine and diagnostic testing of power transformers during manufacturing, commissioning and maintenance.

The various partly automated tests are defined and parameterized via the front panel control of a built-in embedded PC or via an externally connected laptop.

2.2 Device variants

TESTRANO 600 is available with two interface variants.

With multi-touch screen and USB port

Controlled via the embedded PC using *TouchControl* or via a connected laptop using the *Primary Test Manager* software

Without touch screen and embedded PC

Controlled only via laptop using the *Primary Test Manager* software

3 Hardware overview

3.1 TESTRANO 600

► Refer to user manual chapter 15 "Technical data" on page 257 for detailed hardware information.

3.1.1 TESTRANO 600 front panel




Figure 3-1: TESTRANO 600 front panel with display

3.1.2 TESTRANO 600 side panel




Figure 3-2: TESTRANO 600 side panel

3.1.3 Safety and warning indicators

TESTRANO 600 provides the following indicators for safe and dangerous operating conditions.

Table 3-1: Warning indicators

Indicator	Description	Device State	Operating condition
Front panel			
	Green status light on the front panel is on	TESTRANO 600 is up and running in the stand-by mode.	Current/voltage source is inactive/off
	Blue ring on the Start/Stop button is on	A test is ready to start.	
	Blue ring on the Start/Stop button is flashing	The Start/Stop button has just been pressed. There may be hazardous voltage and/or current levels on the TESTRANO 600 outputs.	 Dangerous operating condition
	Red status light on the front panel is flashing	A test is running. There probably are hazardous voltage and/or current levels on the TESTRANO 600 outputs.	
Side panel			
	Warning light 1 on the side panel is flashing (red)	There are hazardous current levels (>3 mA) on the TESTRANO 600 inputs/outputs independent of the measurement state.	 Dangerous operating condition
	Warning light 2 on the side panel is on (orange)	There are hazardous voltage levels (>42 V) on the TESTRANO 600 inputs/outputs independent of the measurement state.	
Acoustic signals			
	1 x beep	Primary Test Manager has established the connection to TESTRANO 600.	Safe operating condition as long as no test has been started – as long as the warning lights are off.
	2 x beep	TESTRANO 600 has booted or a test is ready for execution.	
	Continuous beeping	TESTRANO 600 outputs are active or device is discharging ► Observe the warning lights on the front and side panel.	 Dangerous operating condition

Warning lights

- ▶ Always observe the warning and status lights while working with *TESTRANO 600*.
- ▶ Do not cover the warning and status lights during operation.

If no or both status lights on the front panel are on, the unit is defective or not supplied by mains.

Beeper

The beeper is an additional indicator for the main device status but does not compensate for the lights on the *TESTRANO 600* front and side panel.

If the beeper has been disabled, no acoustical signal will be emitted while the *TESTRANO 600* outputs are active.

- ▶ Refer to section "Beeper" on page 40 of this manual on how to disable and activate the beeper.

If the beeper is activated but does not emit a signal for the scenarios listed above in Table 3-1, *TESTRANO 600* might be defective.

- ▶ If *TESTRANO 600* appears to be defective, do not use it anymore. Contact OMICRON support (see "Support" on page 276).

3.1.4 Emergency Stop button



Pressing the **Emergency Stop** button *immediately* shuts off all *TESTRANO 600* outputs and stops the running measurement. When the **Emergency Stop** button is pressed, you cannot start any measurements.

- ▶ Only use the **Emergency Stop** button in an emergency or to ensure that you can safely connect/disconnect cables.
- ▶ During regular operation, stop tests via the **Start/Stop** button or the software.

3.1.5 TESTRANO 600 measuring cables

- ▶ To connect a measuring cable to *TESTRANO 600*, insert the connector and turn it to the right until it locks with a "click".

For disconnection:

- ▶ Hold the connector and pull back the silver latch.
- ▶ Turn the connector to the left and gently pull it out.




NOTICE

Equipment damage possible

- ▶ Do not pull the cable when disconnecting.
- ▶ Hold, turn and gently pull the connector for disconnection.

Table 3-2: *TESTRANO 600* measuring cables

Item	Picture	Description
<p>High-voltage cable Red marked sleeve after the connector</p>		<ul style="list-style-type: none"> • Polarity protection: only suitable for HIGH VOLTAGE and LOW VOLTAGE sockets • 15 m length • 8 poles
<p>Low-voltage cable Yellow marked sleeve after the connector</p>		<ul style="list-style-type: none"> • cross-section: 4 × 4 mm² for output 4 × 1 mm² for measurement • Neutrik® plug
<p>Tap changer cable No marked sleeve after the connector</p>		<ul style="list-style-type: none"> • Polarity protection: only suitable for TAP CHANGER socket • 15 m length • 8 poles • 8 × 2.5 mm² cross-section • Neutrik® plug

3.2 CP TD1

► Refer to the CP TD1 User Manual for detailed information and safety instructions.

3.2.1 Grounding terminal and booster input



Figure 3-3: Left side view of the CP TD1

3.2.2 Serial interface connector and measuring inputs



Figure 3-4: Right side view of the CP TD1

3.2.3 High-voltage connector




Figure 3-5: Back side view of the CP TD1

3.3 CP TD12/15

► Refer to the CP TD12/15 User Manual for detailed information and safety instructions.

3.3.1 CP TD12/15 grounding terminal and Booster input



* For more details on the interlock function refer to 3.3.4 "Safety and interlock functions" on page 24.

Figure 3-6: Grounding terminal and booster input of the CP TD12/15 (left side of the device)

3.3.2 CP TD12/15 serial interface connector and measuring inputs





Figure 3-7: Serial interface and measuring inputs of the CP TD12/15 (right side of the device)

3.3.3 CP TD12/15 high-voltage connector



* For more details on the interlock function refer to 3.3.4 "Safety and interlock functions" on page 24.

Figure 3-8: High-voltage connector of the CP TD12/15 (rear of the device)

3.3.4 Safety and interlock functions

The CP TD12/15 has several internal and external safety functions to prevent dangerous situations. The CP TD12/15 will not work if a safety function detects a problem, such as:

- defect of the protective earth connection to the *Control device*
- missing measurement ground connection (cable not connected to device)
- bad measurement ground connection (measurement ground has no contact to protective ground)
- HV-cable is not connected to the CP TD12/15

Additionally, the interlock function is active when an external CP CR600 is connected. The CP TD12/15 will not work if the interlock function detects one of the following problems:

- missing safety connection to the CP CR600
- HV-cable is not connected to the CP CR600
- overtemperature of the CP CR600

Note: If the interlock function prevents the CP TD12/15 from working, check all connections and options mentioned above.

3.4 Cleaning

WARNING

Death or severe injury caused by high voltage or current possible

- ▶ Do not clean TESTRANO 600 the CP TD or any other device when connected to the test object.
- ▶ Disconnect the test object, accessories and connection cables before cleaning.

- ▶ Use a cloth dampened with isopropanol alcohol to clean TESTRANO 600 and its accessories.

4 Functional scheme




Figure 4-1: Functional scheme for TESTRANO 600

Table 4-1: Terminals of *TESTRANO 600*

Terminal	Description
Mains interface	
L	Mains phase
N	Mains neutral
PE	Equipotential ground
Communication and safety interfaces	
I1	1 × External EtherCAT® module
I2	1 × Ethernet
I3	1 × Serial
I4	2 × Safety
EXTERNAL BOOSTER	
E1	External booster phase
EN	External booster neutral
PE	Equipotential ground
HIGH VOLTAGE	
L1	Phase 1 high voltage
L2	Phase 2 high voltage
L3	Phase 3 high voltage
N	Neutral high voltage
LOW VOLTAGE	
L1	Phase 1 low voltage
L2	Phase 2 low voltage
L3	Phase 3 low voltage
N	Neutral low voltage
TAP CHANGER	
Tap up	Command for upward switching direction
Tap down	Command for downward switching direction
V _{motor} IN	Motor voltage input
I _{motor} IN	Motor current input

5 Application

5.1 Safety precautions in the substation

Before setting *TESTRANO 600* into operation and carrying out a test, it is essential that you have read and understood chapter 1 "Safety instructions" on page 8.

- ▶ Be aware that all output sockets of *TESTRANO 600* can carry life-hazardous voltage and current.
- ▶ Only use *TESTRANO 600* with a solid connection to ground. Refer to 1.6 "Grounding" on page 12 for more information on grounding *TESTRANO 600*.
- ▶ Separate your working area – see Figure 1-1: "Illustration of work area and high-voltage area established for working with *TESTRANO 600* and *CP TD*" on page 10.
- ▶ Tests with high voltages and currents must only be carried out by authorized and qualified personnel.
- ▶ Personnel receiving training, instructions, directions, or education on high-voltage/current tests should remain under the constant supervision of an experienced operator while working with the equipment.
- ▶ The instructions have to be renewed at least once per year.
- ▶ The instructions must be available in written form and signed by each person assigned to do high-voltage/current tests.

Prior to connecting a test object to *TESTRANO 600*, the following steps need to be carried out by an authorized employee of the utility:

- ▶ Protect yourself and your working environment against an accidental re-connection of high voltage by other persons and circumstances.
- ▶ Verify that the test object is safely isolated.
- ▶ Earth-connect and shorten out the test object's terminals using a grounding set.
- ▶ Protect yourself and your working environment with a suitable protection against other (possibly live) circuits.
- ▶ Protect others from accessing the high-voltage area and accidentally touching live parts by setting up a suitable barrier and, if applicable, warning lights.
- ▶ If there is a longer distance between the location of *TESTRANO 600* and the area of danger, a second person with an additional **Emergency Stop** button is required.

5.2 Preparing the test setup



DANGER

Death or severe injury caused by high voltage or current

The output sockets of *TESTRANO 600* can carry life-hazardous voltage potential and life-hazardous currents.

- ▶ Do not use *TESTRANO 600* without a solid connection to ground.
- ▶ Before switching on *TESTRANO 600*, make sure it is completely dry.
- ▶ Before connecting any cables, check them for damage. Make sure that the connectors are clean and dry and that the insulation is intact.

1. Make sure that the power switch on the *TESTRANO 600* side panel is turned off.
2. Press the **Emergency Stop** button.
3. Connect *TESTRANO 600* to:
 - a) equipotential ground: Ground *TESTRANO 600* with a cable of at least 6 mm² cross-section as close as possible to the operator.
 - b) the computer with the PTM installed on it (optional if *TESTRANO 600* is used with *TouchControl*)
 - c) the mains power supply
4. Optional: Connect the *CP TD* to *TESTRANO 600*.
 - a) Properly connect the *TESTRANO 600* grounding terminal to substation ground.
 - b) Properly connect the *CP TD* grounding terminal/measurement ground to ground of the asset to be measured.
 - c) Connect the *CP TD BOOSTER IN* to the *TESTRANO 600 EXTERNAL BOOSTER* using the booster cable.
 - d) Connect the *CP TD SERIAL* to *TESTRANO 600 SERIAL* with the data cable.
5. Turn on the power switch on the *TESTRANO 600* side panel.
6. The green light and the blue ring of the **Start/Stop** button are switched on, showing that *TESTRANO 600* does not output dangerous voltage or current.
7. If the PE connection is defective or if the power supply has no galvanic connection to ground, a warning message appears.

Note: If *TESTRANO 600* is supplied by mains and switched on, and no or both warning lights are on, the unit might be defective. Contact OMICRON support (see "Support" on page 276).

5.3 Connecting to the transformer

5.3.1 Preparing the software

TouchControl

1. Select a test.
2. After defining the asset's vector group, tap **Wiring**  to display the wiring diagram for the test.
3. Lock *TESTRANO 600* using the **Software lock** (see the **Software lock** in the *TouchControl* software, chapter 6.5 "Software lock" on page 41).
4. Connect the test leads to *TESTRANO 600* (and, if applicable, the *CP TD*) as described in the following section 5.3.2 "Connecting to the transformer".

Primary Test Manager

1. Create a job with tests or select a manual test.
2. View the wiring diagram in the **General** tab of the test.
3. Lock your computer.
4. Connect the test leads to *TESTRANO 600* (and, if applicable, the *CP TD*) as described in the following section 5.3.2 "Connecting to the transformer".

5.3.2 Connecting to the transformer

⚠ DANGER

Death or severe injury caused by high voltage or current possible

- ▶ Before connecting any test leads to the transformer, turn off and disconnect any voltage to and from the transformer (e. g. high voltage on the main terminals, control voltage of the tap changer).
- ▶ Ground and short-circuit its terminals using a grounding set.

1. Connect the test leads to *TESTRANO 600* as shown in the wiring diagram on the *TouchControl* or in *Primary Test Manager*. Additionally, observe the connection sequence given below in Figure 5-1: "Connection sequence *TESTRANO 600* to transformer":

⚠ CAUTION

Minor or moderate injury caused by wrong connection possible

- ▶ Always observe the wiring diagram shown on the *TouchControl* or in *Primary Test Manager*.




Figure 5-1: Connection sequence *TESTRANO 600* to transformer

-
- I. Connect the high-voltage (red), low-voltage (yellow) and tap changer cables to *TESTRANO 600*.
 - II. Connect the high-voltage (red) and low-voltage (yellow) cables to the transformer's main terminals.
 - III. Connect the tap changer cable to the appropriate terminals in the control cabinet of the transformer (see Figure 5-2 below).
 - IV. Re-connect and turn on the voltage of the tap changer.
-

Note: If the tap changer control voltage exceeds 42 V, the orange warning light 2 on the side panel will indicate a hazardous voltage on the *TESTRANO 600* inputs (see 3.1.3 "Safety and warning indicators" on page 18).

2. Depending on the measurement purpose, tap changers might be required. Therefore, none, one or both of the following two instructions are necessary:
 - ▶ For tap changer control connect **TapUp+** and **TapUp-** (blue) to the connectors controlling the upward switching of the tap changer.
Connect **TapDown+** and **TapDown-** (purple) to the connectors controlling the downward switching of the tap changer.
 - ▶ For the measurement of motor current and voltage, connect **VIn+** and **VIn-** (green) as illustrated below. On a three-phase motor **VIn+** can be connected to either L1, L2 or L3.
Connect the current clamp to **CurrentIn+** and **CurrentIn-**.




Figure 5-2: Connection scheme tap changer cable to tap changer

- Optional: If you connected the *CP TD* to the *TESTRANO 600* (step 4 in section 5.2), connect the **IN_A**, **IN_B** and high-voltage output of the *CP TD* to the transformer.
 - ▶ Refer to the *CP TD1* User Manual for more information on safely connecting the *CP TD1* to a device under test.
 - ▶ Refer to the *CP TD12/15* User Manual for more information on safely connecting the *CP TD12/15* to a device under test.
- Erect a barrier separating the work area from the high-voltage test area (see page 10).
- Remove the grounding set from the test object.
- Release the **Emergency Stop** button.

5.4 Measurement

TouchControl

- Disable the **Software lock** by entering the 4-digit code into the **Enter code** entry field and by then pressing the **Unlock** button  or the **Enter** button .
- Enter/adjust the test settings in the **Settings** view.
- Open the **Measurement** view and prepare to start the test by tapping **Start** button .
- The blue ring on the **Start/Stop** button  located on the front panel lights up.
- Press the **Start/Stop** button to confirm and actually start the test.
- The blue ring  and the red warning light  on the front panel are now flashing for approx. 3 seconds.
 - ▶ To suspend the test at any time, press the **Start/Stop** button on the *TESTRANO 600* front panel.
 - ▶ In an emergency, press the **Emergency Stop** button to stop the test.
- After the measurement is completed or stopped, the green warning light  switches on.
- TouchControl* displays the results in the **Measurement view** of the test.
 - ▶ To perform additional tests, repeat the steps in chapters 5.3.2 to 5.4.

Primary Test Manager

- Establish the connection between *Primary Test Manager* and *TESTRANO 600*.
- Enter/adjust the test settings in the **Settings and conditions** area.
- Select a standard in the **Assessment** area (if applicable).
- Press the **Start** button .
- The blue ring on the **Start/Stop** button  lights up.
- Press the **Start/Stop** button to start the test.
- The blue ring  and the red warning light  are now flashing for approx. 3 seconds.
 - ▶ To suspend the test, press the **Start/Stop** button on the *TESTRANO 600* front panel.
 - ▶ In an emergency, press the **Emergency Stop** button to stop the test.
- After the measurement is completed or stopped, the green warning light  switches on.
- Primary Test Manager* displays the results in the **Measurements** section of the test.
 - ▶ To perform additional tests, repeat the steps in chapters 5.3.2 to 5.4.

5.5 Disconnection

1. Wait until the green light on the *TESTRANO 600* front panel is on and the warning lights on the front and side panel are off.

Note: If the tap changer control voltage exceeds 42 V, the orange warning light 2 on the side panel will indicate a hazardous voltage on the *TESTRANO 600* inputs (see 3.1.3 "Safety and warning indicators" on page 18).

- ▶ Disconnect the tap changer cable to extinguish warning light 2.

2. Press the **Emergency Stop** button on the *TESTRANO 600* front panel.

DANGER

Death or severe injury caused by high voltage or current

- ▶ Never unplug any cables while the measurement is running.
- ▶ Only disconnect cables when **all** of the following apply:
 - The red warning light on the front panel is **off**.
 - The warning lights on the side panel are **off**.
 - The green light on the front panel is **on**.

If all lights on *TESTRANO 600* are off, the device is defective or not supplied by mains.

3. To prevent anyone from starting a test, use the **Software lock** in the *TouchControl* software (see chapter 6.5 "Software lock" on page 41) and/or lock your computer.
4. Remove the barrier between the high-voltage area and the work area.

DANGER

Death or severe injury caused by high voltage or current possible

- ▶ Before touching any part of the transformer, ground and short-circuit its terminals using a grounding set.

5. Disconnect all cables from the transformer.
6. Disconnect all cables from *TESTRANO 600* and, if applicable, from the *CP TD*.
7. Switch *TESTRANO 600* off by pressing the mains power switch on the side panel.
8. Disconnect the mains power cord.
9. Remove the equipotential ground as the last connection that is removed first from *TESTRANO 600* and then on the substation side.

6 TESTRANO 600 TouchControl

The *TESTRANO 600* display variant can either be controlled via the *TouchControl* software (also called *TouchControl* User Interface, in short TUI) discussed in this Chapter, or by using a laptop with *Primary Test Manager* (also called PTM) installed on it.

After the first start of *TouchControl*, the **Home** screen with all available tests is displayed in the **Select a test** view. The main parts of this view are shown below.




Figure 6-1: *TouchControl* – **Select a test** view

This view contains five main parts allowing the following operations:

- 1 To display the tests in the list of the current session tap this icon.
If the list contains tests their number is indicated by a number at the top right corner of the icon.
In the above screenshot the number "1" in the top right corner of icon  indicates the list has one test in it. If the list is empty no numerical value is displayed. The maximum number of tests in the list is **20** after which no more tests can be added into the list. To open a new test first remove at least one test from the list.
- 2 Load a test by selecting the icon of the desired test.
- 3 Explorer function: Open the test list from internal or external memory
Note: External memory is a USB memory stick connected to the USB port of the test device.
- 4 Explorer function: Loading of jobs predefined by OMICRON from internal memory.
- 5 SW version info, changing of general TUI settings etc.

6.1 Explorer functions

The *TouchControl* User Interface contains two Explorer type functions, the Manual test lists and Loading predefined jobs functions.

6.1.1 Open test list

- ▶ Tap **Open test list** in this view to open the **Load** window and to access the *TouchControl* file system for the following options:
 - Save, load and move test lists to/from the internal or external memory
 - Create, rename, duplicate and delete folders and test lists
- ▶ Tap **Eject**  to safely remove the USB drive.
- ▶ To select a test tap the name of the test file.
- ▶ To unselect a single test tap the selected name again.
- ▶ To select several tests long-tap each test successively.
- ▶ You can unselect all selected tests by tapping .

Note: Test lists cannot be edited or deleted in the **Explorer** as long as they are still open in the manual test list.

Table 6-1: **Explorer** buttons

Name	Icon	Function
Up		Go back to parent folder
New folder		Create a new folder
Rename		Rename the selected test (max. 60 characters)
Copy		Copy one or more tests Note: Results are not copied.
Delete		Delete the selected test <ul style="list-style-type: none"> ▶ To delete a folder, long-tap to mark, then delete it ▶ To rename a folder, long-tap the folder name and tap Rename
Unselect all		To unselect all selected tests

6.1.2 Open predefined jobs

TESTRANO 600 comes with two test lists predefined by OMICRON:

- **three winding.ptma** for three-winding transformers
- **two winding.ptma** for two-winding transformers

The test lists can be edited and saved. They comprise all available standard tests, a Winding DF and Cap test and Bushing tests.

To save time configuring your tests, enter the relevant data in the **Settings** view of the first test and tap **Copy to all**  to apply the configuration to all tests in the list.

- ▶ Tap **Open predefined jobs** in this view to open the **Predefined jobs** window and to access the *TouchControl* file system for the following options:
 - Load from the internal or external memory
- ▶ Tap **Eject**  **Eject** to safely remove the USB drive.
- ▶ To select a predefined job tap the name of the job.
- ▶ To unselect a single predefined job select name again.
- ▶ To select several predefined jobs long-tap each test successively.

6.2 Side bar

The side bar contains the various commands for the Test list you are working on.

- ▶ In the test view, tap **Test list**  in the sidebar to expand the **Test list**.

6.2.1 Test list functions

Table 6-2: Sidebar buttons for actions regarding the test list

Name	Icon	Function
Test list		<p>Display the manual test list and access the functions described in table 6-3.</p> <p>If the list contains tests the number of tests in the list is indicated by a number indicated at the top right corner of this icon.</p> <p>Example:  indicates the list has one test saved on it. If the list is empty no numerical value is displayed beside the icon.</p>
Save		Save the test list and its settings.
		<p>Test has been saved successfully</p> <ul style="list-style-type: none"> ▶ Long-tap to display the Save as  button
Save as		<p>This icon is displayed when you long-tap the Save  button.</p> <ul style="list-style-type: none"> ▶ Tap to save the open test list under a different name.

Table 6-3: Sidebar options for actions regarding the test list with the test list opened

Name	Icon	Function
Edit asset		Edit asset parameters related to the test
Rename		<p>Rename the selected test (max. 60 characters).</p> <p>Note: The number of characters available is shown at the left of the entry field and is updated as the name is typed.</p>
Duplicate		<p>Duplicate the selected test and its settings.</p> <p>Note: Results are not copied.</p>
Up		Move the selected test up in the test list.
Down		Move the selected test down in the test list.
Comment		Write a comment for the selected test.
		<p>View and edit a previously written comment for the test.</p> <p>Note: This icon indicates, that the selected test has a comment which can be edited.</p>
Delete		Delete the selected test.

6.2.2 Edit asset



To edit general asset settings, tap the **Test list** button and then the **Edit asset** button on the top right side of the expanded **Test list** sidebar. When you import tests into *Primary Test Manager*, tests will be attributed to the asset based on the serial number.

Asset

- ▶ Tap the **<Select asset type>** drop-down list to select from the following asset types:
 - Two-winding
 - Three-winding
 - Auto w/o tert: Auto transformer without tertiary winding
 - Auto w tert: Auto transformer with tertiary winding
 - Voltage regulator
- ▶ Enter the **Serial number** and **Manufacturer** into the appropriate entry fields

Bushing

- ▶ Select the number of **Bushings** from the drop-down list.
- ▶ Enter their **Serial numbers** into the appropriate entry fields.
- ▶ To copy the first serial number entered to the rest of the serial number fields tap **Copy to all** .
- ▶ Save settings by tapping the **OK** button.

Execution state icons

In the test list, the execution state of tests are displayed by icons listed in the table below, with the icon shown to the right of the test name.

Table 6-4: Execution state icons

Icon	State
	Data necessary for test execution are missing
	Test not yet executed – ready for execution
	Test partially executed
	Test executed

If a mandatory setting has not been defined for a test, the **START** button will have the  icon displayed at the top right corner and the test cannot be started before the missing setting has been properly defined via **Settings** view. The missing parameter requiring entry is indicated with the same the  icon displayed in the **Settings** view with the possible range shown when applicable.

6.3 Status indicators

The USB and *CP TD* icons in the lower menu bar of the *TouchControl* software represent the device statuses.

Table 6-5: Status icons in the lower menu bar

Icon	Description
	<i>CP TD</i> is not connected
	<i>CP TD</i> is connected and ready
	No USB drive connected
	USB drive connected ▶ Tap to safely remove the USB drive. Any unsaved changes will be saved.
	<i>TESTRANO 600</i> cannot detect a connection to protective earth.

6.4 TouchControl settings

To open the **Settings** view tap the appropriate **Settings icon** on the bottom right side of the **Select a test** view. The **Settings** view opens and the menu on the left contains the following main options:

- General** General *TouchControl* settings
- Legal** Legal information
- Version** Software version, serial number and calibration date
- Time and date** Time and date setting
- Logging** Settings for data logging

6.4.1 General

This option contains options for selecting the system interface (menu) language, the correct standard profile, preferred temperature unit, auto save function, screen display brightness, beeper function, presentation mode and the device self-test.

Language

- ▶ Tap the **Language** drop-down box to change the system language.

Profile

- ▶ Tap the **Profile** drop-down box to choose between the **IEEE** and **IEC** profile – depending on the standard commonly used in your location.

Note: Changing the language or standard profile does not effect the name of the currently open test.

Temperature unit

- ▶ Select the preferred temperature units (°C or °F) by selecting the appropriate setting.

Auto save

- ▶ Set **Auto save** to **ON** to have your results saved automatically when a measurement is finished.

Display brightness

- ▶ Adjust screen brightness by moving the **Display brightness** slider.

Beeper

- ▶ Set **Beeper** to desired setting

Note: The beeper emits an acoustic warning signal while the *TESTRANO 600* is discharging or it's outputs are active. The beeper is an additional indicator for the *TESTRANO 600* status but does not compensate for the warning lights on the *TESTRANO 600* front and side panel.

For more information on which warning indicators *TESTRANO 600* is equipped with refer to Table 3-1: "Warning indicators" on page 18 and "Beeper" on page 19.



WARNING

Death or severe injury can occur if the appropriate safety instructions are not observed.

If the beeper is set to **OFF**, no acoustical warning signal will be emitted while the device outputs are active.

Presentation mode

You can use a VNC client to display the *TESTRANO 600 TouchControl* on a computer.

Note: VNC client can be downloaded from <https://www.realvnc.com>

- ▶ Install a VNC software on your computer.
- ▶ Set **Presentation mode** to **ON**
- ▶ Connect *TESTRANO 600* to the computer using the IP address of your *TESTRANO 600* displayed in the *OMICRON Device Browser*.

Device self-test

If *TouchControl* repeatedly displays a hardware error message, we recommend performing a device self-test. The self-test checks functionality of the *TESTRANO 600* hardware components.

- ▶ If the self-test passes but the error messages persist, check the wiring.

Note: During the self-test, the **Emergency Stop** button must be released.

6.4.2 Legal

Displays the legal text regarding the license.

6.4.3 Version

It is possible to check relevant device information of *TESTRANO 600* by selecting this option.

Displayed values:

- Version** Software version loaded into the *TESTRANO 600*
- Serial number** HW version number of the hardware
- Calibration date** Last calibration date [YYYY-MM-DD]

6.4.4 Time and date

This option enables setting the current time and date using the appropriate up or down buttons. Confirm setting by selecting **OK**, exit without saving by selecting **Cancel**.

Note: Date format is [YYYY-MM-DD].

6.4.5 Logging

- ▶ *TESTRANO 600* software includes a logging function. The log files provide information to help find the cause for possible errors in cooperation with an OMICRON support engineer. Log files do not contain any personal information.

Note: Enabling logging may slow *TESTRANO 600* down.

Table 6-6: Logging parameters

Item	Parameter	Description
Logging level	Disabled	Logging is disabled.
	Errors only	Only errors are logged. Recommended setting.
	Info	Errors and some additional information are logged.
Device logging level	Disabled	Function switched off.
	Errors only	Only errors are logged. Recommended setting.
	Info	Errors and some additional information are logged.
Device log files	Download to flash drive	Transfers device's log files to the connected USB drive.

6.5 Software lock

It is possible to lock *TESTRANO 600* in a safe and de-energized state. This allows you to temporarily leave the test setup in a safe state for a limited period of time.

Note: The Lock function is available in **Settings** and **Measurement** views.

TESTRANO 600 User Manual

- ▶ Tap **Lock**  at the bottom of the screen to access the **Lock screen**.
- ▶ Enter a four-digit code. Tap **Show** to display the numbers.
- ▶ Tap **Lock** to lock the device.
- ▶ To cancel locking tap **Cancel**
- ▶ To unlock the screen, enter the four-digit code and tap .
- ▶ Alternatively, switch *TESTRANO 600* off to disable the software lock.

Note: Test settings that were changed before locking *TESTRANO 600* can still be saved in the lock screen.

7 Testing with *TouchControl*

7.1 Getting started

The following table lists the basic steps necessary to complete a measurement using *TouchControl*.

► For more information on each step refer to the chapters listed on the right.

Step		User manual chapter
	1. SAFETY	Safety instructions Hardware overview Safety and warning indicators Emergency Stop button Application
	2. Start <i>TESTRANO 600</i>	TESTRANO 600 side panel
	3. Enter asset info	Edit asset
	4. Add tests	<i>TouchControl</i> tests
	5. Connect to transformer	Safety instructions TESTRANO 600 measuring cables Application Wiring diagram
	6. Prepare test	Test views
 	7. Measurement	Actual measurement

7.2 Test views

All *TESTRANO 600* test views (except the **Quick** view) of tests listed on the **Home** view contain when opened the **Settings** tab, the view of which displayed as default and through which the settings for the test are defined.

Depending on the selected test the top menu bar may contain other tabs such as **Measurement**, **Single phase**, **Three phase**, **Per phase** and **Plot** for starting and monitoring the actual measurement, or the **Capacitor** tab or **Define Winding** view for selecting further settings.

After all settings have been determined, the measurement can be started by tapping the **START** button  located at the bottom left corner of the **Measurement** view. The user must confirm the start of the test by pressing the physical **Start/Stop** button on the front panel of the *TESTRANO 600*.

The progress of the measurement can be followed via **Measurement** view in which measured values are updated into a table during the measurement.

In the example below the **Turns ratio** test has been selected from the Test view. The **Settings** tab is opened as default.

To define the tap changer select either **OLTC** (On-Load Tap Changer) or **DETC** (De-Energized Tap Changer) icon after which the **Define Tap Changer** view opens.

If mandatory data are missing, the corresponding submenu and the **Start** button are marked with .

It is possible to copy the settings entered through the **Settings** view to all tests that have not yet been executed by tapping **Copy to all** .




Figure 7-1: Example of a **Settings** view - **Turns ratio** test

Some features in the above Settings view example are highlighted in the list below:

- 1 Each test opens up by default to the **Settings** view, which has at the top menu bar tabs to select other possible views.
The other possible views depending on the test are one or more of the following views:
 - Measurement
 - Three phase
 - Single phase
 - Per phase
 - Capacitor
 - Plot
- 2 The selected options and entered values from this **Settings** view can be copied to all other tests which have not been executed yet by pressing .
- 3 The vector group is defined by pressing the rectangle shaped area on the screen and by selecting the appropriate vector options.
TESTRANO 600 cables: HV = RED / LV = YELLOW
- 4 Settings for **Automatic tap changer**.
- 5 **OLTC / DETC** position selection is done by tapping the appropriate icon (HV or LV side). Active choice is shown in blue color.
- 6 Some values are selected from a drop-down list of predetermined values.
- 7 Other values are entered using a pop-up numpad, which offers in addition a slider control option.
- 8 Manual tap control **UP**  and **DOWN**  control buttons.
- 9 The wiring example for the defined test can be displayed by tapping this icon.
- 10 To minimize all select  and to expand again select .

Entering values

- ▶ Tap a box, then use the numpad to enter or correct a value.
- ▶ If needed, tap the metric prefixes below after entering a value:
 - **k** for kilo-
 - **M** for mega-
 - **m** for milli-
- ▶ If you want to use a slider control after entering an initial value by using the numpad, tap the **Slider** button and use the slider to increase or decrease the displayed value. Release the slider to stop at the desired value.

The slider will stop at the minimum/maximum value.

When all required settings have been entered and to continue with the actual measurement, select the **Measurement** tab from the top bar.

Defining a tap changer

- ▶ To define a tap changer first select the appropriate tap changer type in the test's **Settings** view by pressing the appropriate tap changer icon: **OLTC** (on-load tap changer)  or **DETC** (de-energized tap changer) . Note that after defining the selected tap changer type the icon will change to .

Table 7-1: Steps in the **Define Tap Changer** view

Tap changer settings – Define Tap Changer	
Available	▶ Mark the type of tap changer on the left and tap Yes to confirm and display the settings.
Position	▶ Choose the tap changer's transformer side: HV or LV .
Tap scheme	▶ Select the notation scheme for tap identification from the drop-down list.
No. of taps	▶ Enter the number of taps.
Voltage table	The Voltage table displays the voltage for each tap. You can either enter each values manually or have them calculated.
	▶ Enter at least the first two values and press Calculate  .
	▶ Compare the calculated values with the nominal values on the nameplate before proceeding.
	 Add more taps at the end of the voltage table.
	 Delete a tap from the voltage table.
	 Delete all taps from the voltage table.
	 Insert a tap below the marked tap.
Middle	▶ Enter the voltage for the middle tap (rated voltage) and the deviation value for the calculation, then press Calculate .
First/middle/last	▶ Enter the voltages for the first, middle and last tap, then press Calculate .

When all required settings have been entered and to continue with the actual measurement, select the **Measurement** tab (or **Three phase**, **Per phase** or **Plot**) from the top bar.

7.3 Measurement view

In the **Measurement** view (or **Three phase**, **Per phase** or **Plot**) you can start the actual measurement by tapping the **Start** button  located at the bottom left corner. You will be required to confirm the starting of the test by pushing the **Start/Stop** button on the *TESTRANO 600* front panel.

An ongoing measurement is indicated by a vertical red striped bar at the far left side of the **Measurement** view with a lightning symbol flashing at the top. The shown table is updated with the measured values.

Depending on the test the **Measurement** view may provide several options for displaying the measured values in different ways. You can save the measured values at any time by tapping the **Keep results** button which makes an intermediate save of the results so far. If you want to stop the measurement completely tap the **Stop** button .

If mandatory data is missing, the **Start** button is marked with the symbol . In this case the missing data must be entered via the **Settings** view. If all missing information has been entered/selected the **Start** button should now be green .

The right side of the **Measurement** view has the buttons listed in the following table.

Table 7-2: **Measurement** view right side buttons

Icon	Description
	Full screen
	Assess
	Pass
	Fail
	Investigate
	Not assessed
	Delete result
	Delete all

7.3.1 Plot view

With some measurement the top menu bar will show a button called **Plot** and graphs or bar graphs, when applicable, can be viewed by tapping the **Plot** button.

7.3.2 Wiring diagram

- When in the **Settings** tab, you can display the wiring diagram for the selected test and vector group by tapping the **Wiring**  icon.

The colors in the wiring diagram represent the cable ends (see 3.1.5 "TESTRANO 600 measuring cables" on page 20).




Figure 7-2: Wiring diagram for a TTR (Turns Ratio Test) on a transformer with the vector group YNd5

7.4 Actual measurement

- ▶ Refer to chapter 1 "Safety instructions" on page 8 for detailed information about safe testing.
- ▶ If in doubt, contact OMICRON support (see "Support" on page 276).

DANGER

Death or severe injury caused by high voltage or current

- ▶ Do not unplug any cables while the measurement is running.
- ▶ Only remove cables when **all** of the following apply to *TESTRANO 600*:
 - The red warning light on the front panel is **off**.
 - The warning lights on the side panel are **off**.
 - The green light on the front panel is **on**.

If all lights on *TESTRANO 600* are off, the device is defective or not supplied by mains.

WARNING

Death or severe injury caused by high voltage or current possible

- ▶ Do not enter the high-voltage area during the test.
- ▶ Do not touch any part of the transformer before grounding and short-circuiting its terminals.



1. To start the test measurement tap **Start**.



2. To stop the test measurement tap **Stop**.



3. The blue ring on the **Start/Stop** button on *TESTRANO 600* lights up.

4. Press the **Start/Stop** button on *TESTRANO 600* front panel to start the test.



5. The blue ring and the red warning light are now flashing for approx. 3 seconds.

- ▶ To suspend the test, press the **Start/Stop** button on the *TESTRANO 600* front panel.



- ▶ In an emergency, press the **Emergency Stop** button to stop the test.



6. After the measurement is completed or stopped, the green warning light switches on and *TouchControl* displays the results in the **Measurement** view.

8 TouchControl tests

This chapter lists the tests available for *TESTRANO 600 TouchControl*.

- For details on safely performing tests, refer to chapters 1 "Safety instructions" on page 8 and 5 "Application" on page 27.

Chapter	Page
8.1 Demagnetization	51
8.2 Turns ratio	55
8.3 Winding resistance	59
8.4 Dynamic OLTC-Scan (DRM)	64
8.5 Leakage reactance/Short-circuit impedance	69
8.6 Tan Delta	74
8.7 Exciting current test	78
8.8 High voltage turns ratio	82
8.9 Power losses at low voltage	87
8.10 Quick	90
8.11 Vector group check	93
8.1 Cooldown	96

8.1 Demagnetization

Whenever a power transformer is isolated from the power system, residual magnetism remains in its core due to a phase shift. Due to residual magnetism in the core, high inrush currents, up to the maximum short-circuit current can occur. This puts undesired stress on the transformer when it is switched back into service. In addition, many diagnostic measurements can be affected by residual magnetism, making a reliable assessment very difficult.

Therefore, it is recommended to demagnetize the core before switching the transformer back into service and after DC voltages have been applied during diagnostic testing.

8.1.1 Demagnetization – Settings

- ▶ Adjust the settings and enter the necessary values for your test.
- ▶ Tap **Wiring**  to display the wiring diagram for this test and vector group.




Figure 8-1: Demagnetization test – Settings view

Table 8-1: Demagnetization – Settings

Option	Description
Winding	
Phases	▶ Set the number of transformer phases.
Auto transformer	▶ Tap Yes if you are testing an auto transformer.
Vector group	▶ Tap Copy to all  to copy the winding and tap changer configuration to all tests that have not yet been executed.

Table 8-1: Demagnetization – Settings (continued)

Option	Description
Test settings	
Test current	▶ Enter the maximum test current.
Saturation level	Desired saturation level during the demagnetization process. This value is only adapted in special cases.

8.1.2 Demagnetization – Measurement view

In the **Measurement** view, the results are displayed in the **Measurement**  view.

- ▶ Expand the **Measuring values** section to display the measuring values during and after measurement.
- ▶ Tap **Add**  to add further measurements (max. 30 measurements possible).




Figure 8-2: Demagnetization test – **Measurement** view

Table 8-2: Demagnetization – Measurement

Option	Description
Measurement	
Measurement name	Text field for description or comment
Status	During demagnetization: <ul style="list-style-type: none"> • Positive saturation running • Negative saturation running • Demagnetization running After demagnetization: <ul style="list-style-type: none"> • Demagnetization passed • Saturation failed • Demagnetization aborted
	After measurement <ul style="list-style-type: none"> • Test finished
I DC	Measured current
Min. neg. remanence	Maximum remanence in negative direction of the hysteresis curve
Max. pos. remanence	Maximum remanence in positive direction of the hysteresis curve
Remanence	Measured remanence
Initial remanence	Remanence measured at the beginning of the test

Table 8-3: Demagnetization – Measuring values

Option	Description
Initial remanence	Measured remanence at the start of the test
Max. pos. remanence	Maximum remanence in positive direction of the hysteresis curve
Min. neg. remanence	Maximum remanence in negative direction of the hysteresis curve
Remanence	Measured remanence
Level	Saturation level of the transformer
Max. current	Maximum demagnetizing current (<i>TESTRANO 600</i> output)
Pos. sat. flux	Maximum saturation flux in positive direction of the hysteresis curve
Neg. sat. flux	Maximum saturation flux in negative direction of the hysteresis curve
Resistance	Resistance measured at maximum positive saturation flux
Remaining saturation	Saturation remaining in currently running demagnetization cycle

Table 8-3: Demagnetization – Measuring values (continued)

Option	Description
Status	During demagnetization: <ul style="list-style-type: none"> • Positive saturation running • Negative saturation running • Demagnetization running After demagnetization: <ul style="list-style-type: none"> • Demagnetization passed • Saturation failed • Demagnetization aborted
Output voltage	Current output voltage
Output current	Output current

8.2 Turns ratio

Transformer turns ratio (TTR) measurements are performed to verify the fundamental operating principle of a power transformer. By measuring the ratio and phase angle from one winding to the other, open circuits and shorted turns can be detected. The turns ratio is determined during factory acceptance tests and needs to be checked routinely once the transformer is in service.

8.2.1 Turns ratio – Settings

- ▶ Adjust the settings and enter the necessary values for your test.
- ▶ Tap **Wiring**  to display the wiring diagram for this test and vector group.




Figure 8-3: Turns ratio test – Settings view

Table 8-4: Turns ratio – Settings

Option	Description
Winding	
Phases	▶ Set the number of transformer phases.
Auto transformer	▶ Tap Yes if you are testing an auto transformer.
Vector group	▶ Set the vector group: Tap Select winding configuration .
Rated voltage	▶ Enter the transformer’s rated voltage.

Table 8-4: Turns ratio – Settings (continued)

Option	Description
Tap changer data	
Tap changer settings	▶ Adjust the tap changer settings by tapping the corresponding icon  .
	 No tap changer defined
	 Tap changer has been defined and will be included in the measurement
Tap changer under test	▶ Select which tap changer to include in the measurement if both an OLTC and a DETC have been defined. The tap changer under test is marked with a star ★.
OLTC position	OLTC tap position during tap switching on the DETC
DETC position	DETC tap position during tap switching on the OLTC
Tap changer settings – Define Tap Changer	
▶ Refer to "Defining a tap changer" on page 46.	
Measurement	
Output mode	Standard setting: 3 x 120 V
	▶ Select the 3 x 400 V output mode if the magnetization current of the transformer is low to perform the test by using a higher voltage.
	▶ Refer to "AC high range low current" in Table 15-2, page 258.
Test voltage	Output voltage
Test frequency	Output frequency:
	<ul style="list-style-type: none"> • IEEE: 60 Hz • IEC: 50 Hz
Automatic tap control	
▶ See "Keeping results" on page 58 for more information.	
Select	▶ Select ON to activate the automatic tap control.
↑ Up ↓ Down	▶ If automatic tap control is ON , use the Up and Down buttons in the Settings view to switch between the taps and check if your wiring is correct.
Tap time	Time for the change between two tap positions
Impulse time	Duration of the impulse triggering the tap change
Start tap	Start tap position of the test
Stop tap	Stop tap position of the test

8.2.2 Turns ratio – Measurement view

In the **Measurement** view, the results are displayed in the **Measurement**  or **Plot**  view.

- ▶ Use the **Current tap position** drop-down box to choose the correct label for the currently measured tap.
- ▶ Tap the arrows  in the table head to sort the results by tap or phase number.




Figure 8-4: Turns ratio test – **Measurement** view with results

Table 8-5: Turns ratio – Measurement, table view

Option	Description
Tap	Tap under test (change using )
Phase	Phase under test (change using )
Nominal ratio	Nominal transformer ratio
V prim (L-L)	Output voltage; measured line to line
I prim	Measured current on the primary side of the transformer
V sec (L-L)	Secondary voltage; measured line to line
V phase deviation	Phase shift of the transformer (Absolute, Deviation rad, Deviation deg)
VTR / TTR	Voltage ratio (VTR or TTR)
Ratio deviation	Deviation of the nominal ratio from the voltage ratio (change using )

Table 8-5: Turns ratio – Measurement, table view (continued)

Option	Description
Current tap position	
 Middle	▶ Tap to view the middle tap position.
↑ Up ↓ Down	▶ If automatic tap control is OFF , use the ↑ and ↓ buttons in the Measurement view to switch taps during measurement.
Show results	
V phase	▶ Choose from the drop-down box which value to display in the table. Options are: Absolute Deviation (rad) Deviation (deg)
Ratio	▶ Choose from drop-down box which value to display in the table. Options are: TTR (transformer turns ratio) VTR (voltage ratio)

Table 8-6: Turns ratio – Measurement, plot view

Option	Description
Plot type Drop-down menu at top right	TTR/VTR: Transformer/voltage ratio over tap position
	TTR deviation: Ratio deviation over tap position
	Exciting current: Low-voltage exciting current over tap position
	Phase deviation: Phase deviation over tap position
Filter graph	▶ Select the phases to be displayed in the graph.
Current tap position	
 Middle	▶ Tap to view the middle tap position.
↑ Up ↓ Down	▶ If automatic tap control is OFF , use the Up and Down buttons in the Measurement view to switch taps during measurement.

Keeping results

Automatic tap control = ON: *TouchControl* automatically saves results when the **Tap time** is over.

Automatic tap control = OFF: Tap **Keep results** to manually save results.

8.3 Winding resistance

Winding resistance measurements are performed to assess possible damages in windings or contact problems between bushings and windings, windings and tap changer, etc.

8.3.1 Winding resistance – Settings

- ▶ Adjust the settings and enter the necessary values for your test.
- ▶ Tap **Wiring**  to display the wiring diagram for this test and vector group.




Figure 8-5: Winding resistance test – **Settings** view

Table 8-7: Winding resistance – Settings


Option	Description
Winding	
Phases	▶ Set the number of transformer phases.
Auto transformer	▶ Tap Yes if you are testing an auto transformer.
Vector group	▶ Set the vector group: Tap Select winding configuration .
Rated voltage Rated current	▶ Tap the drop-down box to choose between Rated voltage and Rated current and enter the applicable value.
 Copy to all	▶ Tap Copy to all to copy the winding and tap changer configuration to all tests that have not yet been executed.

Table 8-7: Winding resistance – Settings (continued)

Option	Description
Tap changer data	
Tap changer settings	<p>▶ Adjust the tap changer settings by tapping the corresponding icon .</p> <p> No tap changer defined</p> <p> Tap changer has been defined and will be included in the measurement</p>
Tap changer under test	<p>▶ Select which tap changer to include in the measurement if both an OLTC and a DETC have been defined. The tap changer under test is marked with a star .</p>
OLTC position	The OLTC tap position during tap switching on the DETC
DETC position	The DETC tap position during tap switching on the OLTC
Tap changer settings – Define Tap Changer	
▶ Refer to "Defining a tap changer" on page 46.	
Measurement	
Selected output	<p>Select output cable: HV (red) or LV (yellow)</p> <p>▶ See 3.1.5 "TESTRANO 600 measuring cables" on page 20.</p> <p>Note: With LV as the selected output, you need to specify the rated voltage. Otherwise the output voltage will be limited to 2 V to prevent overvoltage.</p>
Output mode	<p>1 Phase:</p> <ul style="list-style-type: none"> • 16 A @ 340 V Fast magnetization with elevated voltage • 33 A @ 170 V For assets with expected low resistances • 100 A @ 56 V For assets with expectedly very low resistances <p>3 Phases: only available and set by default for the selected output of YN windings</p> <ul style="list-style-type: none"> • 16 A @ 113 V Fast magnetization with elevated voltage • 33 A @ 56 V For assets with expected low resistances
Test current	Current output during the test
Automatic tap control	
▶ See "Keeping results" on page 63 for more information.	
Select	▶ Select ON to activate the automatic tap control.
<p> Up</p> <p> Down</p>	▶ If automatic tap control is ON , use the Up and Down buttons in the Settings view to switch between the taps and check if your wiring is correct.

Table 8-7: Winding resistance – Settings (continued)

Option	Description
Tap time	Time for the change between two tap positions
Impulse time	Duration of the impulse triggering the tap change
Start tap	Start tap position of the test
Stop tap	Stop tap position of the test
Up/Down test	▶ Select ON to activate the automatic change of switching direction after the first/last tap.
Automatic result	
Automatic result	▶ Select ON to automatically keep measurement results, depending on Tolerance R dev and the Settling time .



Tolerance R dev	Tolerance for the deviation of measurement results within the settling time
Settling time (Δt)	If during the settling time the deviation remains below the defined Tolerance R dev , the result is recorded.
Test conditions	
Temperature correction	▶ Tap ON to activate temperature correction.
Material	▶ Select the winding material: copper or aluminium.
Temperature	Winding temperature
Reference temperature	Reference temperature for the temperature correction
Correction factor	Temperature correction factor calculated from the values entered above

8.3.2 Winding resistance – Measurement view

In the **Measurement** view, the results are displayed in the **Measurement**  or **Plot**  view.

- ▶ Use the **Current tap position** drop-down box to choose the correct label for the currently measured tap.
- ▶ Tap the arrows  in the table heads to sort the results by switching direction, tap position or phase number.

If **Automatic tap control** and **Up/down test** are **ON**, the left-most column displays the switching direction: up  or down .




Figure 8-6: Winding resistance test – Measurement view

Table 8-8: Winding resistance – Measurement

Option	Description
Tap	Tap under test
Name	Name indicates between which terminals of the transformer the measurement was performed. A , B and C are measurement prefixes, A-N , B-N and C-N refer to the wiring diagram.
R meas	Measured resistance
R dev	Percentage deviation among the last 20 values measured.
R corr	Corrected measured resistance
Time	Time until a stable condition was reached

Table 8-8: Winding resistance – Measurement (continued)

Option	Description
I DC	Measured current
V DC	Measured voltage
Current tap position	
Middle	 Tap to view the middle tap position.
↑ Up ↓ Down	▶ If automatic tap control is OFF , use the Up and Down buttons in the Measurement view to switch taps during measurement.
Selected phase – Table view	
▶ After rewiring, select the next phase and press Start .	
Filter graph – Plot view	
▶ Select the phases to be displayed in the graph.	

Keeping results

Automatic tap control = ON, Automatic result = ON (*by default*):

In this mode, taps and phases are switched automatically. *TouchControl* saves a result when it detects a value within the **Tolerance R dev** during the settling time.

Automatic tap control = OFF, Automatic result = ON:

- ▶ Select a tap and/or phase.
- ▶ Tap **Auto keep** during the measurement.
TouchControl then automatically saves a result when it detects a value within the **Tolerance R dev** during the settling time.
 On DETCs *TouchControl* measures all three phases for the selected tap.
- ▶ Tap **Keep results** to manually save results during the settling time. This might be necessary in case the results will not stabilize.

8.4 Dynamic OLTC-Scan (DRM)

Dynamic resistance measurements are performed as a supplementary measurement in order to analyze the transient switching process of a resistive diverter OLTC. They investigate the switching process of the diverter switch itself. When switching the tap changer during winding resistance measurements, the DC current temporarily decreases and this behavior is recorded and analyzed.

8.4.1 Dynamic OLTC-Scan – Settings

- ▶ Adjust the settings and enter the necessary values for your test.
- ▶ Tap **Wiring**  to display the wiring diagram for this test and vector group.
Refer to 5.3.2 "Connecting to the transformer" on page 30 for more information on tap changer wiring.




Figure 8-7: Dynamic OLTC-Scan – **Settings** view

Table 8-9: Dynamic OLTC-Scan – Settings


Option	Description
Winding	
Phases	▶ Set the number of transformer phases.
Auto transformer	▶ Tap Yes if you are testing an auto transformer.
Vector group	▶ Set the vector group: Tap Select winding configuration .
Rated voltage Rated current	▶ Tap the drop-down box to choose between Rated voltage and Rated current and enter the applicable value.

Table 8-9: Dynamic OLTC-Scan – Settings (continued)

Option	Description
 Copy to all	▶ Tap to copy the winding and tap changer configuration to all tests that have not yet been executed.
Tap changer data	
Tap changer settings	▶ Adjust the tap changer settings by tapping the corresponding icon  .
	 No tap changer defined
	 Tap changer has been defined and will be included in the measurement
Tap changer under test	▶ Select which tap changer to include in the measurement if both an OLTC and a DETC have been defined. The tap changer under test is marked with a star  .
OLTC position	The OLTC tap position during tap switching on the DETC
DETC position	The DETC tap position during tap switching on the OLTC
Tap changer settings – Define Tap Changer	
▶ Refer to "Defining a tap changer" on page 46.	
Test conditions	
Temperature correction	▶ Tap ON to activate temperature correction.
Material	▶ Select the winding material: copper or aluminum.
Temperature	Winding temperature
Reference temperature	Reference temperature for the temperature correction
Correction factor	Temperature correction factor calculated from the values entered above
Measurement	
Output mode	1 Phase: <ul style="list-style-type: none"> • 16 A @ 340 V Fast magnetization with elevated voltage • 33 A @ 170 V For assets with expected low resistances • 100 A @ 56 V For assets with expectedly very low resistances
	3 Phases: only available and set by default for the selected output of YN windings <ul style="list-style-type: none"> • 16 A @ 113 V Fast magnetization with elevated voltage • 33 A @ 56 V For assets with expected low resistances
Test current	Current output during the test

Table 8-9: Dynamic OLTC-Scan – Settings (continued)

Option	Description
Dynamic shorting	Dynamic short-circuit of low-voltage windings on single- and three-phase transformers. Short-circuit is only set on two- and three-winding transformers with an OLTC on the high-voltage winding.
Tap control	
Automatic control	► Select ON to activate the automatic tap control.
Tap time	Time for the change between two tap positions
Impulse time	Duration of the impulse triggering the tap change
Recording time	Recording period during the switching cycle
Start tap	Start tap position of the test
Stop tap	Stop tap position of the test
Up/Down test	► Select ON to activate the automatic change of switching direction after the first/last tap.
↑ Up ↓ Down	► Use the Up and Down buttons to switch between the taps and check if your wiring is correct.
Automatic result	
Automatic result	In this test, results are saved automatically, depending on Tolerance R dev and the Settling time .



Tolerance R dev	Tolerance for the deviation of measurement results within the settling time
-----------------	---

Table 8-9: Dynamic OLTC-Scan – Settings (continued)

Option	Description
Settling time (Δt)	If during the settling time the deviation remains below the defined Tolerance R dev , the result is recorded.
Motor supply	
Record	▶ Tap ON to record the current and voltage supply to the tap changer motor.
Clamp ratio	▶ Enter the current clamp’s transformer ratio (current to voltage).

8.4.2 Dynamic OLTC-Scan – Measurement view

The results are displayed in the **Measurement**  or **Plot**  view.

Plot view

For an easier distinction of the different graphs, select a graph from the **Graph legend** list, then tap **Color meas.**  to assign a color to it.




Figure 8-8: Dynamic OLTC-Scan – Measurement view

Measurement view

▶ Tap the arrows  in the table head to sort the results by tap or phase number.

If **Up/down test** is **ON**, the left-most column displays the switching direction: up  or down .

Table 8-10: Dynamic OLTC-Scan – Measurement, table view

Option	Description
Tap	Tap under test
Name	Name indicates between which terminals of the transformer the measurement was performed. A , B and C are measurement prefixes, A-N , B-N and C-N refer to the wiring diagram.
R meas	Measured resistance
R dev	Deviation of two successive measurement results at the time the test was stopped
R corr	Temperature-corrected measured resistance
Ripple	Percentage deviation between highest and lowest value in the DRM curve
Time	Time until a stable condition was reached
I DC	Measured current
V DC	Measured voltage

8.5 Leakage reactance/Short-circuit impedance

Short-circuit impedance/leakage reactance measurements are sensitive methods to assess possible deformation or displacements in windings.

The frequency response of stray losses (FRSL) test is a measurement of the resistive component of the short-circuit impedances at multiple frequencies. It is an electrical method to identify short-circuits between parallel strands and local overheating due to excessive eddy current losses. The test setup and procedure of the FRSL test is the same as for the per phase short-circuit impedance/leakage reactance test and can be performed simultaneously.

Note: The name of this test depends on the standard set in the **Settings** view (see 6.4 "TouchControl settings" on page 39):

- According to the IEEE standard: Leakage Reactance
- According to IEC standard: Short-Circuit Impedance

In this chapter, the test will be referred to as short-circuit impedance.

8.5.1 Short-circuit impedance – Settings

- ▶ Adjust the settings and enter the necessary values for your test.
- ▶ Tap **Wiring**  to display the wiring diagram for this test and vector group.




Figure 8-9: Short-circuit impedance test – **Settings** view

Table 8-11: Short-circuit impedance – Settings

Option	Description
Winding	
Phases	▶ Set the number of transformer phases.
Auto transformer	▶ Tap Yes if you are testing an auto transformer.
Vector group	▶ Set the vector group: Tap Select winding configuration .
 Copy to all	▶ Tap to copy the winding and tap changer configuration to all tests that have not yet been executed.
Tap changer data	
Tap changer settings	▶ Adjust the tap changer settings by tapping the corresponding icon  .
	 No tap changer defined
	 Tap changer has been defined and will be included in the measurement
Tap changer settings – Define Tap Changer	
▶ Refer to "Defining a tap changer" on page 46.	
Impedance settings – Define impedances	
▶ Define the tap settings for the short-circuit impedance test. In the Measurement view you will be able to filter the results for the individual entries in this list, using the Impedance list entry drop-down box.	
Short-circuit impedance Z/uk^1	Short-circuit impedance of the transformer
Base power	Base power used for calculating the percent values of impedances
Base voltage	Base voltage used for calculating the percent values of impedances
OLTC position	Tap position of the OLTC corresponding to the impedance value
DETC position	Tap position of the DETC corresponding to the impedance value
Measurement	
	Select Three phase for a three-phase measurement to compare the results to the nameplate data.
Auto shorting	<p>When selected the short-circuit does not need to be done manually and the HV and LV cables remain as connected. <i>TESTRANO 600</i> compensates for the losses in the cables.</p> <p>If auto shorting is selected (ON) the Test current label will be changed to Output current limit with a preset value, which can be changed depending the maximum rate of the secondary winding of the transformer (range 0 - 33 A).</p> <p>Note: To achieve optimal results, <i>TESTRANO 600</i> adjusts the test current automatically to the most feasible value within the range from 0 to the defined maximum Output current limit value.</p>
Test current	▶ Enter the maximum test current.

Table 8-11: Short-circuit impedance – Settings (continued)

Option	Description
Test frequency	▶ Enter the mains frequency.
Test conditions	
Temperature correction	▶ Tap ON to activate temperature correction.
Material	▶ Select the winding material: copper or aluminum.
Temperature	Winding temperature
Reference temperature	Reference temperature for the temperature correction
Correction factor	Temperature correction factor calculated from the values entered above
Result view	
Show FRSL results	▶ Tap ON to display the FRSL results in the Per phase table of the Measurement view.

1. Depending on the **Profile** selected in **Settings – General** (see 6.4.1 "General" on page 39).

8.5.2 Short-circuit impedance – Measurement view

For the short-circuit impedance test, the results are shown in **Measurement**  view or the **Plot**  view.

- ▶ Select  **Three phase** for a three-phase measurement to compare the results to the nameplate data.
- ▶ Select  **Per phase** for an in-depth error analysis of the individual phases.
- ▶ Choose an **Impedance list entry** from the drop-down-list to show the results for one of the impedances defined in the **Settings** view (see page 70).

► Tap the arrows  in the table heads to sort the results by frequency or position.




Figure 8-10: Short-circuit impedance test – **Measurement** view

Table 8-12: Short-circuit impedance – Measurement

Option	Description
Position	Entry selected from the impedance list
Phase	Phase under test
I	Measured current
V	Measured voltage
V Phase	Phase angle between voltage and current
Rk	Real part of the measured Zk
Xk	Imaginary part of the measured Zk (short-circuit impedance)
Zk	Measured short-circuit impedance
uk/Zk calc ¹	Calculation based on the Zk value of all three phases

Table 8-12: Short-circuit impedance – Measurement (continued)

Option	Description
uk dev / Zk dev ¹	Three phase measurement: Deviation from the nameplate value entered in the Impedance settings list <hr/> Per phase measurement: Deviation from uk avg / Zk avg
uk avg / Zk avg ^{1, 2}	Average of Zk across all phases
Impedance list entry	Tap settings for the short-circuit impedance test (see "Impedance settings – Define impedances" on page 70)
Selected phase ²	▶ After rewiring, select the next phase and press Start .

1. Depending on the **Profile** selected in **Settings – General** (see 6.4.1 "General" on page 39).

2. Only for **Per phase** test

8.6 Tan Delta

Capacitance and power factor/dissipation factor measurements are performed to investigate the condition of the insulation of power transformers and bushings. Both insulation systems are essential for the reliable operation of the transformer.

Note: This test requires the *CP TD*.

- ▶ For details on how to connect the devices and prepare a test, refer to chapter 5.2 "Preparing the test setup" on page 28.

8.6.1 Tan Delta – Settings

- ▶ Adjust the settings and enter the necessary values for your test.




Figure 8-11: Tan delta test – **Settings** view

Table 8-13: Tan Delta – Settings

Option	Description
Measurement	
Test frequency	▶ Set the output frequency for the test/the frequency used to calculate the sweep.
Show results	▶ Select the type of calculation for the measured results from the drop-down list (see Table 8-14: "Tan Delta – Measurement" on page 76).
Noise suppression	
Averaging (no. of points)	▶ Enter the number of measurement points used for averaging.

Table 8-13: Tan Delta – Settings (continued)

Option	Description
Bandwidth	▶ Select the <i>CP TD</i> filter bandwidth from the drop-down list.
Avoid test frequency	<p>If this setting is active, the measurement will <i>not</i> be performed at the Test frequency set in the Measurement section. <i>TouchControl</i> will instead measure two values at frequencies below and above the entered Test frequency and calculate the median of those two values.</p> <p>The Avoid test frequency setting is predefined for the selected test.</p> <p>▶ Only change the default setting for special applications.</p>
Device settings	
Shield check	<p>ON: <i>TESTRANO 600</i> checks whether the shield of the high-voltage cable is connected.</p> <p>Note: Only valid if a CP TD1 is connected.</p>
Beeper	ON: The <i>CP TD</i> beeper is on during the measurement.
Test conditions	
Ambient temperature	Ambient temperature on site
Test object temperature	Temperature of the test object
Humidity	Relative ambient humidity
Weather	Weather conditions during the test
Correction factors	
Temperature correction	▶ Tap ON to set the temperature correction factor.
Reference voltage	▶ Tap ON to set the reference voltage for the extrapolation of measurement results.

8.6.2 Tan Delta – Measurement view

- ▶ Tap **Wiring**  to display the wiring diagram for this test and vector group.
- In the **Measurement** view, the results are displayed in the **Measurement**  or **Plot**  view.
- ▶ Switch to the **Live**  view to monitor the voltage output **V out** during measurement.
- The **Overview** lists all measurements.
- ▶ Mark a list entry and tap **Go to meas.**  to open the measurement.




Figure 8-12: Tan delta test – Measurement view

Table 8-14: Tan Delta – Measurement

Option	Description
Table	
Mode	Measurement mode
Measurement	Text field for description or comment
V test	Test voltage
Freq.	Test frequency
V out	Measured output voltage
I out	Measured output current

Table 8-14: Tan Delta – Measurement (continued)

Option	Description
Depending on the Result view	
PF/DF ¹ , Cap, Watt losses	Power factor/dissipation factor, capacitance and watt losses
Imp. Z	Impedance with phase angle
Q power, S power	Reactive and apparent power
Cp, Rp	Parallel capacitance and parallel resistance
Cp, quality factor	Parallel capacitance and quality factor
Ls, Rs	Serial inductance and serial resistance
Ls, quality factor	Serial inductance and quality factor
Correction factors	
Temperature correction	▶ Tap ON to activate temperature correction.
Reference voltage	Reference voltage for the extrapolation of measurement results

1. Depending on the **Profile** selected in **Settings – General** (see 6.4.1 "General" on page 39).

Measurements – Sweeps

- ▶ In the **Table** view, tap **Add**  to add further measurements (max. 30).
- ▶ Tap **Add point**  to add a point to an existing measurement.

The following sweeps are available:

- Frequency sweep CPC template:
Sweep frequencies specified by the *CPC 100* test templates
- Frequency sweep OMICRON expertise:
Sweep frequencies dynamically distributed within the *CP TD* frequency range for optimum results
- Voltage sweep OMICRON expertise:
Sweep voltages dynamically distributed within the asset-dependent voltage range for optimum results
- Manual sweep

8.7 Exciting current test

Exciting current measurements are performed to assess the turn-to-turn insulation of the windings, the magnetic circuit of a transformer as well as the tap changer. The most valued benefit of the test is to detect turn-to-turn short-circuits in a winding. Physical movement of the core laminations or severe damage to the core can influence the reluctance and, thus, will result in a change in exciting current. Deviations may also indicate contact wear or improper wiring of the tap changer.

8.7.1 Exciting current test – Settings

- ▶ Adjust the settings and enter the necessary values for your test.
- ▶ Tap **Wiring**  to display the wiring diagram for this test and vector group.




Figure 8-13: Exciting current test – **Settings** view

Table 8-15: Exciting current – Settings

Option	Description
Winding	
Phases	▶ Set the number of transformer phases.
Auto transformer	▶ Tap Yes if you are testing an auto transformer.
Vector group	▶ Set the vector group: Tap Select winding configuration .
 Copy to all	▶ Tap to copy the winding and tap changer configuration to all tests that have not yet been executed.

Table 8-15: Exciting current – Settings (continued)

Option	Description
Tap changer data	
Tap changer settings	▶ Adjust the tap changer settings by tapping the corresponding icon  .
	 No tap changer defined
	 Tap changer has been defined and will be included in the measurement
Tap changer settings – Define Tap Changer	
▶ Refer to "Defining a tap changer" on page 46.	
Noise suppression	
Averaging (no. of points)	▶ Enter the number of measurement points used for averaging.
Bandwidth	Select the <i>CP TD</i> filter bandwidth from the drop-down list.
Avoid test frequency	<p>If this setting is active, the measurement will <i>not</i> be performed at the Test frequency set in the Measurement section. <i>TouchControl</i> will instead measure two values at frequencies below and above the entered Test frequency and calculate the median of those two values.</p> <p>The Avoid test frequency setting is predefined for the selected test.</p> <p>▶ Only change the default setting for special applications.</p>
Device settings	
Shield check	ON: <i>CP TD</i> checks whether the shield of the high-voltage cable is connected.
Beeper	ON: The <i>CP TD</i> beeper is on during the measurement.
Measurement	
Test voltage	Output voltage
Test mode	Test mode for this test: UST-A
Selected phase	▶ After rewiring, select the next phase and press Start .
Test frequency	Output frequency: <ul style="list-style-type: none"> • IEEE: 60 Hz • IEC: 50 Hz
Automatic tap control	
▶ See "Keeping results" on page 58 for more information.	
Select	▶ Select ON to activate the automatic tap control.
↑ Up ↓ Down	▶ If automatic tap control is ON , use the Up and Down buttons in the Settings view to switch between the taps and check if your wiring is correct.
Tap time	Time for the change between two tap positions

Table 8-15: Exciting current – Settings (continued)

Option	Description
Impulse time	Duration of the impulse triggering the tap change
Start tap	Start tap position of the test
Stop tap	Stop tap position of the test
Correction factors	
Reference voltage	▶ Tap ON to set the reference voltage for the extrapolation of measurement results.

8.7.2 Exciting current – Measurement view

▶ Tap **Wiring**  to display the wiring diagram for this test and vector group.

In the **Measurement** view, the results are displayed in the **Measurement**  or **Plot**  view.

▶ Switch to the **Live**  view to monitor the voltage output **V out** during measurement.




Figure 8-14: Exciting current test – Measurement view

Table 8-16: Exciting current test – Measurement

Option	Description
Tap	Tap under test
Phase	Phase under test ▶ Refer to the wiring diagram for correct wiring after changing the phase.
V out	Measured output voltage
I out	Measured output current
I phase	Measured primary current per phase
Watt losses	Measured losses
Reactance	Main inductance of the transformer

Table 8-17: Exciting current test – Measurement, table view

Option	Description
Tap	Tap under test
Phase	Phase under test ▶ Refer to the wiring diagram for correct wiring after changing the phase.
V out	Measured output voltage
I out	Measured output current
I phase	Measured primary current per phase
Watt losses	Measured losses
Reactance	Main inductance of the transformer
Selected phase	
▶ After rewiring, select the next phase and press Start .	
Current tap position	
Middle	 ▶ Tap to view the middle tap position.
Correction factors	
▶ Tap ON to edit the reference voltage.	

8.8 High voltage turns ratio

The turns ratio is determined during factory acceptance tests and needs to be checked routinely once the transformer is in service. By measuring the ratio and phase angle from one winding to the other, open circuits and shorted turns can be detected.

A low-voltage turns ratio test may not detect a voltage sensitive failure within the transformer. Therefore, for fault investigations, it is recommended that a high-voltage TTR test is performed to apply a higher electrical stress to the insulation system.

8.8.1 High voltage turns ratio – Settings

- ▶ Adjust the settings and enter the necessary values for your test.
- ▶ Tap **Wiring**  to display the wiring diagram for this test and vector group.




Figure 8-15: High voltage turns ratio test – **Settings** view

Table 8-18: High voltage turns ratio– Settings

Option	Description
Winding	
Phases	▶ Set the number of transformer phases.
Auto transformer	▶ Tap Yes if you are testing an auto transformer.
Vector group	▶ Set the vector group: Tap Select winding configuration .
Rated voltage	▶ Enter the transformer’s rated voltage.

Table 8-18: High voltage turns ratio– Settings (continued)

Option	Description
 Copy to all	▶ Tap to copy the winding and tap changer configuration to all tests that have not yet been executed.
Tap changer data	
Tap changer settings	▶ Adjust the tap changer settings by tapping the corresponding icon  .  No tap changer defined  Tap changer has been defined and will be included in the measurement
Tap changer under test	▶ Select which tap changer to include in the measurement if both an OLTC and a DETC have been defined. The tap changer under test is marked with a star ★.
OLTC position	OLTC tap position during tap switching on the DETC
DETC position	DETC tap position during tap switching on the OLTC
Tap changer settings – Define Tap Changer	
▶ Refer to "Defining a tap changer" on page 46.	
Noise suppression	
Averaging (no. of points)	▶ Enter the number of measurement points used for averaging.
Bandwidth	▶ Select the <i>CP TD</i> filter bandwidth from the drop-down list.
Avoid test frequency	If this setting is active, the measurement will <i>not</i> be performed at the Test frequency set in the Measurement section. <i>TouchControl</i> will instead measure two values at frequencies below and above the entered Test frequency and calculate the median of those two values. The Avoid test frequency setting is predefined for the selected test. ▶ Only change the default setting for special applications.
Device settings	
Shield check	ON: The <i>CP TD</i> checks whether the shield of the high-voltage cable is connected.
Beeper	ON: The <i>CP TD</i> beeper is on during the measurement.
Measurement	
Test voltage	Output voltage
Test frequency	Output frequency: • IEEE: 60 Hz • IEC: 50 Hz
Test mode	Test mode for this test: UST-A
Selected phase	▶ After rewiring, select the next phase and press Start .

Table 8-18: High voltage turns ratio– Settings (continued)

Option	Description
Measurement capacitor	
Z abs	Absolute impedance value
Z phase	Phase angle of the impedance
Automatic tap control	
▶ See "Keeping results" on page 58 for more information.	
Select	▶ Select ON to activate the automatic tap control.
↑ Up ↓ Down	▶ If automatic tap control is ON , use the Up and Down buttons in the Settings view to switch between the taps and check if your wiring is correct.
Tap time	Time for the change between two tap positions
Impulse time	Duration of the impulse triggering the tap change
Start tap	Start tap position of the test
Stop tap	Stop tap position of the test

8.8.2 High voltage turns ratio – Measurement view

In the **Measurement** view, the results are displayed in the **Measurement**  or **Plot**  view.

- ▶ Use the **Current tap position** drop-down box to choose the correct label for the currently measured tap.
- ▶ Tap the arrows  in the table head to sort the results by tap or phase number.




Figure 8-16: High voltage turns ratio test – **Measurement** view with results

Table 8-19: High voltage turns ratio – Measurement, table view

Option	Description
Tap	Tap under test
Phase	Phase under test
Nominal ratio	Nominal transformer ratio
V prim	Output voltage
I sec	Measured current on the secondary side of the transformer
Z sec	V prim divided by I sec Used to calculate the turns ratio
V phase	Phase shift between primary and secondary voltage
TTR	Measured transformer turns ratio

Table 8-19: High voltage turns ratio – Measurement, table view (continued)

Option	Description
Ratio deviation	Deviation of the measured ratio from the nominal ratio
Show results	
V phase	► Choose from the drop-down box which value to display in the table.
Ratio	► Choose between TTR (transformer turns ratio) and VTR (voltage ratio) to be displayed in the result table.

Table 8-20: High voltage turns ratio – Measurement, plot view

Option	Description
Plot type	TTR/VTR: Transformer/voltage ratio over tap position
	TTR deviation: Ratio deviation over tap position
Filter graph	► Select the phases to be displayed in the graph.
Show results	
V phase	► Choose from the drop-down box which value to display in the table.
Ratio	► Choose between TTR (transformer turns ratio) and VTR (voltage ratio) to be displayed in the result table.

Table 8-21: High voltage turns ratio – Capacitor table

Option	Description
V out	Output voltage
I out	Output current
Z abs	Absolute impedance value
Z phase	Phase angle of the impedance

8.9 Power losses at low voltage

The power losses at low voltage test helps detect open circuits, shorted turns or problems with the transformer core. It is performed during factory acceptance tests and for routine checks on a regular basis to comply with the GOST 3484.1 standard, in countries where it is applicable.

Note: The transformer should always be demagnetized before performing a power losses at low voltage test.

TESTRANO 600 currently only supports the power losses at low voltage test on transformers with vector groups YNd11, Yd11 and YNyn0.

8.9.1 Power losses at low voltage – Settings

- ▶ Adjust the settings and enter the necessary values for your test.
- ▶ Tap **Wiring**  to display the wiring diagram for this test and vector group.




Figure 8-17: Power losses at low voltage test – **Settings** view

Table 8-22: Power losses at low voltage – Settings

Option	Description
Winding	
Vector group	▶ Select from vector groups YNd11, Yd11 and YNyn0.
Measurement	
Selected phase	▶ After rewiring, select the next phase and press Start . Only available if Auto shorting is set to OFF .

Table 8-22: Power losses at low voltage – Settings (continued)

Option	Description
Test voltage	▶ Enter the output voltage.
Test frequency	▶ Enter the mains frequency.
Output current limit	▶ Enter the maximum output current.
Auto shorting	ON: Automatic phase switch and short-circuiting of the phases <i>not</i> under test OFF: Manual phase switching via the Phase selection buttons and manual short-circuiting of the phases <i>not</i> under test

8.9.2 Power losses at low voltage – Measurement

In the **Measurement** view, the results are displayed in the **Measurement**  or **Plot**  view.




Figure 8-18: Power losses at low voltage test – **Measurement** view

Table 8-23: Power losses at low voltage – Measurement

Option	Description
Table	
Phase	Phase under test ▶ Refer to the wiring diagram for correct wiring after changing the phase.
V out	Measured output voltage
I out	Measured output current
I phase	Measured current per phase
Watt losses	Measured losses
cos φ	Power factor
Selected phase	
▶ After rewiring, select the next phase and press Start .	

8.10 Quick

Quick is the most basic mode to operate all of the *TESTRANO 600* outputs in a manual-like mode using *TouchControl*.

8.10.1 Quick – Settings

- ▶ Adjust the settings and enter the necessary values for your test.




Figure 8-19: Quick test – **Settings** view

- ▶ Enter the **Output** and **Magnitude** data as required.

Table 8-24: Quick test – Settings

Option	Description
Output	
Signal mode	▶ Set AC or DC as output signal.
Output mode	▶ Select 1-phase or 3-phase voltage (V) or current (A) control from the drop-down list.
Selected output	▶ Select the <i>TESTRANO 600</i> output: HV (red) or LV (yellow) ▶ See 3.1.5 " <i>TESTRANO 600</i> measuring cables" on page 20

Table 8-24: Quick test – Settings (continued)

Option	Description
Magnitude	
Equal magnitude	▶ Tap ON for magnitude distribution to all three phases (phase shift = 120°)
Test frequency	▶ Enter the mains frequency
Measurement	
Phases	Number of phases
HV/LV	▶ Choose the cable pair for the measurement. ▶ Choose between line-to-line (L-L) and line-to-neutral (L-N) voltage.
Result table view	
▶ Tap ON/OFF to activate/deactivate the corresponding value in the Result table in the Measurement view.	

8.10.2 Quick – Measurement

- ▶ Tap **Wiring**  to display the wiring diagram for this test and vector group.
- ▶ Tap **Vector**  to switch to polar coordinate system for visualization of the measurement data.
- ▶ To mark a test result for later reference, tap the result's number and press the star icon . Markers will be included in the report file.
- ▶ Tap **Delete result**  to delete the currently open result, and **Delete all**  to delete all results saved during this test.




Figure 8-20: Quick test – **Measurement** view (table form)

Quick test calculation

- ▶ In the **Measurement** view, tap **Add**  to add up to three calculations based on the measured current, voltage and frequency values.
- ▶ In the **Quick Test Calculation** view, choose two channels and the **Calculation type** for each calculation.
- ▶ Tap **Reset calculation** to delete your settings.

8.11 Vector group check

The Vector group check comprises a three-phase turns ratio measurement, neutral detection and a series of single-phase measurements to determine the vector group.

8.11.1 Vector group check – Settings




Figure 8-21: Vector group check – Settings view

Table 8-25: Vector group check – Settings

Option	Description
Measurement	
Test voltage	Maximum output voltage <ul style="list-style-type: none"> ▶ Perform the vector group check using the default value (50 V). ▶ If there is no conclusive result, try increasing the test voltage (Accepted range: 40-120 V).
Test frequency	<ul style="list-style-type: none"> ▶ Enter the mains frequency

8.11.2 Vector group check – Measurement

In the **Measurement** view of the Vector group check, you can observe the maximum values applied during the test.




Figure 8-22: Vector group check – **Measurement** view

Table 8-26: Vector group check – Measurement

Option	Description
V HV	Voltage on high-voltage side
V LV	Voltage on low-voltage side
I	Measured current at HV or LV side of the transformer

After the check is completed, *TouchControl* displays the detected vector group(s).

Note: An unsupported vector group may be caused by magnetization of the transformer core. Please run a demagnetization test in Yd5 or Dy5 configuration (see 8.1 "Demagnetization" on page 51) and run the Vector group check sequence again.

- In the case of an unsupported vector group, a list of properties based on the test result's raw data will be shown.

Table 8-27: Undetected vector group(s) listed results

Property	Description
Phase shift	N-times 30°, where N is the phase shift (0-11)
HV neutral detected	Neutral terminal accessible and connected on HV side
LV neutral detected	Neutral terminal accessible and connected on LV side
HV-LV connection detected	Galvanic connection between HV and LV sides
HV Y-Winding detected	Star winding present on HV side
LV Y-Winding detected	Star winding present on LV side

► Tap the vector group. *TouchControl* then transfers it to the **Settings** view.

You can now determine the **Tap changer data** – see "Defining a tap changer" on page 46.

► Tap **Copy to all**  to copy the winding and tap changer configuration to all tests that have not yet been executed.

Errors during the test

The following errors may appear when conducting the Vector group check:

Table 8-28: Error messages during the Vector group check

Error	Description
Test aborted. Unsupported transformer phase shift detected.	Unexpected phase shift: the three phases need to have the same phase number/shift
Test aborted. Unsupported ratio detected. Please check the wiring to the transformer.	Unexpected ratio: LV is higher than HV

8.1 Cooldown

The Cooldown test is performed to determine the winding temperature at the end of the heat run procedure by means of a winding resistance measurement.

8.1.1 Cooldown – Settings

- ▶ Adjust the settings and enter the necessary values for your test.
- ▶ Tap **Wiring**  to display the wiring diagram for this test.




Figure 8-23: Cooldown test – **Settings** view

Table 8-29: Cooldown – Settings

Option	Description
Winding	
Phases	▶ Set the number of transformer phases.
Auto transformer	▶ Tap Yes if you are testing an auto transformer.
Vector group	▶ Set the vector group: Tap Select winding configuration .
Rated voltage Rated current	▶ Tap the drop-down box to choose between Rated voltage and Rated current , and then enter the applicable value.
 Copy to all	▶ Tap o copy the winding and tap changer configuration to all tests that have not yet been executed.

Table 8-29: Cooldown – Settings (continued)

Option	Description
Tap changer data	
Tap changer settings	▶ Adjust the tap changer settings by tapping the corresponding icon  .
	 No tap changer defined
	 Tap changer has been defined and will be included in the measurement
Tap changer under test	▶ Select which tap changer to include in the measurement if both an OLTC and a DETC have been defined. The tap changer under test is marked with a star  .
OLTC position	Current tap position of the OLTC
DETC position	Current tap position of the DETC
Tap changer settings – Define Tap Changer	
▶ Refer to "Defining a tap changer" on page 46.	
Measurement	
Selected phase	Selected measured phase: A, B or C
Selected tap	Current tap position of the tap changer under test
Output mode	50 A @ 120 V Fast magnetization with elevated voltage
	100 A @ 56 V For assets with expectedly very low resistances
Test current	Current output during the test
Meas. on cool transformer	
Material	Material of transformer winding
T ref.	Reference temperature of transformer winding
R 1 at T ref.	Resistance 1 of transformer winding at reference temperature
R 2 at T ref.	Resistance 2 of transformer winding at reference temperature
Timer	
Measurement interval	Sampling time interval at which the winding resistance is measured
Recording	Total measurement time
Start timer Reset timer	▶ Tap Start timer at the end of the heat run procedure to start time measurement. ▶ Tap Reset timer to reset the timer. You can reset the timer only when the measurement is not running and the test has no results.

8.1.2 Cooldown – Measurement view

With the Cooldown test, you can measure the resistance of two transformer windings simultaneously. You can wire the transformer according to your needs. For detailed information about connecting TESTRANO 600 to the transformer, see the wiring diagram on the screen.

The measurements are displayed in the **Measurement** or **Plot** view.

▶ Tap the arrows in the table heads to sort the results.




Figure 8-24: Cooldown test – Measurement view

Table 8-30: Cooldown – Measurement

Option	Description
Time	Time elapsed since the timer was started
R dev	Percentage deviation of the resistance 1 among the last 20 values measured (same as of the resistance 2 due to common transformer core)
R meas 1	Measured resistance 1
Temp. 1	Temperature of the resistance 1
R meas 2	Measured resistance 2

Table 8-30: Cooldown – Measurement (continued)

Option	Description
Temp. 2	Temperature of the resistance 2
I DC	Measured current
V DC 1	Measured voltage across the resistance 1
V DC 2	Measured voltage across the resistance 2

To perform the Cooldown test:

1. Start the heat run procedure.
2. In the **Settings** view, enter the test settings.
3. Tap **Start timer** simultaneously with the end of the heat run procedure.
4. Connect *TESTRANO 600* to the transformer under test (see the wiring diagram on the screen).
5. Tap **Start** to start the measurement.
6. In the **Measurement** view, observe the R dev value and tap **Keep Result** to take the first result manually when the R dev value becomes stable.

Note: You must repeat step 6 if the test has been stopped and resumed.

Note: After the first measurement has been recorded the following measurements are automatically recorded in the time intervals specified in the test settings. The measurement automatically stops and discharges the winding after the total recording time has been reached.

9 *Primary Test Manager*

9.1 Introduction

Primary Test Manager is a management tool for testing primary assets such as power transformers, circuit breakers, and current transformers with the OMICRON test systems. *Primary Test Manager* provides a computer interface to the test set, controls the automated test procedures, and facilitates testing of primary assets by guiding you through the test workflow.

Primary Test Manager uses the concept of jobs. A job contains all relevant information about the location, the asset under test, and the tests. With *Primary Test Manager*, you can process jobs as separate entities.

With *Primary Test Manager*, you can manage locations, assets, jobs and reports, create new jobs, open jobs, and perform tests. For a specified job, you can make measurements on the asset under test by just pressing the **Start/Stop** button on the front panel of the *TESTRANO 600* test system. After you have performed a test, you can generate exhaustive test reports. *Primary Test Manager* runs on a computer and communicates with the test set through the Ethernet connection.

9.2 Installing *Primary Test Manager*

For the minimum requirements your computer needs to run the *Primary Test Manager* software, see 9.5 "Primary Test Manager system requirements" on page 106.

To install *Primary Test Manager*:

1. Connect the computer's Ethernet port to the network connector of *TESTRANO 600* using an Ethernet cable.

Note: You can operate *Primary Test Manager* without connection to *TESTRANO 600*. The computer running *Primary Test Manager* must be connected to *TESTRANO 600* in order to run tests.

2. Switch on *TESTRANO 600*.
3. Insert the *Primary Test Manager* DVD into the DVD drive of your computer and follow the instructions on the screen.

Note: Upgrade your *TESTRANO 600* during the installation, if necessary.

9.3 Software start and device update

9.3.1 Connecting to *TESTRANO 600*

- ▶ Start *Primary Test Manager* via the Windows Start menu or the desktop icon.
- ▶ To connect to *TESTRANO 600*, select the device from the list in the *Primary Test Manager* home view.
- ▶ In *Primary Test Manager* click **Connect** after selecting the device.



Figure 9-1: Connecting to *TESTRANO 600* via *Primary Test Manager*

If you were not able to connect to your *TESTRANO 600* and the green light is permanently on, wait a few seconds, then do one of the following:

- ▶ Click **More** next the **Connect** button, and then click **Refresh** (or press F5).

If the *TESTRANO 600* device to which you want to connect is not displayed in the list of available devices, proceed as described in "Manual connection to a test system" on page 119.

Alternatively, you can manage the connection to *TESTRANO 600* in the *Primary Test Manager* status bar (see 9.6.4 "Manage connection to the test system" on page 119).

9.3.2 Firewall configuration

If you can not connect to your *TESTRANO 600*, check your firewall configuration since a correct firewall configuration is essential for successful establishing a communication between *TESTRANO 600* and your computer.

Note: Any change to the firewall settings mentioned in this section requires administrator rights on your computer.

Windows firewall

The configuration of the Windows firewall is carried out automatically during the installation of *Primary Test Manager*. However, in certain cases this may have no immediate effect.

- ▶ To prevent the Windows firewall from blocking communication, (temporarily) disable it via the Windows Control panel.

If you are now able to successfully establish communication, the Windows firewall was the reason for the blocked communication between your test set and your computer.

- ▶ Reconfigure the Windows firewall in order to enable a permanent use of the test set without having to disable the Windows firewall.
For more information, see "Manual firewall configuration" later in this section.

Third-party firewall

- ▶ If you are using a firewall other than the Windows firewall, temporarily disable it to see if this firewall may be the cause for the blocked communication.

For more information on configuring a third-party firewall to allow a permanent communication between *TESTRANO 600* and your computer, see "Manual firewall configuration" later in this section.

Note: Numerous computer security programs or anti-virus packages also contain an integrated firewall function. Double-check and, if applicable, remove all such programs that may be installed on your computer.

Manual firewall configuration

If you would like to manually configure your firewall settings, the following ports/services have to be open in order to get a functional communication.

Table 9-1: Inbound rules

Program/service name	Rule name	Protocol type	Local port	Remote port	Local IP	Remote IP
OMFind.exe ¹	OMICRON OMFind 4987 (UDP-In)	UDP	4987	Any	Any	Any
	OMICRON OMFind 4988 (UDP-In)	UDP	4988	Any	234.5.6.7	Any
	OMICRON OMFind 4987 (UDP-In)	UDP	4987	Any	Any	Any
	OMICRON OMFind 4988 (UPD-In)	UDP	4988	Any	234.5.6.7	Any
OMComm.exe ²	OMICRON Device Detection (In)	UDP	4987, 4988	Any	Any	Any
Any	OMICRON Interprocess Communication	TCP, UDP	Any	Any	127.0.0.0/8	127.0.0.0/8

- Default installation path:
64-bit: C:\Program Files (x86)\Common Files\OMICRON
32-bit: C:\Program Files\Common Files\OMICRON
- Default installation path:
C:\Program Files\Common Files\OMICRON\OMCOMM\omcomm.exe

Table 9-2: Outbound rules

Program/service name	Rule name	Protocol type	Local port	Remote port	Local IP	Remote IP
Any	OMICRON TESTRANO (ICMPv4-Out)	ICMPv4	Any	Any	Any	Any
	OMICRON OMFind (ICMPv4-Out)	ICMPv4	Any	Any	Any	Any
	OMICRON Primary Test Manager (ICMPv4-Out)	ICMPv4	Any	Any	Any	Any
	OMICRON Device Detection (ICMP)	ICMP	Any	Any	Any	Any
	OMICRON Interprocess Communication	TCP, UDP	Any	Any	127.0.0.0/8	127.0.0.0/8
	OMICRON Test Set Communication	TCP	Any	2200 - 2204	Any	Any
ODBFileMonitor.exe ¹	OMICRON Device Browser File Monitor FTP CMD (TCP-Out)	TCP	Any	21	Any	Any
	OMICRON Device Browser File Monitor FTP DATA (TCP-Out)	TCP	Any	3000 - 3020	Any	Any

Table 9-2: Outbound rules (continued)

Program/service name	Rule name	Protocol type	Local port	Remote port	Local IP	Remote IP
OMFind.exe ¹	OMICRON OMFind 4988 (UDP-Out)	UDP	Any	4988	Any	234.5.6.7
PTM.exe ²	OMICRON TESTRANO 8816 (TCP-Out)	TCP	Any	8816	Any	Any
OMComm.exe ³	OMICRON Device Detection (Out)	UDP	Any	4988	Any	Any
DeviceLink.exe ⁴	OMICRON DeviceLink	UDP	Any	69	Any	Any

1. Default installation path:
64-bit: C:\Program Files (x86)\Common Files\OMICRON
32-bit: C:\Program Files\Common Files\OMICRON
2. Default installation path: C:\Program Files\OMICRON\PTM
3. Default installation path: C:\Program Files\Common Files\OMICRON\OMCOMM\omcomm.exe
4. Default installation path: C:\Program Files\Common Files\OMICRON\DeviceLink\DeviceLink.exe

9.3.3 Updating the TESTRANO 600 embedded software

The TESTRANO 600 embedded software must be compatible with the *Primary Test Manager* software. You can update the TESTRANO 600 embedded software by following the steps below:

1. In the *Primary Test Manager* home view, select the device you want to update from the list.
2. Click **More** beneath the **Connect** button, and then click **Update device software**.
3. In the **Select TESTRANO Upgrade Image** dialog box, double-click the `embeddedImage.tar` file.
▶ Alternatively, select the device you want to update from the list, and then click **Connect**. *Primary Test Manager* will prompt you to update the TESTRANO 600 embedded software, if necessary.

9.3.4 Upgrading the TESTRANO 600 firmware

After upgrading the TESTRANO 600 embedded software, you might also need to upgrade the firmware of TESTRANO 600. If a firmware upgrade is necessary, a message is displayed on top of the screen.

- ▶ To upgrade the TESTRANO 600 firmware, click **Start firmware update**.

Manual software upgrade using Device Link

If you encounter any problems when upgrading the TESTRANO 600 embedded software in the *Primary Test Manager* home view, we recommend using the **Device Link**.

To update TESTRANO 600 license by using **Device Link**:

1. Exit *Primary Test Manager* if it is running.
2. Double-click the **Device Link** icon  on the desktop.
3. In the **Device Link** window, left-click the TESTRANO 600 device you want to update, and then click **Manage licenses** to progress to the file selection screen.
4. Select the license upgrade package (.upg) and click **Open**.
5. Click **Yes** to proceed with the licence upgrade when prompted.
6. After the update has finished, reboot the TESTRANO 600 device.

For detailed information, contact your OMICRON local sales representative or distributor.

9.3.5 Device web interface

On the device website, you can get log files, roll back software images, reboot the device and manage license files.

To open the device web interface:

1. In the home view, select the device from the list.
2. Click **More** beneath the **Connect** button, and then click **Open device web interface**.
A website with the IP address of the device opens in the default web browser.

9.4 Primary Test Manager licensing

Table 9-3: Primary Test Manager licenses

License	Description
PTM Standard	Manual control mode with tests according to your <i>TESTRANO 600</i> license. Additional 30 testing days with guided workflow according to your <i>TESTRANO 600</i> license.
PTM Advanced	Unlimited testing with guided workflow and manual tests according to your <i>TESTRANO 600</i> license.

The PTM Advanced license key is on the device. You can upgrade your *TESTRANO 600* on the *TESTRANO* start page via "Open Device website".

9.5 Primary Test Manager system requirements

Table 9-4: Primary Test Manager system requirements

Characteristic	Requirement (*recommended)
Operating system	Windows 10 64-bit*
CPU	Multicore system with 2 GHz or faster* , single-core system with 2 GHz or faster
RAM	min. 4 GB (8 GB*)
Hard disk	min. 5 GB of available space
Storage device	DVD-ROM drive
Graphics adapter	Super VGA (1280×768) or higher-resolution video adapter and monitor ¹
Interface	Ethernet NIC ² , USB 2.0 ³
Installed software required for the optional Microsoft Office interface functions	Microsoft 365* , Office 2019, Office 2016, Office 2013

1. We recommend graphics adapter supporting Microsoft DirectX 9.0 or later.
2. For testing with *TESTRANO 600*, *CPC 100* and *CIBANO 500*. NIC = Network Interface Card. *TESTRANO 600*, *CPC 100* and *CIBANO 500* can be connected with RJ-45 connectors either directly to the computer or to the local network, for example, by using an Ethernet hub.
3. For testing with *FRANEO 800*

9.6 Home view

After starting *Primary Test Manager*, the home view opens. In the home view, you can select different user tasks designed to support you during diagnostic testing and management of test objects and test data.




Figure 9-2: *Primary Test Manager* home view

Primary Test Manager processes data of different workflow importance. This is indicated by balloons of different categories as described in the following table.

Table 9-5: Data importance categories

Balloon	Category	Description
	Mandatory	Indicates data required for performing tests.
	Recommended	Indicates data supporting the <i>Primary Test Manager</i> workflows.
	Information	Contains descriptive information.

Primary Test Manager supports the following user tasks.

Table 9-6: Selecting the user tasks


Button	Description	Action
	Manage	Click to manage locations, assets, jobs, and reports (see 9.8 "Manage objects" on page 159).
	New guided job	Click to start the guided test workflow (see 9.7 "Jobs" on page 125).
	New manual job	Click to create a new manual job (see 9.7.7 "Create new manual jobs" on page 155).
	Open job	Click to open a job (see 9.7.8 "Open jobs" on page 157).

Table 9-7: User interface actions

User interface element	Action
Title bar	
 Settings	Click to open the Settings dialog box (see 9.6.1 "Settings" later in this chapter).
 Help	Click to open the <i>PTM</i> help. Note: Alternatively, select F1 on your keyboard.
 Send data to technical support	Click to send system information and your data to OMICRON technical support (see 9.6.2 "Send data to Technical Support" on page 117).
 About	Click to open the About Primary Test Manager dialog box (see 9.6.3 "About" on page 118).
Device	
Connect/Disconnect	Click to manage connection to the test system (see 9.6.4 "Manage connection to the test system" on page 119).
Data	
Synchronize¹	Click to synchronize your local database with the <i>Primary Test Manager</i> server database (see 9.6.5 "Synchronize data" on page 120).
Import files	Click to import <i>Primary Test Manager</i> data (see 9.6.6 "Import data" on page 122).
Back up your data	Click to back up the <i>Primary Test Manager</i> database (see 9.6.7 "Back up and restore data" on page 122).
Restore data from a backup	Click to restore your data in the database (see 9.6.7 "Back up and restore data" on page 122).
Information	
Click a list item to get information about your test system and its application.	
Recent guided jobs/Recent manual jobs	
Click a list item to open a recently created guided or manual job.	
Status bar	
In the status bar, you can connect to and disconnect from a test system and view the test set information (see 9.6.8 "Status bar" on page 123).	

1. Only enabled with the appropriate license.

9.6.1 Settings

In the **Settings** dialog box, you can make a number of *Primary Test Manager* settings to match your regional conventions, manage the job templates, and set the *Primary Test Manager* server settings for data synchronization (see 9.6.5 "Synchronize data" on page 120).

- ▶ To open the **Settings** dialog box, click  **Settings** in the title bar.

NOTICE

Equipment damage or loss of data possible

Changing the settings in the **Settings** dialog box affects all data in *Primary Test Manager*.

- ▶ Only change settings if you are qualified to do so.
- ▶ Review your changes before clicking **OK**.

Note: After changing a setting, you must restart *Primary Test Manager* for the setting to take effect.

General

On the **General** tab, you can make the general settings of *Primary Test Manager*.




Figure 9-3: **General** tab

- ▶ To set the *Primary Test Manager* language, select your preferred language from the **Language** list.

- ▶ To set the logging level, select your preferred level from the **Logging PTM** and **Logging device** lists. The logging function provides information to help find the cause for an error in cooperation with an OMICRON support engineer. **Logging PTM** collects information on PTM while **Logging device** focuses on your device.

Note: Log files do not contain any information about users or devices.

Table 9-8: Logging levels

Logging level	Description
Disabled	Logging is disabled.
Errors only	Only errors are logged. Recommended setting
Info	Errors and some additional information are logged.
Full	All software-related activities are logged.

Note: Full logging will slow down software performance.

- ▶ To set the types of available devices, select the respective check boxes.

Location settings

In this section you can activate the **Use location information** check box for **Grounding system** tests.

Default test device configuration

In this section *Primary Test Manager* displays the default devices for testing different assets. If more than one device is available for an asset, you can set your preferred test system as default device for that asset.

Note: If no device is connected, *Primary Test Manager* will automatically compile the test list (see section 9.7.5 "Test view" on page 141) for the selected default test set.

Privacy Information / Customer Experience Improvement Program

The **CEIP** collects information about how you use *Primary Test Manager* without interrupting you. This helps OMICRON identify which features to improve. No information collected is used to identify or contact you. We encourage you to join the program to help improve *Primary Test Manager*.

Remote control

Certain features of *Primary Test Manager* can be controlled via the *PTMate* app. Complete the steps below to establish the connection between your smartphone and your computer.

1. Select the **Allow remote control via PTMate** check box in the **Remote control** section of the **Settings** dialog box. *Primary Test Manager* will establish a Wi-Fi access point.
 - ▶ If both your smartphone and your computer are already connected to the same Wi-Fi network, proceed with step 2.
 - ▶ If you are *not* connected to a Wi-Fi network, click the **Start Wi-Fi access point** button. *Primary Test Manager* will attempt to create a Wi-Fi access point and refresh the displayed QR code.

Note: If your computer does not support ad hoc Wi-Fi access point creation, you can use an external Wi-Fi device supporting this functionality or create a hotspot on your smartphone. Be aware that using a smartphone hotspot can lead to additional costs.

2. Open the *PTMate* app on your smartphone, go to **Settings** and scan the QR code displayed in the **Remote control** section in *Primary Test Manager*.

Primary Test Manager displays status icons in the bottom bar:

-  Number of active remote connections
-  Active Wi-Fi access point
-  Active remote control

Profiles

On the **Profiles** tab, you can set your profile, the default rated frequency, the loss index, the units of your own profiles, and make the test system settings.




Figure 9-4: **Profiles** tab: **Global settings**

With *Primary Test Manager*, you can use predefined profiles and create your own profiles for naming conventions.

Note: *Primary Test Manager* sets the default profile according to the regional settings of your computer.

- ▶ To set a profile, select the profile you want to use from the **Profiles** list.

To create your own profile:

1. Click **Create custom profile**.
2. In the **Create custom profile** dialog box, type the profile name, and then click **Create**.
3. Under **Global settings**, set the default rated frequency, the loss index, and your preferred units.

4. Under **Transformer**, set the transformer terminal name schemes and preferences such as the names of some tests, the oil measure, and the short-circuit impedance abbreviation.




Figure 9-5: Profiles tab: Transformer

With *Primary Test Manager*, you can use predefined transformer naming conventions according to the established standards and create your own terminal name schemes.

- ▶ To set a terminal names scheme, select the scheme you want to use from the **Terminal names scheme** list.

To create your own terminal names scheme:

1. Click **Create custom scheme**.
2. In the **Enter scheme name** dialog box, type the scheme name.
3. Set the transformer terminal names, scheme options, and preferences.

- ▶ To delete your own terminal name scheme, select the scheme from the **Terminal names scheme** list, and then click **Delete current scheme**.

Templates and libraries

On the **Templates and libraries** tab, you can edit, import and export job templates for **Transformers**. For information on how to process the templates, see "Processing templates" on page 149.




Figure 9-6: **Templates** tab

To manage the job templates, select **Transformer** from the **Display templates for** list, and then do one of the following:

- ▶ To assign a template to a different asset type or a phase group, or to edit template properties (name, comment), click the respective **Edit**  button.
- ▶ To delete templates from the **Asset type** or **Phases** list, click the **Delete**  button.
- ▶ To export a template, select the template, and click the **Export**  button.
- ▶ To import a template, click the **Import**  button, then browse to the template you want to import.
- ▶ To set a template as favorite, click the star icon .

Note: All future test lists with the same asset and number of phases will by default be loaded with the tests defined in this favorite template.

The right pane of the template workspace displays the template preview.

Databases

On the **Databases** tab you can create, manage and optimize (comprise) the *Primary Test Manager* database, and switch between different databases. Under **Properties**, you can adjust the server settings for *DataSync*. For more information, see "Server settings" on page 120.




Figure 9-7: **Databases** tab

Inspection test

On the **Inspection test** tab you can create and manage inspection test work flows by naming a template, defining the asset kind and type information and by creating a check list. For more information, see "Server settings" on page 120.




Figure 9-8: Inspection test tab

9.6.2 Send data to Technical Support

In the **Contact Technical Support** dialog box, you can send system information and your data to OMICRON technical support.

- ▶ To open the **Contact Technical Support** dialog box, click  **Send data to Technical Support** in the title bar.




Figure 9-9: **Contact Technical Support** dialog box

1. In the **Contact Technical Support** dialog box, select your region, and then click **Next**.
2. The system will collect system information which may take a while.
3. After collection of data is finished click **Next**.
4. Click **Add files**.
5. Browse to the data you want to send, and then click **Next**.
6. Select the method of sending and follow the instructions shown.
7. In case you want to use the e-mail sending option click **Prepare e-mail**.

9.6.3 About

In the **About Primary Test Manager** dialog box, you can enter license keys to upgrade your *Primary Test Manager* and enhance its functionality by installing additional features.

► To open the **About Primary Test Manager** dialog box, click  **About** in the title bar.




Figure 9-10: **About Primary Test Manager** dialog box

To activate a license:

1. Enter the license key in the **About Primary Test Manager** dialog box, and then click **Add license key**.
The **About Primary Test Manager** dialog box displays the available licenses and a new **Enter license key** box.
2. Repeat step 1 for all license keys you want to enter.

Alternatively, you can enter license keys from files. To enter a license key from a file, click **Add license from file**, and then browse to the file containing the license you want to add.

For detailed information about the *Primary Test Manager* licensing, contact your OMICRON local sales representative or distributor.

9.6.4 Manage connection to the test system

Under **Device**, you can connect to and disconnect from the test system.

- ▶ To connect to a *TESTRANO 600* device, select the device from the list, and then click **Connect**.



Figure 9-11: Connecting to *TESTRANO 600*

If you could not connect to your *TESTRANO 600* device and the green light is permanently on, wait a few seconds, and then proceed as follows:

1. Click **More** next to the **Connect** button, and then click **Refresh**.
2. Select the test system from the list, and then click **Connect**.

Alternatively, you can manage the connection to *TESTRANO 600* in the *Primary Test Manager* status bar (see 9.6.8 "Status bar" on page 123).

Device self-test

If *Primary Test Manager* repeatedly displays a hardware error message, we recommend performing a device self-test. The self-test checks functionality of the *TESTRANO 600* hardware components.

You can run the hardware self-test from the **Test Set Information** window (see Figure 9-15: "Test set information dialog box after connecting to *TESTRANO 600*" on page 124).

- ▶ If the self-test passes but the error messages persist, check the wiring.

Note: During the self-test, the **Emergency Stop** button must be released.

Manual connection to a test system

If you encounter any problems when connecting to *TESTRANO 600* we recommend turning off any wireless adapter and VPN software on your computer.

If the *TESTRANO 600* device to which you want to connect is not displayed in the list of available devices, proceed as follows:

1. Open the **Device Link**.
2. Locate your *TESTRANO 600* device from the list and check the IP address displayed for the device.
3. In the home view, click **More** beside the **Connect** button, then click **Add device manually**.
4. In the **Add Device Manually** dialog box, type the IP address of the device you want to connect to.
5. Click **Connect**.

If you assigned a static IP address to the device, you can try to connect as follows:

1. In the **Add Device Manually** dialog box, select the **Direct connection** check box.
2. In the **Host or IP** box, type *tts://a.b.c.d*, where *a.b.c.d* is the static IP address of the device.

9.6.5 Synchronize data

Primary Test Manager comes with the client/server architecture. With this feature, you can synchronize your local database with the *Primary Test Manager* server database. The data synchronization is a partial data replication based on subscriptions, that is, all local data is synchronized with the server database and selected data on the server is synchronized with the local database.

Note: To synchronize your data, you need a license. To get the license, contact your regional OMICRON Service Center or sales partner. You can find our Service Center or sales partner closest to you at www.omicronenergy.com.

Server settings

Before synchronizing the *Primary Test Manager* databases for the first time, you need to set the server settings.

1. In the title bar, click **Settings** and select the **Databases** tab.
The next step depends on the data synchronization method you use: *DataSync* via web server or *DataSync* on premises.
 - ▶ For the service URL and certificate for *DataSync* via web server, contact your regional OMICRON Service Center.
 - ▶ For the service URL and certificate for *DataSync* on premises, contact your system administrator.




Figure 9-12: Server settings for *DataSync*

2. Enter the **Service URL** and upload the **Certificate**.
3. To test the connection to the server, click **Test** next to **Connection status**.

You can create different databases for testing and switch between them.

- ▶ Use the corresponding buttons next to **Database** to create, optimize or delete a database.
- ▶ To switch to a different database, select it from the **Database** list.

Managing subscriptions

You can select data on the server which you want to synchronize with your local data by managing subscriptions. To manage subscriptions:

1. In the home view, click the **Manage** button .




Figure 9-13: Manage view

2. In the manage view, click **Manage subscriptions** on the ribbon.
3. In the **Subscriptions** dialog box, select the data on the server you want to synchronize with your local data.

Database synchronization

- ▶ To synchronize the local *Primary Test Manager* database with the server database: In the home view, click **Synchronize**.

Note: You can synchronize databases at any time, as long as a connection to the server database is available.

When the database synchronization is complete, the locations, assets, and jobs (objects) newly added to the local database are marked with blue dots in the manage view. You can sort the objects by this column. As soon as you open an object, its blue dot is removed. All blue dots are removed when you perform another database synchronization.

9.6.6 Import data

In the home view, you can import *Primary Test Manager* jobs.

To import a job:

1. Under **Data**, click **Import files**.
2. Browse to the file you want to import.

Primary Test Manager supports the following file import formats.

Table 9-9: Supported file import formats

File name extension	Description
.ptm	<i>Primary Test Manager</i> native exchange format
.ptma	Format for import of manual test data. ¹

1. To import manual test data, you must select the corresponding asset in the manage view.

9.6.7 Back up and restore data

We strongly recommend backing up your data in the *Primary Test Manager* database on a regular basis. *Primary Test Manager* reminds you to back up the data periodically by prompting you to save the data in your preferred location. The data is backed up in DBPTM format. You can back up and restore the data in the *Primary Test Manager* home view.

To back up the data without the *Primary Test Manager* prompt:

1. Under **Data**, click **Back up your data**.
2. Save the data in your preferred location.

To restore the data:

1. Under **Data**, click **Restore data from a backup**.
2. Browse to the file you want to restore.

9.6.8 Status bar

The status bar displays the status of the test system, and provides access to the zoom function. In the status bar, you can connect to and disconnect from a test system, and show and refresh the test set information.

Table 9-10: Test system icons

Icon	Connected device
	TESTRANO 600
	CP TD

To connect to a test system:

1. In the status bar, right-click **Not connected**, and then click **Connect**.




Figure 9-14: **Test set information** dialog box before connecting to *TESTRANO 600*

2. In the **Test set information** dialog box, select the test system from the list, and then click **Connect**.

Note: Select the **Automatic connection if only one device detected** check box if only one device is available. Then *Primary Test Manager* connects to the available device automatically.

If you could not connect to your *TESTRANO 600* device and the green light is permanently on, wait a few seconds, and then proceed as follows:

1. Click **More** next to the **Connect** button, and then click **Refresh**.
2. Select the test system from the list, and then click **Connect**.

After you have connected to the test system, the following dialog box appears.




Figure 9-15: **Test set information** dialog box after connecting to *TESTRANO 600*

After you have connected to a test system, right-click the *TESTRANO 600* icon in the status bar, and then do one of the following:

- ▶ To display information about the connected test system, click **Show test set information**.
- ▶ To update the test set information, click **Refresh test set information**.
- ▶ To disconnect from a test system, click **Disconnect**.

Note: You can open the **Test set information** dialog box also by double-clicking the *TESTRANO 600* icon.

9.7 Jobs

When creating a new job, *Primary Test Manager* leads you through the guided test workflow.

► To open the new guided job view, click the **New guided job** button  in the home view.

A job contains all relevant information about the location, the asset under test, and the tests. With *Primary Test Manager*, you can process jobs as separate entities. During the guided test workflow, the job status displayed in the left pane of the new guided job view changes. The following table describes the job statuses.

Table 9-11: Job statuses

Status	Description
New	Location has been defined.
Prepared	Asset has been defined.
Partially executed	At least one measurement has been executed.
Executed	All tests of the job have been executed.
Approved	Job has been approved.

9.7.1 Guided test workflow

The guided test workflow leads you through the following steps:

1. Enter the job data (see 9.7.2 "Job overview" on page 128).
2. Specify the location (see 9.7.3 "Location view" on page 130).
3. Specify the asset (see 9.7.4 "Asset view" on page 132).
4. Specify and perform the tests (see 9.7.5 "Test view" on page 141).
5. Generate the test reports (see 9.7.9 "Test reports" on page 157).

To navigate through the test workflow, click the navigation buttons in the left pane of the new guided job view.




Figure 9-16: Navigation buttons

Note: You can interrupt the test workflow and return to any view at any time by clicking the corresponding navigation button.

By using the commands on the ribbon, you can process jobs. The following table describes the available operations.

Table 9-12: Operations on the jobs

Command	Action
Home/Manage	Closes a job displayed in the new guided job view and leads you back to home or manage view respectively.
Save job	Saves the job displayed in the new guided job view.
Export job	Exports the job displayed in the new guided job view into a Microsoft Excel spreadsheet.
Load existing location ¹	Load an existing location available in <i>Primary Test Manager</i> .

Table 9-12: Operations on the jobs (continued)

Command	Action
Load existing asset ²	Load an existing asset available in <i>Primary Test Manager</i> .
Copy test ³	Adds another test of the same kind and with the same settings to the test list. Results are not copied.
Delete test ³	Deletes the currently active/selected test.
Take screenshot ³	Takes screenshot of the selected area of the <i>Primary Test Manager</i> workspace. The screenshot appears as attachment in the General area and can be attached to the test report (see 9.7.9 "Test reports" on page 157).

1. Only available if the **Location** view is open and job has not been saved yet.
2. Only available if the **Asset** view is open and job has not been saved yet.
3. Only available if a test is open

For more information about operations on the jobs, see 9.8 "Manage objects" on page 159.

9.7.2 Job overview

In the job overview, you can enter the job data (see Table 9-13: "Job data" on page 128). In the course of the guided test workflow, *Primary Test Manager* sets also some basic location, asset, and test data.

► To open the job overview, click the **New guided job** button  in the home view.




Figure 9-17: Job overview

Job data

The following table describes the job data.

Table 9-13: Job data

Data	Description
Name ¹	Name of the job (by default generated by <i>Primary Test Manager</i>)
Work order	Work order of the job
Creation date	Date the job was created
Execution date	Date the job was executed
Tested by	Person who performed the job
Approved by	Person who approved the job
Approval date	Date the job was approved (see "Approving jobs" later in this section)

1. Mandatory data

Approving jobs

If the job data displayed in the job overview has been approved, you can set the approval date of the job.

- ▶ To set the job approval date, click **Approve**.

Note: After approving a job, some settings cannot be edited anymore. The job approval cannot be undone.

Assessment summary

In the Tests area of the job overview, the result state and assessment status of the test results and the execution date are displayed.

- ▶ Use the **Overall Assessment** combo box to manually characterize the asset's condition for reporting purposes.

Table 9-14: Assessment statuses in the job overview

Status	Description
Fail	The status was automatically set to <i>Fail</i> by <i>Primary Test Manager</i> .
Manual fail	The status was manually set to <i>Fail</i> .
Investigate	The status was automatically set to <i>Investigate</i> by <i>Primary Test Manager</i> .
Manual investigate	The status was manually set to <i>Investigate</i> .
Pass	The status was automatically set to <i>Pass</i> by <i>Primary Test Manager</i> .
Partial pass	Some measurements have not been assessed.
Manual pass	The status was manually set to <i>Pass</i> .
Manual partial pass	Some measurements have not been assessed and at least one assessment status was changed manually.
Not assessed	The measurement has not been assessed.
Not rated	The status was automatically set to <i>Not Rated</i> by <i>Primary Test Manager</i> .

Managing attachments

Under **Attachments**, you can manage attachments to jobs.

- ▶ To add an attachment to a job, click the **Add** button , and then browse to the file you want to attach to the job.
- ▶ To open an attachment, select the attachment, and then click the **Open** button , or double click the attachment.
- ▶ To remove an attachment from a job, select the attachment you want to delete, and then click the **Remove** button .

9.7.3 Location view

In the location view, you can specify locations.

- ▶ To open the location view, click the **Location** navigation button .




Figure 9-18: Location view

To specify a location, do one of the following:

- ▶ Enter the location data.

Note: If you enter location or asset data for a prepared job that differ from those of the master location or master asset, a notification bar will be displayed. In this case, choose between the following options:

- ▶ To import the previously defined location or asset data to this job, click **Import from master location** or **Import from master asset** in the notification bar.
- ▶ To update the previously defined location or asset data with the data you have entered for this job, click **Update master location** or **Update master asset** in the notification bar.
- ▶ For more information on operations on the jobs, see 9.8 "Manage objects" on page 159.

- To load the location data available in *Primary Test Manager*, click **Load existing location** on the ribbon, and then select the location you want to load in the **Select Location** dialog box.




Figure 9-19: **Select Location** dialog box

In the **Select Location** dialog box, you can search for locations (see "Search for objects" on page 160).


In the location view, you can enter addresses of, for example, a client, owner or utility.

- To enter additional addresses, click **Add address** under **Additional addresses**.

Setting the geo coordinates

To set the geo coordinates of a location:

1. In the location view, click **Edit coordinates**.



NOTE: Coordinate system is WGS84

Figure 9-20: **Edit Coordinates** dialog box

2. In the **Edit Coordinates** dialog box, enter the latitude and longitude of the location.

Managing attachments

Under **Attachments**, you can manage attachments to locations.

- ▶ To add an attachment to a location, click the **Add** button **+**, and then browse to the file you want to attach to the job.
- ▶ To open an attachment, select the attachment, and then click the **Open** button **📁**, or double click the attachment.
- ▶ To remove an attachment from a location, select the attachment you want to delete, and then click the **Remove** button **-**.

9.7.4 Asset view

In the asset view of the new guided job view, you can specify assets.

- ▶ To open the asset view, click the **Asset** navigation button **📊**.




Figure 9-21: Asset view

The asset view depends on the asset you want to specify with *Primary Test Manager*. To specify an asset, do one of the following:

- ▶ Enter the asset data. The asset data includes the general asset data common to all assets (see "General asset data" on page 134 and the asset-specific data described in chapter 11 "PTM Asset data" on page 167).

Note: If you enter location or asset data for a prepared job that differ from those of the master location or master asset, a notification bar will be displayed. In this case, choose between the following options:

- ▶ To import the previously defined location or asset data to this job, click **Import from master location** or **Import from master asset** in the notification bar.
- ▶ To update the previously defined location or asset data with the data you have entered for this job, click **Update master location** or **Update master asset** in the notification bar.
- ▶ For more information on operations on the jobs, see 9.8 "Manage objects" on page 159.
- ▶ To load the asset data available in *Primary Test Manager*, click **Load existing asset** on the ribbon, and then select the asset you want to load in the **Select asset** dialog box.




Figure 9-22: **Select asset** dialog box

In the **Select asset** dialog box, you can search for assets (see "Search for objects" on page 160) and sort them alphabetically or in the chronological order.

General asset data

The following table describes the general asset data.

Table 9-15: General asset data

Data	Description
Asset ¹	Asset under test
Asset type	Type of the asset
Serial no. ¹	Serial number of the asset
Manufacturer	Manufacturer of the asset
Manufacturer type	Type of the asset according to the manufacturer
Manufacturing year	Year of the asset's manufacturing
Asset system code	Code of the asset used by the maintenance planning systems
Apparatus ID	Identifier of the asset
Feeder	Feeder the asset is connected to
Phase ²	Phase the asset is connected to

1. Mandatory data

2. Only available for current transformers, voltage transformers and miscellaneous assets.

Managing attachments

- ▶ To add an attachment to an asset, click the **Add** button  , and then browse to the file you want to attach to the asset.
- ▶ To open an attachment, select the attachment, and then click the **Open** button  , or double click the attachment.
- ▶ To remove an attachment from an asset, select the attachment you want to delete, and then click the **Remove** button  .

Transformer view

In the transformer view, you can specify transformers and assets associated with the transformer such as bushings, tap changers, and surge arresters.

Specifying a transformer

1. From the **Asset** list, select **Transformer**.
2. From the **Asset type** list, select the type of the transformer.




Figure 9-23: Transformer view

3. In the transformer view, enter the general asset data.
 - ▶ See Table 9-15: "General asset data" on page 134.
4. Under **Winding configuration**, set the transformer's vector group.
 - ▶ See "Setting the vector group of a transformer" on page 136.
5. Under **Ratings, Impedances** and **Others**, enter the transformer data.
 - ▶ See 11.1 "Transformer data" on page 167.
6. Optionally, specify the bushing mounted on the transformer.
 - ▶ See "Bushings tab (Transformer)" on page 137.
7. Optionally, specify the tap changers of the transformer.
 - ▶ See "Tap changers tab" on page 138.
8. Optionally, specify the surge arresters mounted on the transformer.
 - ▶ See "Surge arresters tab" on page 139.

Setting the vector group of a transformer

You can set the vector group manually or use the **Vector group check** to determine it.

- ▶ For more information, see 12.14 "Vector Group Check test" on page 213 and 12.24 "Manual Vector Group Check" on page 238.

To manually set the vector group in the transformer view:

1. Select the number of the transformer's phases.
2. Do one of the following:
 - ▶ Select the configuration of the transformer's windings from the respective lists.
 - ▶ Click **Select Winding Configuration** and in the **Edit vector group** dialog box, set the transformer's vector group.




Figure 9-24: **Edit vector group** dialog box

Note: *Primary Test Manager* sets the vector group of an autotransformer without tertiary winding automatically.

Bushings tab (Transformer)

On the **Bushings** tab, you can specify the bushings mounted on the transformer.




Figure 9-25: Transformer view: **Bushings** tab

Specifying a bushing

1. From the **Asset type** list, select the type of the bushing.
2. Enter the bushing data (see 11.2 "Spare bushing data" on page 170).

Under **Copy bushing data**, you can copy data of a bushing to other bushings. To copy the bushing data, select the respective bushings from the **From** and **To** lists, and then click **Copy**.

Tap changers tab

On the **Tap changers** tab, you can specify the tap changers of the transformer.




Figure 9-26: Transformer view: **Tap changers** tab

Specifying an on-load tap changer (OLTC)

1. Select the **OLTC** check box.
2. Enter the OLTC data (see 11.1.2 "Tap changer data" on page 169).
3. Under **Tap changer configuration**, set the tap changer's winding, the tap scheme, and the number of taps.
4. In the **Voltage table** you can either enter each value manually or have them calculated. Click **Calculate** for the voltage table calculation and use one of the three methods:
 - **First and second**: Calculation based on the voltages of the first and second tap
 - **Middle**: Calculation based on the middle tap (rated voltage) and the entered deviation value
In the guided workflow, the rated voltage is automatically transferred from the **Voltage ratings** table under **Asset** data – **Transformer**.
 - **First/middle/last**: Calculation based on the voltages of the first, middle and last tap

Note: **Middle** and **First/middle/last** are only available for odd tap numbers.

► After calculation, compare the calculated values with the nominal values on the nameplate.

Specifying a de-energized tap changer (DETC)

1. Select the **DETC** check box.
2. Enter the DETC data (see 11.1.2 "Tap changer data" on page 169).
3. Under **Tap changer configuration**, set the tap changer's winding, the tap scheme, the number of taps, and the current tap position.
4. Type the voltage of all taps.

To add a tap, select the tap below which you want to add a tap, and then click **Add**.

Note: The added taps match no tap scheme.

- ▶ To delete a tap, select the tap you want to delete, and then click **Delete**.
- ▶ To delete all taps, click **Remove all**.

Surge arresters tab

On the **Surge arresters** tab, you can specify the surge arresters mounted on the transformer.




Figure 9-27: Transformer view: **Surge arresters** tab

Specifying a surge arrester

1. Select the respective **Surge arrester** check box.
2. Enter the surge arrester data (see 11.1.3 "Surge arrester" on page 169).

Under **Copy surge arrester data**, you can copy data of a surge arrester to other surge arresters. To copy the surge arrester data, select the respective surge arresters from the **From** and **To** lists, and then click **Copy**.

DGA Trending

DGA Trending is a licensed feature that visualizes a transformer's historic **Oil analysis** data in various charts and offers a comparison of data recorded at different points in time.

► Refer to 14.1 "Oil Analysis" on page 248 for more detailed information on the **Oil analysis** test.

Spare bushing view

In the spare bushing view, you can specify bushings.

To specify a spare bushing:

1. From the **Asset** list, select **Bushing**.
2. From the **Asset type** list, select the type of the spare bushing.




Figure 9-28: Spare bushing view

3. In the spare bushing view, enter the general asset data (see Table 9-15: "General asset data" on page 134).
4. Enter the spare bushing data (see 11.2 "Spare bushing data" on page 170).

9.7.5 Test view

In the test view, you can select, import and perform tests.

- To open the test view, click the **Tests** navigation button .




Figure 9-29: Test view

The test view is divided into the **Available tests** area, the **Selected tests** area, and the **General test settings** area.

Click the button labeled with the test system with which you want to perform the test on the top of the **Available tests** area. Then *Primary Test Manager* displays the available guided tests and optional manual tests supported for the selected test system and the asset under test.

- To display the guided tests grouped in categories, click the **Show test categories** button .

You can select tests for different test systems supported by *Primary Test Manager* within the same job.

Then the  symbol indicates the tests not available for the connected test system to signal to you that you need to connect another test system before proceeding to execute the job.

The optional manual tests are asset-independent. You can perform the tests for any asset described in this User Manual, but *Primary Test Manager* does not guide you through the tests and provides no test settings data. The manual tests offer a large amount of flexibility to define the test procedures and specify test settings according to your specific needs.

- For more information about the manual tests, see 9.7.7 "Create new manual jobs" on page 155.

The Selected tests area displays the tests you want to perform. By default, *Primary Test Manager* displays the tests recommended by OMICRON.

Selecting tests

- ▶ To add a test or all tests of a category into the Selected tests area, click the **Add** button  next to the test or the category name in the Available tests area.

The tests added to the Selected tests area are displayed under **Tests** in the left pane of the test view.

- ▶ To rename a test, click the test name, and then type the name you want to use.

The Selected tests area displays the test to be performed in the recommended execution order. You can change the order of the tests by dragging them or by using the  and  buttons.

- ▶ To remove a test from the Selected tests area and from the left pane, click the **Remove** button  next to the test name.
- ▶ To open a test, click the test name in the left pane of the test view.

The General test settings area displays the reason of the job, the global test conditions, and some asset specific data.

Grouping tests

You can group tests from the **Selected tests** column in the **Tests** view of a job.

1. In the **Selected tests** area, select the check boxes next to the tests you want to group. Only groupable tests are displayed with a check box.
2. Click the **Group tests** button .

The test groups are displayed under **Tests** in the left pane of the test view.

- ▶ To rename the test group, double-click the test group name.
- ▶ To remove a test from the test group, click the **Ungroup** button  next to the test name.
- ▶ To remove a test group from the **Selected tests** area and from the left pane, click **Remove the selected test** button  next to the test group name.
- ▶ To open a test group, click the test group name in the left pane of the test view. The test group view displays **Settings and conditions** that are common for all tests in this group.
- ▶ In the group's **Test control** section, click **Start all** to start the listed tests in sequence. You can stop measurements and then click **Start** to start individual measurements or **Resume all** to resume the grouped tests in sequence.

Importing tests

In the test view, you can import tests performed with *TESTRANO 600* and even with the test systems not currently supported by *Primary Test Manager*. *Primary Test Manager* supports import of tests of the following formats.

Table 9-16: Supported test formats

File Name Extension	Description
.ptma	<i>Primary Test Manager</i> manual test
.drax	<i>DIRANA</i> native format

You can also import tests in JPG, PDF and any Microsoft Office file format.

To import test data:

1. In the **Selected tests** area, click **Add from file**.
2. Browse to the file you want the import.
3. In the left pane of the test view, click the imported test.




Figure 9-30: Test view after a test has been imported

4. In the workspace of the test view, you can change the test title and the test type.
5. To open the test, click the **Open** button  under **Test data**.

Note: To open a test, you must have installed the associated application software on your computer.

6. You can attach files as described earlier in this chapter and add comments to the test.
- ▶ For information about importing and exporting jobs, see "Import and export jobs" on page 164.

Performing tests

To perform a test:

1. Add the tests you want to perform into the selected tests area (see "Selecting tests" on page 142).
2. In the left pane of the test view, click the test you want to perform.
The test view is then split into the General pane, the Settings and conditions pane, the Measurements pane and, if automatic assessment is available for the test, the Assessment pane. You can expand and collapse the panes by clicking the arrows on the split bars.
3. In the Settings and conditions pane, enter the test settings (see the chapter on the asset tests later in this manual).




Figure 9-31: Test view: Settings and conditions pane

4. In the Assessment pane, enter the automatic assessment parameters and limits, if applicable.




Figure 9-32: Test view: Assessment pane

TESTRANO 600 User Manual

5. Connect the test setup to the asset under test according to the wiring diagram displayed in the General pane. For information about connecting the test setup to the asset under test, see chapter 5 "Application" on page 27.
 - ▶ As soon as you connect *TESTRANO 600* to *Primary Test Manager*, the tap switch command in the bottom bar is available. You can use the arrow buttons to switch a connected OLTC when no measurement is running.




Figure 9-33: Test view: General pane

6. In the Measurements pane, click **Start** to start the selected measurement.




Figure 9-34: Test view: Measurements pane



DANGER

Death or severe injury caused by high voltage or current

The flashing lightning symbol in the *Primary Test Manager* test view indicates that an output of *TESTRANO 600* is active.

- ▶ Do not touch any outputs or cables while the lightning symbol is displayed.
- ▶ If in doubt, press the **Emergency Stop** button.

7. Press the **Start/Stop** button on the front panel of *TESTRANO 600*.




Figure 9-35: Test view during a measurement

After the measurement has been finished, *Primary Test Manager* displays the numeric measurement data and the automatic assessment, if available, in the Measurements pane. To view graphical diagrams of the measurement results, click the **Plot** tab.

8. Repeat steps 6 and 7 for all test measurements.

Note: Some tests support starting all measurements at once by clicking the **Start all** button.

Note: After the test has been performed some asset data relevant for the test configuration cannot be edited anymore.

Processing templates

In the guided test workflow, you can save jobs as templates and open the saved templates. With the help of templates, you can configure jobs according to your needs (for example, for repeated routines), and then repeatedly perform tests you only have to define once. When you create a new job, the favorite template for the corresponding asset type and number of phases is loaded automatically, if available.

To save a job as template:

1. In the guided test workflow, configure a job.
2. In the **Selected tests** area of the test view, click **Save as template**.

Figure 9-36: **Save Tests as New Template** dialog box

3. In the **Save Tests as New Template** dialog box:
 - ▶ Select the **Asset type** and number of **Phases**.
 - ▶ Enter a **Name** for the template.

4. Optionally, you can add a customized Microsoft Excel report template (see 9.7.9 "Test reports" on page 157) to the job template.

- ▶ To add a Microsoft Excel report template, click **Select template**, and then browse to the report template you want to add.

To open a template:

1. In the Selected tests area of the test view, click **Open template**.




Figure 9-37: **Choose Template** dialog box

2. In the **Choose Template** dialog box, select the asset type, the number of phases and the template you want to open.

Note: If you added a Microsoft Excel report template to the job template, its location is displayed under **Customized Excel report template**.

- ▶ To replace the tests in the current job with the selected template, click **Replace existing testplan**.
- ▶ To add the selected template to the current job, click **Append to existing testplan**.

Note: If you click **Append to existing testplan**, the Microsoft Excel report template will not be added to the currently open job.

9.7.6 Handling results

Trending tab

The **Trending** tab displays measurement data from PF/DF/Tan δ tests performed at rated frequency at different points in time.

For the collection of data, the serial number and manufacturer are taken into account. Therefore, all measurements of the bushing in question are displayed, regardless of its location (for example spare bushing, bushing mounted on different transformers, etc.).

In the chart, measurements performed with 10 kV at rated frequency are displayed as circles ○. All other data are displayed as triangles ▽.

Note: If several tests are performed on one day, the most recent test of that day is connected to the curve in the **Trending** chart. The others are displayed in the same chart but are not connected.

Assessing measurement results

- Use the Assessment column in the Measurements area of a test to assess the measurement results or to change the automatic assessment provided by *Primary Test Manager*.

Table 9-17: Assessment statuses in the Test view

Status	Description
Fail	The status was automatically set to <i>Fail</i> by <i>Primary Test Manager</i> .
Manual fail	The status was manually set to <i>Fail</i> .
Investigate	The status was automatically set to <i>Investigate</i> by <i>Primary Test Manager</i> .
Manual investigate	The status was manually set to <i>Investigate</i> .
Pass	The status was automatically set to <i>Pass</i> by <i>Primary Test Manager</i> .
Manual pass	The status was manually set to <i>Pass</i> .
Not assessed	The measurement has not been assessed.
Not rated	The status was automatically set to <i>Not Rated</i> by <i>Primary Test Manager</i> .

Comparing results

Some tests support comparison of the graphical diagrams of measurement results. The comparison data is an integral part of the tests. You can compare tests for different assets but we recommend to perform only comparisons of tests for the same assets or assets of the same design type. *Primary Test Manager* offers you only tests of the same type for which the comparison is possible.

To compare a test with a test available in the database:

- 1. In the **Measurements** pane of a test, click the **+ Select comparison** button, if available.
- 2. In the **Select a test** window, select the test you want to compare with the current test.




Figure 9-38: Select a test window

- The Measurements pane displays the measurement results of the selected test.




Figure 9-39: Test comparison: Measurement results of the first test

- Start the test (see "Performing tests" on page 144).
- Click the **Plot** tab.

6. *Primary Test Manager* displays the measurement results of both tests in real time.




Figure 9-40: Test comparison: Measurement results of both tests

To remove the comparison diagram, click **Remove comparison**.

Alternatively, you can compare two tests available in the database:

1. In the Manage view (see 9.8 "Manage objects" on page 159), select the job including the first test for comparison.
2. In the left pane of the job overview, click the first test for comparison.
3. In the Measurements pane, click the **+ Select comparison** button, if available.
4. In the **Select a test** window, select the second test for comparison.
5. *Primary Test Manager* displays the measurement results of both tests.

9.7.7 Create new manual jobs

► To open the new manual job view, click the **New manual job** button  in the home view.




Figure 9-41: New manual job view

The workspace of the new manual job view depends on the selected button in the left pane (see Figure 9-42: "Left-pane buttons" on page 156). Initially, the workspace is divided into the **Available tests** area and the **Selected tests** areas.

On top of the **Available tests** area you can select the test system you want to use for measurement. *Primary Test Manager* displays all available manual tests supported for the selected test system.

Add tests to a job

- ▶ On the top of the **Available tests** area, click the button labeled with the test system with which you want to perform the test.
Primary Test Manager then displays all available manual tests supported for the selected test system.
- ▶ To add a test to a job, click the **Add** button **+** next to the test name or double-click the test in the **Available tests** area.

The tests added to a job are displayed in the **Selected tests** area.




Figure 9-42: Left-pane buttons

Note: You can change the default test names. To rename a test, click the corresponding button in the left pane, and then click the test name.

- ▶ To remove a test from the **Selected tests** area, click the **Remove** button **X** next to the test name in the left pane.
- ▶ To open a test, click the left-pane button with the test name.
- ▶ To add the currently open test to the job, click **Copy test** on the ribbon.

9.7.8 Open jobs

With *Primary Test Manager*, you can open existing guided and manual jobs. To open a job:

1. Click the **Open job** button  in the home view.
2. Browse to the job you want to open.

The open job view displays the tests in the left pane. To view the test results, click the corresponding test button. You can add new tests and generate test reports as described in 9.7.7 "Create new manual jobs" on page 155.

9.7.9 Test reports

In the report view, you can configure and generate test reports.

- ▶ To open the report view, click the **Report** button  in the left pane.




Figure 9-43: Report view

The report view is divided into the **New report** area, the **Settings** area and the **Existing reports** area. In the **New report** area, you can set the report data. The following table describes the report data.

Table 9-18: Report data

Data	Description
Title	Title of the report. Appears as the report header.
Report language	Language the report is created in
Client	Customer for which the report is designated
Summary	Text field to summarize the content of the test report in own words.

Setting the logo

To insert your own logo:

1. In the **New report** area, click **Select logo...**
 2. Browse to the file you want to insert.
- ▶ To set your own logo as default, click **Set as default**.

Configuring test reports

In the **Settings** area, you can configure test reports by selecting the respective check boxes. You can generate test reports as Microsoft Word documents or in PDF format.

- ▶ To generate a test report in your preferred format, click **Report to Word** or **Report as PDF**.

You can use customized Microsoft Excel templates provided by OMICRON to tailor test reports to your needs. For information about the test report templates, contact your OMICRON local sales representative or distributor.

To open a test report template:

1. In the **Settings** area, click the **Custom reports** tab.
 2. Click **Select template**.
 3. Browse to the template you want to use.
- ▶ To set the customized test report template as default, click **Set as default**.

The **Existing reports** area displays the test reports available for the job. In addition to the test reports generated by *Primary Test Manager*, you can add other reports to jobs. To add a report to a job:

1. In the **Existing reports** area, click **Add report from file**.
2. Browse to the report you want to add to the job.

9.8 Manage objects

In the manage view, you can manage locations, assets, jobs, and reports available in *Primary Test Manager*.

► To open the manage view, click the **Manage** button  in the home view.

Note: In this chapter, the locations, assets, jobs, and reports are collectively called objects.




Figure 9-44: Manage view

Note: The mounted assets are displayed in italics. To hide them, expand the Asset area, and then select the **Hide mounted assets** check box.

The manage view displays the objects in a hierarchical structure as follows:

- If you select a location, the manage view displays the assets, jobs, and reports associated with the selected location.
- If you select an asset, the manage view displays the jobs and reports associated with the selected asset.
- If you select a job, the manage view displays the reports associated with the selected job.

You can sort the objects alphabetically or in the chronological order.

► Drag and drop the column headers to rearrange the columns.

In the manage view, you can:

- Search for objects
- Perform operations on objects
- Relocate assets
- Import and export jobs

Search for objects

In the manage view, you can search for the objects available in *Primary Test Manager*:

- By searching for keywords in all object data
- By searching for keywords in particular object data
- ▶ To search for keywords in all object data, type the keyword you search for in the respective **Search** box.

To search for keywords in particular object data:

1. Expand the Location, Asset, Job and Report areas.
2. Type the keyword(s) you search for in the respective object data box(es).

The following table describes the asset search data.

Table 9-19: Asset search data

Data	Description
Asset kind	Asset under test
Asset type	Type of the asset
Serial no.	Serial number of the asset
Manufacturer	Manufacturer of the asset
Manufacturer type	Type of the asset according to the manufacturer
Asset system code	Code of the asset used by the maintenance planning systems
Apparatus ID	Identifier of the asset
Feeder	Feeder the asset is connected to

The following table describes the job search data.

Table 9-20: Job search data

Data	Description
Name	Name of the job or work order
Work order	Work order of the job
Tested by	Person who performed the test
Executed between	Time period between the job was executed
Status	Status of the job

The following table describes the report search data.

Table 9-21: Report search data

Data	Description
Name	Name of the report
Client	Customer for which the report is designated
Created between	Time period between the report was created

Perform operations on objects

To perform operations on objects, select an object from the respective list, and then do one of the following:

- ▶ Click the **Create new *object*** button  to add a new object of the same category.
- ▶ Click the **Open selected *object*** button  to display the data of the selected object.
- ▶ Click the **Delete selected *object*** button  to delete the selected object.

Additionally, you can copy jobs with the associated location, asset and test data. The test results and reports are not copied. To copy a job:

1. Select the job you want to copy.
2. Click the **Copy selected job** button .

To perform operations on multiple objects, click **Enable multiple selection** on the ribbon, and then do one of the following:

- ▶ To delete multiple locations, assets, jobs, and test reports, select the check boxes next to the objects you want to delete, and then click the **Delete selected *object*** button .
- ▶ To export multiple jobs, select the check boxes next to the jobs you want to export, and then click the **Export** button .

Master locations and assets

Primary Test Manager supports master locations and assets to help you keep your data consistent. When you create a job, the location and asset associated with that job – called master location and master asset, respectively – are copied to the job.

Consequently, whenever you try to change the location or the asset of an existing job, a notification bar at the top of the *Primary Test Manager* workspace prompts you to do one of the following:

- ▶ Click **Import from master location** or **Import from master asset** to import the location or asset originally associated with the job (master location/asset) to the current job.
- ▶ Click **Update master location** or **Update master asset** to update the location or asset originally associated with the job (master location/asset) with the data of the current job.

Duplicate assets

In the manage view, you can duplicate assets available in *Primary Test Manager*. To duplicate an asset:

1. From the asset list, select the asset you want to duplicate.
2. Click the **Duplicate selected asset** button .
3. In the asset view, type the serial number of the new asset.




Figure 9-45: Asset view

4. Click **Save asset** on the ribbon.

Note: By default, the duplicated assets are linked to location of the original asset. For relocating the asset to a different location, see "Relocate assets" later in this chapter.

Relocate assets

In the manage view, you can relocate assets available in *Primary Test Manager*. To relocate an asset:

1. From the asset list, select the asset you want to relocate.
2. Click the **Relocate selected asset** button .




Figure 9-46: **Relocate Asset** dialog box

3. In the **Relocate Asset** dialog box, select the location you want to move the asset to.
4. If the asset you want to relocate is mountable, select an asset where the moved asset is to be mounted.

Note: You can filter the locations and assets by searching for keywords (see "Search for objects" on page 160).

Import and export jobs

Primary Test Manager supports data exchange between different test systems.

You can export jobs in the *Primary Test Manager* native PTM format and as Microsoft Excel documents.

To export a job:

1. From the job list, select the job you want to export.
2. Click the **Export** button .
3. Browse to the folder where you want to save the job.

You can import *Primary Test Manager* jobs in PTM format, test data in CSV format, and XML and SFRA Doble files.

Note: During the import, the Doble XML data is mapped to the *Primary Test Manager* jobs.

To import a job:

1. In the **Job** area, click the **Import** button , and then click **Import from file**.
2. Browse to the file you want to import.

10 Testing with Primary Test Manager

10.1 Getting started

The following table lists the basic steps necessary to complete a measurement using *TESTRANO 600* and the *Primary Test Manager* guided workflow.

► For more information refer to the user manual chapters listed on the right.

Step	User manual chapter
 1. SAFETY	Safety instructions Hardware overview Safety and warning indicators Emergency Stop button Application
 2. Connection to TESTRANO 600	Preparing the test setup
 3. Start device and software	TESTRANO 600 side panel Software start and device update
 4. Location and asset	Location view Asset view
 5. Jobs	Jobs
 6. Tests	Test view PTM Transformer tests PTM Bushing tests Device-independent PTM tests
 7. Connection to device under test	Safety instructions TESTRANO 600 measuring cables Application Connecting to the transformer
 8. Test settings	Performing tests
 9. Test assessment	Assessing measurement results
 10. Measurement	Measurement

10.2 Measurement

- ▶ Refer to chapter 1 "Safety instructions" on page 8 for detailed information about safe testing.
- ▶ If in doubt, contact OMICRON support (see "Support" on page 276).

DANGER

Death or severe injury caused by high voltage or current

- ▶ Do not unplug any cables while the measurement is running.
- ▶ Only remove cables when **all** of the following apply to *TESTRANO 600*:
 - The red warning light on the front panel is **off**.
 - The warning lights on the side panel are **off**.
 - The green light on the front panel is **on**.

If all lights on *TESTRANO 600* are off, the device is defective or not supplied by mains.

WARNING

Death or severe injury caused by high voltage or current possible

- ▶ Do not enter the high-voltage area during the test.
- ▶ Do not touch any part of the transformer before grounding and short-circuiting its terminals.

 Start

1. Press **Start** in *Primary Test Manager*.
2. The blue ring on the **Start/Stop** button lights up.
3. Press the **Start/Stop** button to start the test.
4. The blue ring and the red warning light are now flashing for approx. 3 seconds.
 - ▶ To suspend the test, press the **Start/Stop** button on the *TESTRANO 600* front panel.
 - ▶ In an emergency, press the **Emergency Stop** button to stop the test.
5. After the measurement is completed or stopped, the green warning light switches on and *Primary Test Manager* displays the results in the **Measurements** view.

11 PTM Asset data

This section describes the data in the **Asset** view when you create a new or edit an existing asset from the **Manage** view.

11.1 Transformer data

The following tables describe the transformer data.

Table 11-1: Winding configuration

Data	Description
Phases	Number of transformer phases
Vector group	Vector group of the transformer (see " Setting the vector group of a transformer " on page 136)
Unsupported vector group (for documentation)	Vector group not supported by <i>Primary Test Manager</i> as text for documentation

Table 11-2: Ratings

Data	Description
Rated frequency	Rated frequency of the transformer
Voltage ratings	
Winding	Transformer's winding
Voltage L-L	L-L voltage of the transformer's winding
Voltage L-L	L-L voltage of the transformer's winding
Voltage L-N	L-N voltage of the transformer's winding
Insul. level L-L (BIL)	L-L basic impulse level rating of the transformer's winding
Power ratings	
Rated power	Power rating of the transformer
Cooling class	Cooling class of the transformer
Temp. rise wind.	Temperature rise of the transformer's winding
Current ratings at rated power	
H/X/Y ¹	Maximum power frequency current of the transformer at rated power
Short-circuit rating	
Max. short-circuit current	Maximum short-circuit current of the transformer in kA during a given time in seconds

1. Term depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112).

Table 11-3: Impedances

Data	Description
Ref. temp.	Reference temperature
Leakage reactance H - X, H - Y, X - Y¹	
Leakage reactance Z (%) ²	Leakage reactance of the transformer
Base power	Base power used for calculating the percent values of impedances
Base voltage	Base voltage used for calculating the percent values of impedances
Load losses Pk	Load loss at the transformer's rated load
OLTC position	Tap position of the OLTC
DETC position	Tap position of the DETC
Zero sequence impedance	
Base power	Base power used for calculating the percent values of impedances
Base voltage	Base voltage used for calculating the percent values of impedances
Winding	Transformer's winding
Zero sequence impedance Z0 (%)	Zero sequence impedance of the transformer

1. Term depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112) and the available winding combinations depend on the transformer type.
2. Term depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112).

Table 11-4: Others

Data	Description	
Category	Application category of the transformer	
Status	Usage status of the transformer	
Tank type	Type of transformer tank	
Insulation medium	Insulation medium of the transformer	
Insulation	Weight	Weight of transformer insulation
	Volume	Volume of transformer insulation
Total weight	Total weight of the transformer	
Winding	Conductor material	
Conductor material	Conductor material of the transformer's winding	

11.1.1 Bushing data

For the data of the transformer's bushings, see 11.2 "Spare bushing data" on page 170.

11.1.2 Tap changer data

The following table describes the on-load tap changer (OLTC) and the de-energized tap changer (DETC) data.

Table 11-5: Tap changer data

Data	Description
OLTC/DETC	Select the OLTC check box to set the OLTC data. Select the DETC check box to set the DETC data.
Tap changer configuration	
Winding	Transformer's winding to which the tap changer is connected
Tap scheme	Notation scheme for tap identification
No. of taps	Number of the tap changer's taps
Current tap position ¹	Current position of the tap
Voltage table	
Tap	Number of the tap
Voltage	Voltage on the tap

1. Only available for the DETC

11.1.3 Surge arrester

The following table describes the surge arrester data.

Table 11-6: Surge arrester data

Data	Description
Ratings	
Units in stack	Number of the surge arrester's units
Numerical positions	Select the Numerical positions check box to set numerical positions of the surge arrester.
Literal positions	Select the Literal positions check box to set alphabetical positions of the surge arrester.
Position	Position of the surge arrester
Serial no.	Serial number of the surge arrester
Voltage L-L Voltage L-N	Values needed to calculate the maximum test voltages
MCOV rating	Maximum continuous operating voltage between the terminals of the surge arrester
Unit catalog no.	Identifier of the surge arrester unit

11.2 Spare bushing data

The following table describes the spare bushing data.

Table 11-7: Spare bushing data

Data	Description
Pos. ¹	Terminal of the transformer's winding to which the spare bushing is connected
Ratings	
Rated frequency	Rated frequency of the spare bushing
Insul. level LL (BIL)	L-L basic impulse level rating of the spare bushing
Voltage L-ground	Rated line-to-ground voltage
Max. system voltage	Maximum voltage between phases during normal service
Rated current	Rating current of the spare bushing
Manufacturer info	
Catalog no.	Catalog number of the spare bushing
Drawing no.	Drawing number of the spare bushing
Style no.	Style number of the spare bushing
Nominal values	
PF (C1) ²	Power factor of the capacitance C1 between the top of the spare bushing and the voltage/test tap
Cap. (C1)	Capacitance C1 between the top of the spare bushing and the voltage/test tap
PF (C2) ²	Power factor of the capacitance C2 between the voltage/test tap of the spare bushing and ground
Cap. (C2)	Capacitance C2 between the voltage/test tap of the spare bushing and ground
Other	
Insulation type	Insulation type of the spare bushing
Outer insulation type	Outer insulation type of the spare bushing

1. Only available for spare bushings mounted on another assets

2. Term depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112).

12 PTM Transformer tests

This chapter lists the *Primary Test Manager* transformer tests available for *TESTRANO 600*.

- ▶ For details on safely performing tests, refer to chapters 1 "Safety instructions" on page 8 and 5 "Application" on page 27.

Note: Some test names depend on the **Profile** selected in the **Settings** (see "Profiles" on page 112). For your convenience, you can use your preferred naming to, for example, match regional conventions:

- IEEE standard: **Power factor (PF)** for the loss indicator; **H/X/Y** for the windings
- IEC standard: **Dissipation factor (DF)** for the loss indicators; **Prim/Sec/Tert** for the windings
- Custom profiles: **Power factor (PF)**, **Dissipation factor (DF)** or **Tangent delta (Tan δ)** for the loss indicator; various naming options for the windings

The dissipation factor and the tangent delta are identical characteristics of the primary asset under test.

Primary Test Manager supports the following tests of transformer tests:

Guided transformer tests	Page
12.1 Overall PF & Cap test ¹	173
12.2 Bushing PF & CAP – C1 test ¹	178
12.3 Bushing PF & CAP – C2 test ¹	183
12.4 Bushing – Energized Collar test ¹	187
12.5 Exciting Current test	189
12.6 Insulating Fluids PF & CAP test ¹	191
12.7 Surge Arrester Watt Losses test ¹	193
12.8 HV TTR test ¹	195
12.9 Leakage Reactance test ¹	198
12.10 TTR test ¹	201
12.11 DC Winding Resistance test ¹	204
12.12 Dynamic OLTC-Scan (DRM) test ¹	208
12.13 Demagnetization test	211
12.14 Vector Group Check test ¹	213

1. Test name depends on the **Profile** selected in **Settings** (see "Profiles" on page 112)

Manual transformer tests	Page
12.15 Manual Demagnetization test	214
12.16 Manual Power losses at low voltage test	216
12.17 Manual TTR test ¹	217
12.18 Manual Exciting Current test	221
12.19 Manual HV TTR test ¹	223
12.20 Manual DC Winding Resistance test	226
12.21 Manual Dynamic OLTC-Scan (DRM)	230
12.22 Manual Leakage Reactance test ¹	232
12.23 Manual Tan Delta test	235
12.24 Manual Vector Group Check	238
12.25 Quick test	239
12.26 Manual Cooldown test	241

1. Test name depends on the **Profile** selected in **Settings** (see "Profiles" on page 112).

Note: The chapters list the available options and settings for the tests. Depending on the individual asset and the general *Primary Test Manager* settings, not every test displays all listed items.

- For information on how to group tests and execute them in sequence, refer to "Grouping tests" on page 142.

12.1 Overall PF & Cap test

Note: This test name depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112):

- IEEE standard: **Overall PF & CAP**
- IEC standard: **Winding DF & CAP**
- Custom Profile: for example **Overall Tan δ & CAP** or **Winding Tan δ & CAP**

In this section, the terms **Power factor (PF)** and **Overall PF & CAP** will be used.

Power factor and capacitance measurements are performed to investigate the condition of the insulation of power transformers and bushings. Both insulation systems are essential for the reliable operation of the transformer.

The following table describes the Overall PF & CAP test settings.

Table 12-1: Overall PF & CAP test settings

Setting	Description
Measurement settings	
Test frequency	▶ Set the output frequency for the test.
Sweep settings	
Frequency sweep	Sweep profile: None, OMICRON expertise (recommended), or CPC template <ul style="list-style-type: none"> • None: no frequency sweep • OMICRON expertise: sweep frequencies dynamically distributed within the <i>TESTRANO 600</i> frequency range for optimum results • CPC template: sweep frequencies specified by the <i>CPC 100</i> test templates
Voltage sweep (tip-up)	Sweep profile: None or OMICRON expertise <ul style="list-style-type: none"> • None: no voltage sweep • OMICRON expertise: sweep voltages dynamically distributed within the asset-dependent voltage range for optimum results
 Sweep profiles	▶ Click the pen button  to create a frequency or voltage sweep profile. ▶ Add up to 30 measurement points with individual output voltages or frequencies. Double-click a value to change it. ▶ Mark a favorite  to use it as the default sweep profile for future tests. Note: The predefined profiles None , OMICRON expertise and CPC template cannot be edited or deleted. The default sweep profiles for this test are: <ul style="list-style-type: none"> • Frequency sweep: OMICRON expertise • Voltage sweep: None

Table 12-1: Overall PF & CAP test settings (continued)

Setting	Description
Noise suppression settings	
Averaging (no. points)	Number of averaged measurements
Bandwidth	CP TD filter bandwidth
Avoid test frequency	<p>If this setting is active, the measurement will <i>not</i> be performed at the Test frequency set in the Measurement section. <i>Primary Test Manager</i> will instead measure two values at frequencies below and above the entered Test frequency and calculate the median of those two values.</p> <p>The Avoid test frequency setting is predefined for the selected test.</p> <p>▶ Only change the default setting for special applications.</p>
Device settings	
Tan Delta device	▶ Select the CP TD you are using
Enable shield check	▶ Select the check box if you want that the TESTRANO 600 checks whether the shield of the high-voltage cable is connected.
Use beeper	▶ Select the check box if you want to use the CP TD's beeper during the measurement.
Test conditions	
Custom test conditions	▶ Select the Custom test conditions check box to set test conditions differing from the global test conditions.
Top oil temperature	Oil temperature at the top of the transformer's tank
Bottom oil temperature	Oil temperature at the bottom of the transformer's tank
Average oil temperature	Calculated average oil temperature of the transformer's tank
Winding temperature	Temperature of the transformer's winding
Ambient temperature	Ambient temperature on site
Humidity	Relative ambient humidity
Weather	Weather during the test
Correction factors	
Temperature correction	▶ Select the check box to activate temperature correction.
Correction temp.	▶ In the Custom list, click the correction temperature, or type the correction temperature beneath.

Table 12-1: Overall PF & CAP test settings (continued)

Setting	Description
Correction factor	▶ Click the Calculate button to calculate the correction factor automatically or type the correction factor beneath.
Use reference voltage	▶ Select the check box to extrapolate the I out and Watt losses results for the specified reference voltage.
Reference voltage	Reference voltage for extrapolation of measurement results
Bushings compensation	▶ Select the check box to activate bushings compensation. Note: Bushing compensation compensates the effect of the capacitance C1 of the transformer's bushings on the measurement results of the test.

NOTICE**Equipment damage or loss of data possible**

Before making a decision based on the *Primary Test Manager* automatic assessment, read the disclaimer "Automatic assessment" on page 11.

Primary Test Manager supports automatic assessment for the following insulation media if you activate the temperature correction by selecting the **Temperature correction** check box:

- Natural ester
- Mineral oil
- Silicone

The following table describes the automatic assessment parameters of the Overall PF & CAP test.

Table 12-2: Overall PF & CAP automatic assessment parameters

Parameter	Description
Limit schema	Limit schema underlying the assessment
Global assessment criteria	
Min. Iout @10 kV	Threshold value of the automatic assessment. If Iout < Min. Iout @10 kV, the automatic assessment status is Investigate .

To save the selected limit schema as the default setting for all future jobs, click **Set as default**.

Under **Visible limits**:

- ▶ Click **only limits that are used for this measurement** to display only limits for the selected transformer's insulation type.
- ▶ Click **all limits** to display limits for all supported transformer's insulation types.

The following tables describe the automatic assessment limits of the Overall PF & CAP test.

Table 12-3: Overall PF & CAP automatic assessment limits based on Power factor¹

Assessment against	Limit	Power factor ¹
Absolute limits for measurements	Low limit (fail) ² Low limit (warn.) ² High limit (warn.)@<230 kV ^{2,3} High limit (warn.)@>=230 kV ^{2,3} High limit (fail) ²	Limits for the measured power factor

1. Term depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112).
2. Set to the absolute limits.
3. According to the IEEE guidelines for oil isolated transformers the warning limit depends on the rated voltage (LL) of the primary winding. If the rated voltage (LL) of the primary winding is less than 230 kV the first limit value is used for the high limit (warn.) otherwise the second one is used. For an automatic assessment based on the IEEE guidelines for another insulation or based on the IEC standards the same values for high limit (warn.)@<230 kV and high limit (warn.)@>=230 kV are set.

If you selected the **Use reference voltage** check box *Primary Test Manager* performs additionally a cross check by using the following additional limits.

Table 12-4: Overall PF & CAP cross check limits based on Power Factor¹

Assessment against	Limit	Power factor ¹
Absolute limits for cross check	Multiplier (high warn. limit) ^{2,3} Multiplier (high fail limit) ^{2,3} / Divider (low fail limit) ^{2,3}	Limits for the measured power factor

1. Term depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112).
2. The high warn., high fail and low fail limits are calculated from the cross check corrected values by using the respective multiplier and divider and then compared to the corrected measured values.
3. The cross check assessment of the power factor if the reference correction voltage is set to 10 kV. Otherwise the cross assessment is based only on the capacitance.

Table 12-5: Overall PF & CAP cross check limits based on capacitance

Assessment against	Limit	Capacitance
Relative limits for cross check	Low limit (warn)/ High limit (warn) Low limit (fail)/ High limit (fail)	Limits for the measured capacitance

You can assess the test:

- During measurement
To assess the test while the measurements are running, select the **Assess during measurements** check box.
- Manually after all measurements have been finished
To assess the test manually, click **Assess measurements**.

After a measurement has been assessed, the test settings and the assessment parameters are locked.

If you change nameplate data relevant for the assessment (i.e. insulation type, PF or CAP) after a measurement has been assessed and you reopen the test, the following message appears:

 **Update Required** The assessment for this test is performed on a different basis. Asset data are changed.

To update the assessment, click **Update and re-assess**.

To change the test data, the test settings or the assessment parameters, click **Clear all assessments**.

You can overwrite the *Primary Test Manager* automatic assessment manually. To do so, click the arrow next to the automatic assessment, and then select a manual assessment from the list.

Note: The automatic assessment is stored in the **Assessment** box for documentation purposes.

The following table describes the Overall PF & CAP measurement data.

Table 12-6: Overall PF & CAP measurement data

Data	Description
No.	Number of the measurement
Measurement	Arrangement of the measurement
Test mode	Test mode according to the IEEE Std 62-1995
Sweep	Swept variable: frequency, voltage, or none
V test	Test voltage
Freq.	Test frequency
V out	Measured output voltage
I out	Measured output current
Watt losses	Measured losses
PF meas ¹	Measured power factor
PF corr ¹	Corrected measured power factor
Cap. meas	Measured capacitance
Assessment	Measurement assessment

1. Term depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112).

12.2 Bushing PF & CAP – C1 test

Note: This test name depends on the winding used for performing the test, and on the **Profile** selected in the **Settings** (see "Profiles" on page 112):

- IEEE standard: **Bushing H/X/Y PF & CAP – C1**
- IEC standard: **Bushing Prim/Sec/Tert DF & CAP – C1**
- Custom Profile: for example **Bushing H/X/Y Tan δ & CAP – C1** or **Bushing Prim/Sec/Tert Tan δ & CAP – C1**

In this section, the terms **Power factor (PF)** and **Bushing PF & CAP – C1** will be used.

Power factor and capacitance measurements are performed to investigate the condition of the insulation of power transformers and bushings. Both insulation systems are essential for the reliable operation of the transformer.

The following table describes the Bushing PF & CAP – C1 test settings.

Table 12-7: Bushing PF & CAP – C1 test settings

Setting	Description
Measurement settings	
Test frequency	► Set the output frequency for the test.
Sweep settings	
Frequency sweep	Sweep profile: None, OMICRON expertise (recommended), or CPC template <ul style="list-style-type: none"> • None: no frequency sweep • OMICRON expertise: sweep frequencies dynamically distributed within the <i>TESTRANO 600</i> frequency range for optimum results • CPC template: sweep frequencies specified by the <i>CPC 100</i> test templates
Voltage sweep (tip-up)	Sweep profile: None or OMICRON expertise <ul style="list-style-type: none"> • None: no voltage sweep • OMICRON expertise: sweep voltages dynamically distributed within the asset-dependent voltage range for optimum results

Table 12-7: Bushing PF & CAP – C1 test settings (continued)

Setting	Description
 Sweep profiles	<ul style="list-style-type: none"> ▶ Click the pen button  to create a frequency or voltage sweep profile. ▶ Add up to 30 measurement points with individual output voltages or frequencies. Double-click a value to change it. ▶ Mark a favorite  to use it as the default sweep profile for future tests. <p>Note: The predefined profiles None, OMICRON expertise and CPC template cannot be edited or deleted.</p> <p>The default sweep profiles for this test are:</p> <ul style="list-style-type: none"> • Frequency sweep: OMICRON expertise • Voltage sweep: OMICRON expertise
Noise suppression settings	
Averaging (no. points)	Number of averaged measurements
Bandwidth	CP TD filter bandwidth
Avoid test frequency	<p>If this setting is active, the measurement will <i>not</i> be performed at the Test frequency set in the Measurement section. <i>Primary Test Manager</i> will instead measure two values at frequencies below and above the entered Test frequency and calculate the median of those two values.</p> <p>The Avoid test frequency setting is predefined for the selected test.</p> <ul style="list-style-type: none"> ▶ Only change the default setting for special applications.
Device settings	
Tan Delta device	▶ Select the CP TD you are using.
Enable shield check	▶ Select the check box if you want that the <i>TESTRANO 600</i> checks whether the shield of the high-voltage cable is connected.
Use beeper	▶ Select the check box if you want to use the CP TD's beeper during the measurement.
Test conditions	
Custom test conditions	▶ Select the check box to set test conditions differing from the global test conditions.
Top oil temperature	Oil temperature at the top of the transformer's tank
Ambient temperature	Ambient temperature on site
Humidity	Relative ambient humidity
Weather	Weather during the test

Table 12-7: Bushing PF & CAP – C1 test settings (continued)

Setting	Description
Correction factors	
Temperature correction	► Select the check box to activate temperature correction.
Correction factor	Temperature correction factor
Use reference voltage	► Select the check box to extrapolate the I out and Watt losses results for the specified reference voltage.
Reference voltage	Reference voltage for extrapolation of the measurement results

NOTICE

Equipment damage or loss of data possible

Before making a decision based on the *Primary Test Manager* automatic assessment, read the disclaimer "Automatic assessment" on page 11.

Primary Test Manager supports automatic assessment for the following bushing's insulation types:

- Oil-impregnated paper
- Resin-bonded paper
- Resin-impregnated paper

For another type of the bushing's insulation the automatic assessment cannot be done.

Note: The assessment can be done only if all bushings have the same insulation type.

The following table describes the automatic assessment parameters of the Bushing PF & CAP – C1 test.

Table 12-8: Bushing PF & CAP – C1 automatic assessment parameters

Parameter	Description
Limit schema	Limit schema underlying the assessment
Global assessment criteria	
Min. Iout @10 kV	Threshold value of the automatic assessment. If Iout < Min. Iout @10 kV, the automatic assessment status is Investigate .

To save the selected limit schema as the default setting for all future jobs, click **Set as default**.

Under **Visible limits**:

- Click **only limits that are used for this measurement** to display only limits for the selected bushing's insulation type and the PF (C1)¹ nameplate values (if entered) or the absolute limits.
- Click **all limits** to display limits for all supported bushing insulation types and the PF (C1)¹ nameplate values (if entered) or the absolute limits.

1. Term depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112).

The following tables describe the automatic assessment limits of the Bushing PF & CAP – C1 test.

Table 12-9: Bushing PF & CAP – C1 automatic assessment limits based on Power Factor¹

Assessment against	Limit	Power factor ¹
Nameplate values	Multiplier (high fail limit) ² / Divider (low warn. limit) ² Multiplier (high warn. limit) ²	Limits based on the PF (C1) nominal values
Absolute limits	Low limit (fail) ³ Low limit (warn.) ³ High limit (warn.) ³ High limit (fail) ³	Limits based on the PF (C1) absolute limits

1. Term depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112).
2. The high fail, high warn. and low warn. limits are calculated from the nominal values by using the respective multiplier and divider, and then compared to the corrected measured values. The low fail limit is set to 0.
3. Set to the absolute limits.

Table 12-10: Bushing PF & CAP – C1 automatic assessment limits based on capacitance

Assessment against	Limit	Capacitance
Nameplate values	Low limit (fail) ¹ / High limit (fail) ¹ Low limit (warn) ¹ / High limit (warn) ¹	Limits based on the Cap. (C1) nominal value

1. Set to the absolute limits.

The following table shows the *Primary Test Manager* assessment logic.

Table 12-11: Assessment logic

PF (C1) ¹ nominal value	Cap. (C1) nominal value	Assessment
Available	Available	Overall assessment
Available	Not available	Assessment based only on PF (C1) ¹ nominal values
Not available	Available	Overall assessment
Not available	Not available	Assessment based only on PF (C1) ¹ absolute limits


1. Term depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112).

You can assess the test:

- During measurement
To assess the test while the measurements are running, select the **Assess during measurements** check box.
- Manually after all measurements have been finished
To assess the test manually, click **Assess measurements**.

After a measurement has been assessed, the test settings and the assessment parameters are locked.

If you change nameplate data relevant for the assessment (i.e. insulation type, PF or CAP) after a measurement has been assessed and you reopen the test, the following message appears:



To update the assessment, click **Update and re-assess**.

To change the test data, the test settings or the assessment parameters, click **Clear all assessments**.

You can overwrite the *Primary Test Manager* automatic assessment manually. To do so, click the arrow next to the automatic assessment, and then select a manual assessment from the list.

Note: The automatic assessment is stored in the **Assessment** box for documentation purposes.

The following table describes the Bushing PF & CAP – C1 measurement data.

Table 12-12: Bushing PF & CAP – C1 measurement data

Data	Description
No.	Number of the measurement
Measurement	Terminal name of the bushing under test
Test mode	Test mode according to the IEEE Std 62-1995
Sweep	Swept variable: frequency, voltage, or none
V test	Test voltage
Freq.	Test frequency
V out	Measured output voltage
I out	Measured output current
Watt losses	Measured losses
PF meas ¹	Measured power factor
PF corr ¹	Corrected measured power factor
PF ref ¹	Reference power factor
Cap. meas	Measured capacitance
Cap. ref	Reference capacitance
Assessment	Measurement assessment

1. Term depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112).

12.3 Bushing PF & CAP – C2 test

Note: This test name depends on the winding used for performing the test, and on the **Profile** selected in the **Settings** (see "Profiles" on page 112):

- IEEE standard: **Bushing H/X/Y PF & CAP – C2**
- IEC standard: **Bushing Prim/Sec/Tert DF & CAP – C2**
- Custom Profile: for example **Bushing H/X/Y Tan δ & CAP – C2** or **Bushing Prim/Sec/Tert Tan δ & CAP – C2**

In this section, the terms **Power factor (PF)** and **Bushing & CAP – C2** will be used.

Power factor and capacitance measurements are performed to investigate the condition of the insulation of power transformers and bushings. Both insulation systems are essential for the reliable operation of the transformer.

The following table describes the Bushing PF & CAP – C2 test settings.

Table 12-13: Bushing PF & CAP – C2 test settings

Setting	Description
Measurement settings	
Test frequency	► Set the output frequency for the test.
Noise suppression settings	
Averaging (no. points)	Number of averaged measurements
Bandwidth	CP TD filter bandwidth
Avoid test frequency	<p>If this setting is active, the measurement will <i>not</i> be performed at the Test frequency set in the Measurement section. <i>Primary Test Manager</i> will instead measure two values at frequencies below and above the entered Test frequency and calculate the median of those two values.</p> <p>The Avoid test frequency setting is predefined for the selected test.</p> <p>► Only change the default setting for special applications.</p>
Device settings	
Tan Delta device	► Select the CP TD you are using.
Enable shield check	► Select the check box if you want that the <i>TESTRANO 600</i> checks whether the shield of the high-voltage cable is connected.
Use beeper	► Select the check box if you want to use the CP TD's beeper during the measurement.
Test conditions	
Custom test conditions	► Select the check box to set test conditions differing from the global test conditions.
Top oil temperature	Oil temperature at the top of the transformer's tank
Ambient temperature	Ambient temperature on site
Humidity	Relative ambient humidity

Table 12-13: Bushing PF & CAP – C2 test settings (continued)

Setting	Description
Weather	Weather during the test
Correction factors	
Temperature correction	► Select the check box to activate temperature correction.
Correction factor	Temperature correction factor
Use reference voltage	► Select the check box to extrapolate the I out and Watt losses results for the specified reference voltage.
Reference voltage	Reference voltage for extrapolation of measurement results

NOTICE

Equipment damage or loss of data possible

Before making a decision based on the *Primary Test Manager* automatic assessment, read the disclaimer "Automatic assessment" on page 11.

Primary Test Manager supports automatic assessment for the following bushing's insulation types:

- Oil-impregnated paper
- Resin-bonded paper
- Resin-impregnated paper

For another type of the bushing's insulation the automatic assessment cannot be done.

Note: The assessment can be done only if all bushings have the same insulation type.

The following table describes the automatic assessment parameters of the Bushing PF & CAP – C2 test.

Table 12-14: Bushing PF & CAP – C2 automatic assessment parameters

Parameter	Description
Limit schema	Limit schema underlying the assessment
Global assessment criteria	
Min. Iout @10 kV	Threshold value of the automatic assessment. If Iout < Min. Iout @10 kV, the automatic assessment status is Investigate .

To save the selected limit schema as the default setting for all future jobs, click **Set as default**.

Under **Visible limits**:

- Click **only limits that are used for this measurement** to display only limits for the selected bushing's insulation type and the PF (C2)¹ nameplate values (if entered) or the absolute limits.
- Click **all limits** to display limits for all supported bushing insulation types and the PF (C2)¹ nameplate values (if entered) or the absolute limits.

1. Term depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112).

The following tables describe the automatic assessment limits of the Bushing PF & CAP – C2 test.

Table 12-15: Bushing PF & CAP – C2 automatic assessment limits based on Power Factor¹

Assessment against	Limit	Power factor ¹
Nameplate values	Multiplier (high fail limit) ² / Divider (low warn. limit) ² Multiplier (high warn. limit) ²	Limits based on the PF (C2) nominal values
Absolute limits	Low limit (fail) ³ Low limit (warn.) ³ High limit (warn.) ³ High limit (fail) ³	Limits based on the PF (C2) absolute limits

1. Term depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112).
2. The high fail, high warn. and low warn. limits are calculated from the nominal values by using the respective multiplier and divider, and then compared to the corrected measured values. The low fail limit is set to 0.
3. Set to the absolute limits.

Table 12-16: Bushing PF & CAP – C2 automatic assessment limits based on capacitance

Assessment against	Limit	Capacitance
Nameplate values	Low limit (fail) ¹ / High limit (fail) ¹ Low limit (warn.) ¹ / High limit (warn.) ¹	Limits based on the Cap. (C2) nominal value

1. Set to the absolute limits.

The following table shows the *Primary Test Manager* assessment logic.

Table 12-17: Assessment logic

PF (C2) ¹ nominal value	Cap. (C2) nominal value	Assessment
Available	Available	Overall assessment
Available	Not available	Assessment based only on PF (C2) ¹ nominal values
Not available	Available	Overall assessment
Not available	Not available	Assessment based only on PF (C2) ¹ absolute limits

1. Term depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112).

You can assess the test:

- During measurement
To assess the test while the measurements are running, select the **Assess during measurements** check box.
- Manually after all measurements have been finished
To assess the test manually, click **Assess measurements**.

After a measurement has been assessed, the test settings and the assessment parameters are locked.

If you change nameplate data relevant for the assessment (i.e. insulation type, PF or CAP) after a measurement has been assessed and you reopen the test, the following message appears:



To update the assessment, click **Update and re-assess**.

To change the test data, the test settings or the assessment parameters, click **Clear all assessments**.

You can overwrite the *Primary Test Manager* automatic assessment manually. To do so, click the arrow next to the automatic assessment, and then select a manual assessment from the list.

Note: The automatic assessment is stored in the **Assessment** box for documentation purposes.

The following table describes the Bushing PF & CAP – C2 measurement data.

Table 12-18: Bushing PF & CAP – C2 measurement data

Data	Description
No.	Number of the measurement
Measurement	Terminal name of the bushing under test
Test mode	Test mode according to the IEEE Std 62-1995
V test	Test voltage
Freq.	Test frequency
V out	Measured output voltage
I out	Measured output current
Watt losses	Measured losses
PF meas ¹	Measured power factor
PF corr ¹	Temperature corrected power factor
PF ref ¹	Reference power factor
Cap. meas	Measured capacitance
Cap. ref	Reference capacitance
Assessment	Measurement assessment

1. Term depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112).

12.4 Bushing – Energized Collar test

Note: This test name depends on the winding used for performing the test, and on the **Profile** selected in the **Settings** (see "Profiles" on page 112):

- IEEE standard: **Bushing H/X/Y – Energized Collar**
- IEC standard: **Bushing Prim/Sec/Tert – Energized Collar**

In this section, the term **Bushing – Energized Collar** will be used.

Power factor and capacitance measurements are performed to investigate the condition of the insulation of power transformers and bushings. Both insulation systems are essential for the reliable operation of the transformer.

The following table describes the Bushing – Energized Collar test settings.

Table 12-19: Bushing – Energized Collar test settings

Setting	Description
Measurement settings	
Test frequency	▶ Set the output frequency for the test.
Noise suppression settings	
Averaging (no. points)	Number of averaged measurements
Bandwidth	CP TD filter bandwidth
Avoid test frequency	<p>If this setting is active, the measurement will <i>not</i> be performed at the Test frequency set in the Measurement section. <i>Primary Test Manager</i> will instead measure two values at frequencies below and above the entered Test frequency and calculate the median of those two values.</p> <p>The Avoid test frequency setting is predefined for the selected test.</p> <p>▶ Only change the default setting for special applications.</p>
Device settings	
Tan Delta device	▶ Select the CP TD you are using.
Enable shield check	▶ Select the check box if you want that the <i>TESTRANO 600</i> checks whether the shield of the high-voltage cable is connected.
Use beeper	▶ Select the check box if you want to use the CP TD's beeper during the measurement.
Test conditions	
Custom test conditions	▶ Select the check box to set test conditions differing from the global test conditions.
Top oil temperature	Oil temperature at the top of the transformer's tank
Ambient temperature	Ambient temperature on site
Humidity	Relative ambient humidity

Table 12-19: Bushing – Energized Collar test settings (continued)

Setting	Description
Weather	Weather during the test
Correction factors	
Use reference voltage	► Select the check box to extrapolate the I out and Watt losses results for the specified reference voltage.
Reference voltage	Reference voltage for extrapolation of measurement results

The following table describes the Bushing – Energized Collar measurement data.

Table 12-20: Bushing – Energized Collar measurement data

Data	Description
No.	Number of the measurement
Measurement	Terminal name of the bushing under test
Test mode	Test mode according to the IEEE Std 62-1995
V test	Test voltage
Freq.	Test frequency
V out	Measured output voltage
I out	Measured output current
Watt losses	Measured losses
Assessment	Measurement assessment

12.5 Exciting Current test

Exciting current measurements are performed to assess the turn-to-turn insulation of the windings, the magnetic circuit of a transformer as well as the tap changer. The most valued benefit of the test is to detect turn-to-turn short-circuits in a winding. Physical movement of the core laminations or severe damage to the core can influence the reluctance and, thus, will result in a change in exciting current. Deviations may also indicate contact wear or improper wiring of the tap changer.




Figure 12-1: Exciting Current test

Table 12-21: Exciting Current test – Settings and conditions

Option	Description
Measurement settings	
Test voltage	Output voltage
Test mode	Test mode for this test: UST-A
Noise suppression	
Averaging	Number of averaged measurements
Bandwidth	CP TD filter bandwidth

Table 12-21: Exciting Current test – Settings and conditions (continued)

Option	Description
Avoid test frequency	<p>If this setting is active, the measurement will <i>not</i> be performed at the Test frequency set in the Measurement section. <i>Primary Test Manager</i> will instead measure two values at frequencies below and above the entered Test frequency and calculate the median of those two values.</p> <p>The Avoid test frequency setting is predefined for the selected test.</p> <p>▶ Only change the default setting for special applications.</p>
Tap changer settings	
Tap changer under test	▶ Select which tap changer to include in the measurement if both an OLTC and a DETC have been defined.
Tap control settings	
Automatic tap control	▶ Activate the check box to use automatic tap control during the test.
Tap time	Time for the change between two tap positions
Impulse time	Duration of the impulse triggering the tap change
Start tap	Start tap position of the test
Stop tap	Stop tap position of the test

Table 12-22: Exciting Current test – Measurements

Option	Description
Tap	Tap under test
Phase	Phase under test
V out	Output voltage
I out	Excitation current
I phase	Measured primary current per phase
Watt losses	Measured losses
Reactance	Main inductance of the transformer
Assessment	Measurement assessment

12.6 Insulating Fluids PF & CAP test

Note: This test name depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112):

- IEEE standard: **Insulating Fluids PF & CAP**
- IEC standard: **Insulating Fluids DF & CAP**
- Custom Profile: for example **Insulating Fluids Tan δ & CAP**

In this section, the terms **Power factor (PF)** and **Insulating Fluids PF & CAP** will be used.

The following table describes the Insulating Fluids PF & CAP test settings.

Table 12-23: Insulating Fluids PF & CAP test settings

Setting	Description
Measurement settings	
Test frequency	► Set the output frequency for the test.
Noise suppression settings	
Averaging (no. points)	Number of averaged measurements
Bandwidth	CP TD filter bandwidth
Avoid test frequency	<p>If this setting is active, the measurement will <i>not</i> be performed at the Test frequency set in the Measurement section. <i>Primary Test Manager</i> will instead measure two values at frequencies below and above the entered Test frequency and calculate the median of those two values.</p> <p>The Avoid test frequency setting is predefined for the selected test.</p> <p>► Only change the default setting for special applications.</p>
Device settings	
Tan Delta device	► Select the <i>CP TD</i> you are using.
Enable shield check	► Select the check box if you want that the <i>TESTRANO 600</i> checks whether the shield of the high-voltage cable is connected.
Use beeper	► Select the check box if you want to use the <i>CP TD</i> 's beeper during the measurement.
Test conditions	
Oil temperature	Temperature of the oil
Custom test conditions	► Select the check box to set test conditions differing from the global test conditions.
Ambient temperature	Ambient temperature on site

Table 12-23: Insulating Fluids PF & CAP test settings (continued)

Setting	Description
Correction factors	
Temperature correction	► Select the check box to activate temperature correction.
Correction factor	Temperature correction factor
Use reference voltage	► Select the check box to extrapolate the I out and Watt losses results for the specified reference voltage.
Reference voltage	Reference voltage for extrapolation of measurement results

The following table describes the Insulating Fluids PF & CAP measurement data.

Table 12-24: Insulating Fluids PF & CAP measurement data

Data	Description
No.	Number of the measurement
Specimen	Oil sample under test
Test mode	Test mode according to the IEEE Std 62-1995
V test	Test voltage
Freq.	Test frequency
V out	Measured output voltage
I out	Measured output current
Watt losses	Measured losses
PF meas ¹	Measured power factor
PF corr ¹	Corrected measured power factor
Cap. meas	Measured capacitance
Assessment	Measurement assessment

1. Term depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112).

12.7 Surge Arrester Watt Losses test

Note: This test name depends on the winding used for performing the test, and on the **Profile** selected in the **Settings** (see "Profiles" on page 112):

- IEEE standard: **Surge Arrester Watt Losses H/X/Y**
- IEC standard: **Surge Arrester Watt Losses Prim/Sec/Tert**

In this section, the term **Surge Arrester Watt Losses** will be used.

The following table describes the Surge Arrester Watt Losses test settings.

Table 12-25: Surge Arrester Watt Losses test settings

Setting	Description
Measurement settings	
Test frequency	▶ Set the output frequency for the test.
Noise suppression settings	
Averaging (no. points)	Number of averaged measurements
Bandwidth	CP TD filter bandwidth
Avoid test frequency	<p>If this setting is active, the measurement will <i>not</i> be performed at the Test frequency set in the Measurement section. <i>Primary Test Manager</i> will instead measure two values at frequencies below and above the entered Test frequency and calculate the median of those two values.</p> <p>The Avoid test frequency setting is predefined for the selected test.</p> <p>▶ Only change the default setting for special applications.</p>
Device settings	
Tan Delta device	▶ Select the CP TD you are using.
Enable shield check	▶ Select the check box if you want that the <i>TESTRANO 600</i> checks whether the shield of the high-voltage cable is connected.
Use beeper	▶ Select the check box if you want to use the CP TD's beeper during the measurement.
Test Conditions	
Custom test conditions	▶ Select the check box to set test conditions differing from the global test conditions.
Top oil temperature	Oil temperature at the top of the transformer's tank
Ambient temperature	Ambient temperature on site
Humidity	Relative ambient humidity

Table 12-25: Surge Arrester Watt Losses test settings (continued)

Setting	Description
Weather	Weather during the test
Correction factors	
Use reference voltage	► Select the check box to extrapolate the I out and Watt losses results for the specified reference voltage.
Reference voltage	Reference voltage for extrapolation of measurement results

The following table describes the Surge Arrester Watt Losses measurement data.

Table 12-26: Surge Arrester Watt Losses measurement data

Data	Description
Measurement	Terminal name of the surge arrester under test
Position	Surge arrester unit under test
Test mode	Test mode according to the IEEE Std 62-1995
V test	Test voltage
Freq.	Test frequency
V out	Measured output voltage
I out	Measured output current
Watt losses	Measured losses
Assessment	Measurement assessment

12.8 HV TTR test

Note: This test name depends on the winding combination to be tested, and on the **Profile** selected in the **Settings** (see "Profiles" on page 112):

- IEEE standard: **HV TTR H-X/H-Y**
- IEC standard: **HV Turns Ratio Prim-Sec/Prim-Tert**

In this section, the term **HV TTR** will be used.

The turns ratio is determined during factory acceptance tests and needs to be checked routinely once the transformer is in service. By measuring the ratio and phase angle from one winding to the other, open circuits and shorted turns can be detected.

A low-voltage turns ratio test may not detect a voltage sensitive failure within the transformer. Therefore, for fault investigations, it is recommended that a high-voltage turns ratio test is performed to apply a higher electrical stress to the insulation system.

The screenshot displays the 'Primary Test Manager' software interface. On the left, a sidebar shows a 'Job' overview for '2016-08-31 Screenshots 1' with a status of 'Partially executed'. Below this are sections for 'Overview', 'Location' (Omicron QA Lab), 'Asset' (Two-winding Sample TESTRANO), and 'Tests'. The 'Tests' list includes 'DC Winding Resistance X Quick', 'Demagnetization', '(2) Overall Localized', 'Dyn. OLTC-Scan (DRM) X', 'Exciting Current', 'Vector Group Check H-X', and 'HV TTR H-X' (which is selected). A 'Report' button is also visible.

The main area is titled 'General' and features a schematic diagram of a transformer with terminals H1, H2, H3, X1, X2, X3, and Z abs. A measurement capacitor (CP TD) is connected to the H1 terminal, and a high-voltage connector (MCA1) is connected to the X1 terminal. The test voltage is applied to the H1 terminal, and the ratio is measured between H1 and X1.

On the right, 'Test instructions' are listed:

1. Remove all busbar connections from the terminals of the transformer.
2. Adjust the settings for the tap changer and automatic tap control, if applicable.
3. Verify the measurement settings and modify them if required.
4. Enter or measure the capacitance in order to detect the impedance used to calculate the turns ratio.
 - To measure the capacitance:
 - a. Connect IN_A (CP TD) to the measurement capacitor.
 - b. Connect the high-voltage connector (CP TD) to the measurement capacitor.
 - c. Press Start.
5. Connect the CP TD to the transformer as indicated in the wiring diagram. Make sure to connect the MCA1 on the LV side of the transformer.
6. Start the measurement.
7. Assess the results.

The 'Hardware configuration' section shows:

- Measurement capacitor: Z abs = 2,653 MΩ, Z phase = -90,000°

The 'Settings and conditions' section includes:

- Measurement settings: Test voltage = 1.0 kV, Ratio = TTR
- Tap changer settings: Tap changer under test = OLTC, DETC position = 1
- Tap control settings: Automatic tap control (unchecked), Tap time = 5 s, Impulse time = 2.0 s

The bottom status bar shows 'TESTRANO 600 Tap switch Impulse time 2,0 s' and a zoom level of 100%.

Figure 12-2: HV TTR

Table 12-27: HV TTR – Hardware configuration

Option	Description
Measurement capacitor	
Z abs	Absolute impedance value
Z phase	Phase angle of the impedance

Table 12-28: HV TTR – Settings and conditions

Option	Description
Measurement settings	
Test voltage	▶ Enter the output voltage.
Ratio	▶ Choose between transformer turns ratio (TTR) and voltage ratio (VTR).
Test mode	Test mode for this test: UST-A
Noise suppression	
Averaging	Number of averaged measurements
Bandwidth	CP TD filter bandwidth
Avoid test frequency	<p>If this setting is active, the measurement will <i>not</i> be performed at the Test frequency set in the Measurement section. <i>Primary Test Manager</i> will instead measure two values at frequencies below and above the entered Test frequency and calculate the median of those two values.</p> <p>The Avoid test frequency setting is predefined for the selected test.</p> <p>▶ Only change the default setting for special applications.</p>
Device settings	
Tan Delta device	▶ Select the CP TD you are using.
Enable shield check	▶ Activate the check box if you want TESTRANO 600 to check whether the shield of the high-voltage cable is connected.
Use beeper	▶ Activate the check box to activate the CP TD beeper during the measurement.
Tap changer settings	
Tap changer under test	▶ Select which tap changer to include in the measurement if both an OLTC and a DETC have been defined.
Tap control settings	
Automatic tap control	▶ Activate the check box to use automatic tap control during the test.
Tap time	Time for the change between two tap positions
Impulse time	Duration of the impulse triggering the tap change
Start tap	Start tap position of the test
Stop tap	Stop tap position of the test

Table 12-29: HV TTR – Measurements

Option	Description
Capacitor	
Test voltage	Output voltage
Test mode	► Select a test mode from the drop-down list
V out	Measured output voltage
I out	Measured output current
Z abs	Absolute impedance value
Z phase	Phase angle of the impedance
Table	
Phase selection	► After rewiring, select the next phase and press Start .
Tap	Tap under test
Phase	Phase under test
Nominal ratio	Nominal transformer ratio
V prim	Output voltage
I sec	Measured current on the secondary side of the transformer
Z sec	V prim divided by I sec Used to calculate the turns ratio
V phase	Phase shift of the transformer
TTR	Measured transformer turns ratio
VTR	Measured voltage ratio
Ratio dev	Deviation of the nominal ratio from the voltage ratio
Assessment	Measurement assessment

12.9 Leakage Reactance test

Note: This test name depends on the winding combination to be tested, and on the **Profile** selected in the **Settings** (see "Profiles" on page 112):

- IEEE standard: **Leakage Reactance H–X/H–Y/X–Y**
- IEC standard: **Short-circuit Impedance Prim–Sec/Prim–Tert/Sec–Tert**

In this section, the terms **Leakage Reactance** and **Z (%)** as abbreviation for the leakage reactance will be used.

Leakage reactance measurements are sensitive methods to assess possible deformation or displacements in windings.

The frequency response of stray losses (FRSL) test is a measurement of the resistive component of the short-circuit impedances at multiple frequencies. It is an electrical method to identify short-circuits between parallel strands and local overheating due to excessive eddy current losses. The test setup and procedure of the FRSL test is the same as for the per phase leakage reactance test and can be performed simultaneously.




Figure 12-3: Leakage Reactance

Table 12-30: Leakage Reactance – Settings and conditions

Option	Description
Measurement settings	
Auto shorting	<p>When selected the short-circuit does not need to be done manually and the HV and LV cables remain as connected. <i>TESTRANO 600</i> compensates for the losses in the cables.</p> <p>If auto shorting is selected (ON) the Test current label will be changed to Output current limit with a preset value, which can be changed depending the maximum rate of the secondary winding of the transformer (range 0 - 33 A).</p> <p>Note: To achieve optimal results, <i>TESTRANO 600</i> adjusts the test current automatically to the most feasible value within the range from 0 to the defined maximum Output current limit value.</p>
Test current	▶ Enter the maximum test current.
Test conditions	
Temperature correction	▶ Activate the check box to use temperature correction for this test.
Winding material	Conductor material of the transformer's winding
Winding temp.	Temperature of the transformer's winding
Reference temp.	Reference temperature to be used for temperature correction
Correction factor	Temperature correction factor

Table 12-31: Leakage Reactance – Assessment

Option	Description
Limits schema	▶ Select a standard from the drop-down box or set your own limits schema by selecting Customer specific limits .
Assess during measurements	▶ Activate the Assess during measurements check box to assess the test while the measurements are running.

Table 12-32: Leakage Reactance – Measurements

Option	Description
Three phase	The Three phase measurement is performed to compare the results to the nameplate data.
Per phase	The Per phase measurement is performed for an in-depth error analysis of the individual phases.
Short-circuit impedance entry / Leakage reactance entry ¹	Tap settings for the short-circuit impedance test
Show FRSL results ²	► Activate the check box to display the FRSL results in the Per phase table.
Phase	Phase under test
I	Measured current
U	Measured voltage
V phase	Phase angle between voltage and current
Rk	Real part of the measured Zk
Xk	Imaginary part of the measured Zk (short-circuit impedance)
Zk	Measured short-circuit impedance
Zk calc ¹	Short-circuit impedance when IEC profile is active
Zk avg ^{1,2}	Average of Zk across all phases
Zk dev ^{1,2}	Deviation from the nameplate value entered in the Impedance settings list
Assessment	Measurement assessment

1. Term depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112).

2. Only for **Per phase** test

12.10 TTR test

Note: This test name depends on the winding combination to be tested, and on the **Profile** selected in the **Settings** (see "Profiles" on page 112):

- IEEE standard: **TTR H-X/H-Y**
- IEC standard: **Turns Ratio Prim-Sec/Prim-Tert**

In this section, the term **TTR** will be used.

Transformer turns ratio (TTR) measurements are performed to verify the fundamental operating principle of a power transformer. By measuring the ratio and phase angle from one winding to the other, open circuits and shorted turns can be detected. The turns ratio is determined during factory acceptance tests and needs to be checked routinely once the transformer is in service.




Figure 12-4: TTR

Table 12-33: TTR – Settings and Conditions

Option	Description
Measurement settings	
Output mode	Standard setting: 3 x 120 V <ul style="list-style-type: none"> ▶ Select the 3 x 400 V output mode if the magnetization current of the transformer is low to perform the test by using a higher voltage. ▶ Refer to "AC high range low current" in Table 15-2, page 258.
Test voltage	Output voltage
Ratio	▶ Choose between TTR (transformer turns ratio) and VTR (voltage turns ratio) to be displayed in the Measurements table.
V phase	Phase shift of the transformer
Tap changer settings	
Tap changer under test	▶ Select which tap changer to include in the measurement if both an OLTC and a DETC have been defined.
DETC position	DETC tap position during tap switching on the OLTC
OLTC position	OLTC tap position during tap switching on the DETC
Tap control settings	
Automatic tap control	▶ Activate the check box to use automatic tap control during the test.
Tap time	Time for the change between two tap positions
Impulse time	Duration of the impulse triggering the tap change
Start tap	Start tap position of the test
Stop tap	Stop tap position of the test

Table 12-34: TTR – Assessment

Option	Description
Limits schema	▶ Select a standard from the drop-down box or set your own limits schema by selecting Customer specific limits .
Assess during measurements	▶ Activate the Assess during measurements check box to assess the test while the measurements are running.

Table 12-35: TTR – Measurement results

Option	Description
Table	
Tap	Tap under test
Phase	Phase under test
Nominal ratio	Nominal transformer ratio
V prim	Output voltage
I prim	Excitation current
I phase	Measured primary current per phase
V sec	Secondary voltage
V phase	Phase angle of the measured secondary voltage
TTR	Measured transformer turns ratio
VTR	Measured voltage turns ratio
Ratio dev	Deviation of the nominal ratio from the voltage ratio
Assessment	Measurement assessment

12.11 DC Winding Resistance test

Note: This test name depends on the winding used for performing the test, and on the **Profile** selected in the **Settings** (see "Profiles" on page 112):

- IEEE standard: **DC Winding Resistance H/X/Y**
- IEC standard: **DC Winding Resistance Prim/Sec/Tert**

In this section, the term **DC Winding Resistance** will be used.

Winding resistance measurements are performed to assess possible damages in windings or contact problems between bushings and windings, windings and tap changer, etc. A separate DC Winding Resistance test is available for each winding.

The screenshot displays the 'Primary Test Manager' software interface. The left sidebar shows a 'Job' overview with a list of tests, where 'DC Winding Resistance H' is selected. The main area is divided into 'Settings and conditions' and 'Measurements' sections.

Settings and conditions:

- Measurement settings:** Output mode: 16 A @ 340 V; Test current: 5 A.
- Tap changer settings:** Tap changer under test: DETC.
- Result settings:** Automatic result: checked; Settling time (Δt): 2 s; Tolerance R dev: 0.01 %.
- Test conditions:** Temperature correction: checked; Winding material: Copper; Winding temp.: 20 °C; Reference temp.: 75 °C; Correction factor: 1.216.

Measurements:

Buttons: + Select comparison, - Remove comparison, Clear all.

Tap	Name	R meas	R dev	R corr	Time	I DC	V DC	Assessment
1	A (H1 - H2)	-116.536 mΩ	0.018 %	-141.721 mΩ	1 s	5.000 A	-582.68 mV	Not assessed
1	B (H2 - H3)	11.688 mΩ	0.109 %	14.214 mΩ	0 s	5.000 A	58.44 mV	Not assessed
1	C (H3 - H1)	802.289 mΩ	0.803 %	975.672 mΩ	0 s	2.000 A	1.60 V	Not assessed
2	A (H1 - H2)	450.715 mΩ	0.174 %	548.119 mΩ	0 s	2.500 A	1.13 V	Not assessed
2	B (H2 - H3)	67.735 mΩ	0.327 %	82.373 mΩ	0 s	4.000 A	270.94 mV	Not assessed
2	C (H3 - H1)	416.053 mΩ	0.049 %	505.966 mΩ	0 s	5.000 A	2.08 V	Not assessed
3	A (H1 - H2)	-224.698 mΩ	0.024 %	-273.258 mΩ	0 s	5.000 A	-1.12 V	Not assessed


Figure 12-5: Winding Resistance test view

Table 12-36: DC Winding Resistance – Settings and Conditions

Option	Description
Measurement settings	
Output mode	<p>1 Phase:</p> <ul style="list-style-type: none"> • 16 A @ 340 V Fast magnetization with elevated voltage • 33 A @ 170 V For assets with expected low resistances • 100 A @ 56 V For assets with expectedly very low resistances <p>3 Phases: only available and set by default for the selected output of YN windings</p> <ul style="list-style-type: none"> • 16 A @ 113 V Fast magnetization with elevated voltage • 33 A @ 56 V For assets with expected low resistances
Test current	Current output during the test
Tap changer settings	
Tap changer under test	Tap changer actuated during the test
DETC position	DETC tap position during tap switching on the OLTC
OLTC position	OLTC tap position during tap switching on the DETC
Tap control settings¹	
Automatic tap control	▶ Activate the check box to activate the automatic tap control.
Tap time	Time for the change between two tap positions
Impulse time	Duration of the impulse triggering the tap change
Start tap	Start tap position of the test
Stop tap	Stop tap position of the test
Up/Down test	▶ Activate the check box for the automatic change of switching direction after the first/last tap.

Table 12-36: DC Winding Resistance – Settings and Conditions (continued)

Option	Description
Result settings	
Automatic result	► Select ON to automatically keep measurement results, depending on tolerance R dev and the settling time.



Settling time (Δt)	Time during which the deviation of measurement results is evaluated. If the deviation is below the defined tolerance R dev, the result is recorded.
Tolerance R dev	Tolerance for the deviation of measurement results within the settling time
Test conditions	
Temperature correction	► Activate the check box to use temperature correction for this test.
Winding material	Conductor material of the transformer's winding
Winding temp.	Temperature of the transformer's winding
Reference temp.	Reference temperature to be used for temperature correction
Correction factor	Temperature correction factor

1. Only for OLTC

Table 12-37: DC Winding Resistance – Measurement results

Option	Description
Table	
Tap	Tap changer position
Name	Name indicates between which terminals of the transformer the measurement was performed. A , B and C are measurement prefixes, A-N , B-N and C-N refer to the wiring diagram.
R meas	Measured resistance
R dev	Deviation of two successive measurement results at the time the test was stopped
R corr	Corrected measured resistance
Time	Time between the start and stop of a measurement
I DC	Measured current
V DC	Measured voltage
Assessment	Measurement assessment

12.12 Dynamic OLTC-Scan (DRM) test

Note: This test name depends on the winding used for performing the test, and on the **Profile** selected in the **Settings** (see "Profiles" on page 112):

- IEEE standard: **Dynamic OLCT-Scan (DRM) H/X/Y**
- IEC standard: **Dynamic OLCT-Scan (DRM) Prim/Sec/Tert**

In this section, the term **Dynamic OLCT-Scan (DRM)** will be used.

Dynamic resistance measurements are performed as a supplementary measurement in order to analyze the transient switching process of a resistive diverter OLTC. They investigate the switching process of the diverter switch itself. When switching the tap changer during winding resistance measurements, the DC current temporarily decreases and this behavior is recorded and analyzed.




Figure 12-6: Dynamic OLTC-Scan (DRM)

Table 12-38: Dynamic OLTC-Scan (DRM) – Settings and conditions

Option	Description
Measurement settings	
Output mode	DC current output of <i>TESTRANO 600</i>
Test current	Current output during the test
Dynamic shorting	Dynamic short-circuit of the winding without the OLTC on single- and three-phase transformers. Short-circuit is only set on two- and three- winding transformers.
Motor supply	
Record motor supply	▶ Activate the check box to record the current and voltage supply to the tap changer motor.
Clamp ratio	▶ Enter the current clamp's transformer ratio (current to voltage).
Tap control settings	
Automatic tap control	Taps are switched automatically during this measurement
Tap time	Time for the change between two tap positions
Impulse time	Duration of the impulse triggering the tap change
Start tap	Start tap position of the test
Stop tap	Stop tap position of the test
Up/Down test	▶ Activate the check box for the automatic change of switching direction after the first/last tap.
Result settings	
Settling time (Δt)	Time during which the deviation of measurement results is evaluated. If the deviation is below the defined tolerance R dev, the result is recorded.
Tolerance R dev	Tolerance for the deviation of measurement results within the settling time.
Recording time	Recording period during the switching cycle
Test conditions	
Temperature correction	▶ Activate the check box to use temperature correction for this test.
Winding material	Conductor material of the transformer's winding
Winding temperature	Temperature of the transformer's winding
Reference temperature	Reference temperature to be used for temperature correction
Correction factor	Temperature correction factor

Table 12-39: Dynamic OLTC-Scan (DRM) – Measurements

Option	Description
Table	
Tap	Tap changer position
Name	Name indicates between which terminals of the transformer the measurement was performed. A , B and C are measurement prefixes, A-N , B-N and C-N refer to the wiring diagram.
R meas	Measured resistance
R dev	Deviation of two successive measurement results at the time the test was stopped
R corr	Temperature-corrected measured resistance
Ripple	Percentage deviation between highest and lowest value in the DRM curve
Time	Time between the start and stop of a measurement
I DC	Measured current
V DC	Measured voltage
Assessment	Measurement assessment

Measurement results – Dynamic OLTC-Scan (DRM) tab

The **Dynamic OLTC-Scan (DRM)** tab displays the measurement results in charts.

If you activated the **Record motor supply** check box in the **Settings and conditions** section, you can compare both charts in this view. The actual tap switch is marked in the **Motor supply** chart.

- ▶ Expand the **Legend** tab on the left to select which graphs to display and to color them for easier distinction.
- ▶ Expand the **Filters / Cursor values** tab on the right to apply filters and view the detailed values for the positions of the various cursors.

Table 12-40: Cursor values for Dynamic OLTC-Scan measurement results

Option	Description
ΔI [A]	Difference in current values [amperes]
Δt [ms]	Time difference [milliseconds]
ΔU [V]	Difference in voltage values [volts]

12.13 Demagnetization test

Whenever a power transformer is isolated from the power system, residual magnetism remains in its core due to a phase shift. Due to residual magnetism in the core, high inrush currents, up to the maximum short-circuit current can occur. This puts undesired stress on the transformer when it is switched back into service. In addition, many diagnostic measurements can be affected by residual magnetism, making a reliable assessment very difficult.

Therefore, it is recommended to demagnetize the core before switching the transformer back into service and after DC voltages have been applied during diagnostic testing.




Figure 12-7: Demagnetization test view

Table 12-41: Demagnetization – Settings and conditions

Option	Description
Measurement settings	
Test current	► Set the current injected during the test.
Saturation criteria	
Saturation level	Desired saturation level during the demagnetization process. This value is only adapted in special cases.

Table 12-42: Demagnetization – Measurement results

Option	Description
Measurement	
Measurement	Text field for description or comment
Status	During demagnetization: <ul style="list-style-type: none"> • Positive saturation running • Negative saturation running • Demagnetization running After demagnetization: <ul style="list-style-type: none"> • Demagnetization passed • Saturation failed • Demagnetization aborted
I DC	Measured current
Min. neg. remanence	Maximum remanence in negative direction of the hysteresis curve
Max. pos. remanence	Maximum remanence in positive direction of the hysteresis curve
Remanence	Measured remanence
Initial remanence	Measured remanence at the start of the test

12.14 Vector Group Check test

Note: This test name depends on the winding combination to be tested, and on the **Profile** selected in the **Settings** (see "Profiles" on page 112):

- IEEE standard: **Vector Group Check H-X/H-Y**
- IEC standard: **Vector Group Check Prim-Sec/Prim-Tert**

In this section, the term **Vector Group Check** will be used.

The **Vector group check** comprises a three-phase turns ratio measurement, neutral detection and a series of single-phase measurements to determine the vector group.

Table 12-43: Vector group check – Settings and conditions

Option	Description
Measurement settings	
Test voltage	Maximum output voltage <ul style="list-style-type: none"> ▶ Perform the vector group check using the default value. ▶ If there is no conclusive result, try increasing the test voltage.

After the check is completed, *PTM* displays the detected vector group(s) in the **Measurements** section.

- ▶ If there is no conclusive result, try increasing the test voltage.
- ▶ Press **Copy to asset** to apply the suggested vector group to the **Winding configuration** of the asset.

12.15 Manual Demagnetization test

Whenever a power transformer is isolated from the power system, residual magnetism remains in its core due to a phase shift. Due to residual magnetism in the core, high inrush currents, up to the maximum short-circuit current can occur. This puts undesired stress on the transformer when it is switched back into service. In addition, many diagnostic measurements can be affected by residual magnetism, making a reliable assessment very difficult.

Therefore, it is recommended to demagnetize the core before switching the transformer back into service and after DC voltages have been applied during diagnostic testing.




Figure 12-8: Manual Demagnetization test view

Table 12-44: Manual Demagnetization test – Asset data

Option	Description
Vector group	
Phases	► Set the number of transformer phases.
Auto transformer	► Activate the check box if you are testing an auto transformer.
Edit Vector Group	► Set the vector group.
Test settings	
Test current	► Enter the maximum test current.
Saturation level	Desired saturation level during the demagnetization process. This value is only adapted in special cases.

Table 12-45: Manual Demagnetization test – Settings and conditions

Option	Description
Measurement settings	
Test current	▶ Enter the maximum test current.
Saturation criteria	
Saturation level	Desired saturation level during the demagnetization process. This value is only adapted in special cases.

Table 12-46: Manual Demagnetization test – Measurement

Option	Description
Measurement	
Measurement name	Text field for description or comment
Status	During demagnetization: <ul style="list-style-type: none"> • Positive saturation running • Negative saturation running • Demagnetization running After demagnetization: <ul style="list-style-type: none"> • Demagnetization passed • Saturation failed • Demagnetization aborted
I DC	Measured current
Min. neg. remanence	Maximum remanence in negative direction of the hysteresis curve
Max. pos. remanence	Maximum remanence in positive direction of the hysteresis curve
Remanence	Measured remanence
Initial remanence	Measured remanence at the start of the test
Assessment	Measurement assessment

12.16 Manual Power losses at low voltage test

The power losses at low voltage test helps detect open circuits, shorted turns or problems with the transformer core. It is performed during factory acceptance tests and for routine checks on a regular basis to comply with the GOST 3484.1 standard, in countries where it is applicable.

Note: The transformer should always be demagnetized before performing a power losses at low voltage test.

TESTRANO 600 currently only supports the power losses at low voltage test on transformers with vector groups YNd11, Yd11 and YNyn0.




Figure 12-9: Power losses at low voltage test

12.17 Manual TTR test

Table 12-47: Power losses at low voltage test – Settings and conditions

Option	Description
Winding	
Vector group	▶ Select from vector groups YNd11, Yd11 and YNyn0.
Measurement settings	
Test voltage	▶ Enter the output voltage.
Test frequency	▶ Enter the mains frequency.
Output current limit	▶ Enter the maximum output current.
Auto shorting	On: Automatic phase switch and short-circuiting of the phases <i>not</i> under test Off: Manual phase switching via the Phase selection buttons and manual short-circuiting of the phases <i>not</i> under test

Table 12-48: Power losses at low voltage test – Measurements

Option	Description
Phase selection	
▶ After rewiring, select the next phase and press Start .	
Table	
Phase	Phase under test ▶ Refer to the wiring diagram for correct wiring after changing the phase.
V out	Measured output voltage
I out	Measured output current
I phase	Measured current per phase
Watt losses	Measured losses
cos φ	Power factor

Note: This test name depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112):

- IEEE standard: **Manual TTR**
- IEC standard: **Manual Turns Ratio**

In this section, the term **Manual TTR** will be used.

TESTRANO 600 User Manual

Transformer turns ratio (TTR) measurements are performed to verify the fundamental operating principle of a power transformer. By measuring the ratio and phase angle from one winding to the other, open circuits and shorted turns can be detected. The turns ratio is determined during factory acceptance tests and needs to be checked routinely once the transformer is in service.




Figure 12-10: Manual TTR test view

Table 12-49: Manual TTR test – Asset data

Option	Description
Winding	
Phases	▶ Set the number of transformer phases.
Auto transformer	▶ Activate the check box if you are testing an auto transformer.
Edit Vector Group	▶ Set the vector group.
Rated voltage	▶ Enter the transformer's rated voltage.
Tap changer data	
OLTC	▶ Activate the check box to select the tap changer and enter the corresponding data.
DETC	
Winding	▶ Select the tap changer's position.
Tap scheme	▶ Select the notation scheme for tap identification from the drop-down box.
No. of taps	▶ Enter the number of taps.

Table 12-49: Manual TTR test – Asset data (continued)

Option	Description
Current tap position	▶ Select the currently active tap.
Rated voltage	
Primary	▶ Enter the transformer's rated voltage on the primary side.
Secondary	▶ Enter the transformer's rated voltage on the secondary side.
Voltage table	
Voltage	▶ Enter the reference voltage for each tap or use the calculation.
Calculate	▶ Refer to " Specifying an on-load tap changer (OLTC) " on page 138.

Table 12-50: Manual TTR test – Settings and conditions

Option	Description
Measurement settings	
Output mode	▶ Select the output mode from the drop-down list.
Test voltage	Output voltage during the test
Test frequency	Output frequency during the test
V phase	Phase shift of the transformer
Tap changer settings	
Tap changer under test	▶ Select which tap changer to include in the measurement if both an OLTC and a DETC have been defined.
DETC position	DETC tap position during tap switching on the OLTC
OLTC position	OLTC tap position during tap switching on the DETC
Tap control settings¹	
Automatic tap control	▶ Activate the check box to activate the automatic tap control.
Tap time	Time for the change between two tap positions
Impulse time	Duration of the impulse triggering the tap change
Start tap	Start tap position of the test
Stop tap	Stop tap position of the test

1. Only for OLTC

Table 12-51: Manual TTR test – Measurement

Option	Description
Tap	Tap under test
Phase	Phase under test
Nominal ratio	Nominal transformer ratio
V prim	Output voltage

Table 12-51: Manual TTR test – Measurement (continued)

Option	Description
I prim	Measured current on the primary side of the transformer
V sec	Secondary voltage
V phase	Phase shift of the transformer
TTR	Measured transformer turns ratio
VTR	Measured voltage ratio
Ratio deviation	Deviation of the nominal ratio from the voltage ratio
Assessment	Measurement assessment

12.18 Manual Exciting Current test

Exciting current measurements are performed to assess the turn-to-turn insulation of the windings, the magnetic circuit of a transformer as well as the tap changer. The most valued benefit of the test is to detect turn-to-turn short-circuits in a winding. Physical movement of the core laminations or severe damage to the core can influence the reluctance and, thus, will result in a change in exciting current. Deviations may also indicate contact wear or improper wiring of the tap changer.




Figure 12-11: Manual Exciting current test

Table 12-52: Exciting current test – Asset data

Option	Description
Vector group	
Phases	▶ Set the number of transformer phases.
Auto transformer	▶ Activate the check box if you are testing an auto transformer.
Edit Vector Group	▶ Set the vector group.
Tap changer data	
OLTC	▶ Activate the check box to select the tap changer and enter the corresponding data.
DETC	
Winding	▶ Select the tap changer's position

Table 12-52: Exciting current test – Asset data (continued)

Option	Description
Tap scheme	▶ Select the notation scheme for tap identification from the drop-down box.
No. of taps	▶ Enter the number of taps.
Current tap position	▶ Select the currently active tap.
Rated voltage	
Primary	▶ Enter the transformer's rated voltage on the primary side.
Secondary	▶ Enter the transformer's rated voltage on the secondary side.

Table 12-53: Exciting current test – Settings and conditions

Option	Description
Measurement settings	
Test voltage	Output voltage during the test
Test frequency	Output frequency during the test
Test mode	Test mode for this test: UST-A
Noise suppression	
Averaging	Number of averaged measurements
Bandwidth	CP TD filter bandwidth
Avoid test frequency	<p>If this setting is active, the measurement will <i>not</i> be performed at the Test frequency set in the Measurement section. <i>Primary Test Manager</i> will instead measure two values at frequencies below and above the entered Test frequency and calculate the median of those two values.</p> <p>The Avoid test frequency setting is predefined for the selected test.</p> <p>▶ Only change the default setting for special applications.</p>

Table 12-54: Exciting current test – Measurements

Option	Description
Phase	Phase under test
V out	Output voltage
I out	Excitation current
I phase	Measured primary current per phase
Watt losses	Measured losses
Reactance	Main inductance of the transformer
Assessment	Measurement assessment

12.19 Manual HV TTR test

Note: This test name depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112):

- IEEE standard: **Manual HV TTR**
- IEC standard: **Manual HV Turns Ratio**

In this section, the term **Manual HV TTR** will be used.

The turns ratio is determined during factory acceptance tests and needs to be checked routinely once the transformer is in service. By measuring the ratio and phase angle from one winding to the other, open circuits and shorted turns can be detected.

A low-voltage turns ratio test may not detect a voltage sensitive failure within the transformer. Therefore, for fault investigations, it is recommended that a high-voltage TTR test is performed to apply a higher electrical stress to the insulation system.




Figure 12-12: Manual HV TTR test

Table 12-55: Manual HV TTR test – Asset data

Option	Description
Vector group	
Phases	▶ Set the number of transformer phases.
Auto transformer	▶ Activate the check box if you are testing an auto transformer.
Edit Vector Group	▶ Set the vector group.
Rated voltage	
Primary	▶ Enter the transformer's rated voltage on the primary side.
Secondary	▶ Enter the transformer's rated voltage on the secondary side.
Tap changer data	
OLTC	▶ Activate the check box to select the tap changer and enter the corresponding data.
DETC	
Winding	▶ Select the tap changer's position.
Tap scheme	▶ Select the notation scheme for tap identification from the drop-down box.
No. of taps	▶ Enter the number of taps.
Voltage table	
Voltage	▶ Enter the reference voltage for each tap or use the calculation.
Calculate	▶ Refer to " Specifying an on-load tap changer (OLTC) " on page 138.

Table 12-56: Manual HV TTR test – Settings and conditions

Option	Description
Measurement settings	
Test voltage	▶ Enter the output voltage.
Test frequency	▶ Enter the output frequency during the test.
Ratio	▶ Choose between transformer turns ratio (TTR) and voltage ratio (VTR).
Test mode	Test mode for this test: UST-A
Noise suppression	
Averaging	Number of averaged measurements
Bandwidth	CP TD filter bandwidth

Table 12-56: Manual HV TTR test – Settings and conditions (continued)

Option	Description
Avoid test frequency	<p>If this setting is active, the measurement will <i>not</i> be performed at the Test frequency set in the Measurement section. <i>Primary Test Manager</i> will instead measure two values at frequencies below and above the entered Test frequency and calculate the median of those two values.</p> <p>The Avoid test frequency setting is predefined for the selected test.</p> <p>▶ Only change the default setting for special applications.</p>
Device settings	
Tan Delta device	▶ Select the <i>CP TD</i> you are using.
Enable shield check	▶ Activate the check box if you want <i>TESTRANO 600</i> to check whether the shield of the high-voltage cable is connected.
Use beeper	▶ Activate the check box to activate the <i>CP TD</i> beeper during the measurement.
Tap changer settings	
Tap changer under test	▶ Select which tap changer to include in the measurement if both an OLTC and a DETC have been defined.
DETC position	DETC tap position during tap switching on the OLTC
OLTC position	OLTC tap position during tap switching on the DETC

Table 12-57: Manual HV TTR test – Measurements

Option	Description
Tap	Tap under test
Phase	Phase under test
Nominal ratio	Nominal transformer ratio
V prim	Output voltage
I sec	Measured current on the primary side of the transformer
Z sec	<p>V prim divided by I sec</p> <p>Used to calculate the turns ratio</p>
V phase	Phase shift of the transformer
TTR	Measured transformer turns ratio
VTR	Measured voltage ratio
Ratio dev	Deviation of the nominal ratio from the voltage ratio
Assessment	Measurement assessment

12.20 Manual DC Winding Resistance test

Winding resistance measurements are performed to assess possible damages in windings or contact problems between bushings and windings, windings and tap changer, etc. A separate DC Winding Resistance test is available for each winding.




Figure 12-13: Manual DC Winding Resistance test

Table 12-58: Manual DC Winding Resistance test – Asset data

Option	Description
Vector group	
Phases	▶ Set the number of transformer phases.
Auto transformer	▶ Activate the check box if you are testing an auto transformer.
Vector group	▶ Set the vector group.
Rated current	▶ Select the value you want to specify for Primary and Secondary .
Rated voltage	
Primary	▶ Enter the transformer's rated current/voltage on the primary side.
Secondary	▶ Enter the transformer's rated current/voltage on the secondary side.

Table 12-58: Manual DC Winding Resistance test – Asset data (continued)


Option	Description
Tap changer data	
OLTC	▶ Activate the check box to select the tap changer and enter the corresponding data.
DETC	
Winding	▶ Select the tap changer's position.
Tap scheme	▶ Select the notation scheme for tap identification from the drop-down box.
No. of taps	▶ Enter the number of taps.
Current tap position	▶ Select the currently active tap.
Voltage table	
Voltage	▶ Enter the reference voltage for each tap or use the calculation.
Calculate	▶ Refer to " Specifying an on-load tap changer (OLTC) " on page 138.

Table 12-59: Manual DC Winding Resistance test – Settings and conditions

Option	Description
Measurement settings	
Output side	▶ Select the transformer side for the current output.
Output mode	▶ Select the output mode from the drop-down list.
Test current	▶ Enter the output current for the test.
Tap changer settings	
Tap changer under test	▶ Select which tap changer to include in the measurement if both an OLTC and a DETC have been defined.
DETC position	DETC tap position during tap switching on the OLTC
OLTC position	OLTC tap position during tap switching on the DETC
Tap control settings¹	
Automatic tap control	▶ Select ON to activate the automatic tap control.
Tap time	Time for the change between two tap positions
Impulse time	Duration of the impulse triggering the tap change
Start tap	Start tap position of the test
Stop tap	Stop tap position of the test
Up/Down test	▶ Activate the check box for the automatic change of switching direction after the first/last tap.

Table 12-59: Manual DC Winding Resistance test – Settings and conditions (continued)

Option	Description
Result settings	
Automatic result	▶ Activate the check box to automatically keep measurement results, depending on tolerance R dev and the settling time.



Tolerance R dev	Tolerance for the deviation of measurement results within the settling time
Settling time (Δt)	If during the settling time the deviation remains below the defined Tolerance R dev , the result is recorded.
Test conditions	
Temperature correction	▶ Select the check box to activate temperature correction.
Winding material	▶ Select the winding material: copper or aluminum.
Winding temp.	Temperature of the transformer windings.
Reference temp.	Reference temperature for the temperature correction
Correction factor	Temperature correction factor calculated from the values entered above

1. Only for OLTC

Table 12-60: Manual DC Winding Resistance test – Measurement

Option	Description
Tap	Tap under test
Name	Measurement indicates between which terminals of the transformer the measurement was performed. A , B and C are measurement prefixes, A-N , B-N and C-N refer to the wiring diagram.
R meas	Measured resistance
R dev	Deviation of two successive measurement results at the time the test was stopped
R corr	Corrected measured resistance

Table 12-60: Manual DC Winding Resistance test – Measurement (continued)

Option	Description
Time	Time until a stable condition was reached
I DC	Measured current
V DC	Measured voltage
Assessment	Measurement assessment

12.21 Manual Dynamic OLTC-Scan (DRM)

Dynamic resistance measurements are performed as a supplementary measurement in order to analyze the transient switching process of a resistive diverter OLTC. They investigate the switching process of the diverter switch itself. When switching the tap changer during winding resistance measurements, the DC current temporarily decreases and this behavior is recorded and analyzed.




Figure 12-14: Manual Dynamic OLTC-Scan (DRM)

Table 12-61: Manual Dynamic OLTC-Scan (DRM) – Asset data

Option	Description
Vector group	
Phases	► Set the number of transformer phases.
Auto transformer	► Activate the check box if you are testing an auto transformer.
Edit Vector Group	► Set the vector group.
Rated current	► Select the value you want to specify for Primary and Secondary .
Rated voltage	
Primary	► Enter the transformer's rated current/voltage on the primary side.
Secondary	► Enter the transformer's rated current/voltage on the secondary side.

Table 12-61: Manual Dynamic OLTC-Scan (DRM) – Asset data (continued)

Option	Description
Tap changer data	
OLTC	▶ Activate the check box to select the tap changer and enter the corresponding data.
DETC	
Winding	▶ Select the tap changer's position.
Tap scheme	▶ Select the notation scheme for tap identification from the drop-down box.
No. of taps	▶ Enter the number of taps.
Current tap position	▶ Select the currently active tap.

- ▶ For information on **Settings and conditions** and **Measurements**, refer to:
 Table 12-38: "Dynamic OLTC-Scan (DRM) – Settings and conditions" on page 209 and
 Table 12-39: "Dynamic OLTC-Scan (DRM) – Measurements" on page 210
 Section "Measurement results – Dynamic OLTC-Scan (DRM) tab" on page 210

12.22 Manual Leakage Reactance test

Note: This test name depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112):

- IEEE standard: **Manual Leakage Reactance**
- IEC standard: **Manual Short-circuit Impedance**

In this section, the terms **Manual Leakage Reactance** and **Z (%)** as abbreviation for the leakage reactance will be used.

Leakage reactance measurements are sensitive methods to assess possible deformation or displacements in windings.

The frequency response of stray losses (FRSL) test is a measurement of the resistive component of the short-circuit impedances at multiple frequencies. It is an electrical method to identify short-circuits between parallel strands and local overheating due to excessive eddy current losses. The test setup and procedure of the FRSL test is the same as for the per phase leakage reactance test and can be performed simultaneously.




Figure 12-15: Manual Leakage Reactance test

Table 12-62: Manual Leakage Reactance test – Asset data

Option	Description
Vector group	
Phases	▶ Set the number of transformer phases.
Auto transformer	▶ Activate the check box if you are testing an auto transformer.
Edit Vector Group	▶ Set the vector group.
Rated voltage	▶ Enter the transformer's rated voltage.
Tap changer data	
OLTC	▶ Activate the check box to select the tap changer and enter the corresponding data.
DETC	
Winding	▶ Select the tap changer's position.
Tap scheme	▶ Select the notation scheme for tap identification from the drop-down box.
No. of taps	▶ Enter the number of taps.
Current tap position	▶ Select the currently active tap.
Voltage table	
Voltage	▶ Enter the reference voltage for each tap or use the calculation.
Calculate	▶ Refer to " Specifying an on-load tap changer (OLTC) " on page 138.
Short circuit impedance data	
▶ Define the tap settings for the short-circuit impedance test. In the Measurements view you will be able to filter the results for the individual entries in this list, using the Short-circuit impedance entry drop-down box.	
Leakage Reactance Z^1	Short-circuit impedance of the transformer
Base power	Base power used for calculating the percent values of impedances
Base voltage	Base voltage used for calculating the percent values of impedances
OLTC position	Tap position of the OLTC corresponding to the impedance value
DETC position	Tap position of the DETC corresponding to the impedance value

1. Term depends on the **Profile** selected in **Settings** (see "Profiles" on page 112).

Table 12-63: Manual Leakage Reactance test – Settings and conditions

Option	Description
Measurement settings	
Test current	Current output during the test.
Default frequency	▶ Enter the mains frequency.

Table 12-63: Manual Leakage Reactance test – Settings and conditions (continued)

Option	Description
Test conditions	
Temperature correction	▶ Select the check box to activate temperature correction.
Winding material	▶ Select the winding material: copper or aluminum.
Winding temp.	Temperature of the transformer windings.
Reference temp.	Reference temperature for the temperature correction
Correction factor	Temperature correction factor calculated from the values entered above

Table 12-64: Manual Leakage Reactance test – Measurements

Option	Description
Three phase	The Three phase measurement is performed to compare the results to the nameplate data.
Per phase	The Per phase measurement is performed for an in-depth error analysis of the individual phases.
Short-circuit impedance entry / Leakage reactance entry ¹	Tap settings for the short-circuit impedance test
Phase selection ²	▶ Select the phase for the Per phase mode.
Show FRSL results ²	▶ Activate the check box to display the FRSL results in the Per phase table.
Position	Short-circuit impedance entry
Phase	Phase under test
I	Measured current
U	Measured voltage
V phase	Phase shift of the transformer
Rk	Real part of the measured Zk
Xk	Imaginary part of the measured Zk (short-circuit impedance)
Zk	Measured short-circuit impedance
Zk calc ¹	Short-circuit impedance when IEC profile is active
Zk avg ^{1, 2}	Average of Zk across all phases
Zk dev ^{1, 2}	Deviation from the nameplate value entered in the Impedance settings list
Assessment	Measurement assessment

1. Term depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112).

2. Only for **Per phase** test

12.23 Manual Tan Delta test

The Manual Tan Delta test is the most basic test to perform measurements with a *CP TD* in combination with a *TESTRANO 600* in a manual-like mode using *Primary Test Manager*.




Figure 12-16: Manual Tan Delta test

Table 12-65: Manual Tan Delta test – Settings and conditions

Option	Description
Measurement settings	
Default frequency	► Set the output frequency for the test.
Show results	► Select the results you want to display. All measurement results are stored and displayed when selected from the list.
Noise suppression settings	
Averaging (no. points)	Number of averaged measurements
Bandwidth	<i>CP TD</i> filter bandwidth

Table 12-65: Manual Tan Delta test – Settings and conditions (continued)

Option	Description
Avoid test frequency	<p>If this setting is active, the measurement will <i>not</i> be performed at the Test frequency set in the Measurement section. <i>Primary Test Manager</i> will instead measure two values at frequencies below and above the entered Test frequency and calculate the median of those two values.</p> <p>The Avoid test frequency setting is predefined for the selected test.</p> <p>► Only change the default setting for special applications.</p>
Device settings	
Tan Delta device	► Select the <i>CP TD</i> you are using.
Enable shield check	► Activate the check box if you want <i>TESTRANO 600</i> to check whether the shield of the high-voltage cable is connected.
Use beeper	► Activate the check box to activate the <i>CP TD</i> beeper during the measurement.
Test conditions	
Ambient temperature	► Enter the ambient temperature on site.
Test object temperature	► Enter the test object's temperature.
Humidity	► Enter the relative ambient humidity on site.
Weather	► Select the weather conditions during the test.
Correction factors	
Temperature correction	► Activate the check box to use temperature correction for this test.
Correction factor	Temperature correction factor
Use reference voltage	► Activate the check box to extrapolate the I out and Watt losses results for the specified reference voltage.
Reference voltage	Reference voltage for extrapolation of the measurement results
Bushings compensation	► Activate the check box to compensate the effect of the capacitance C1 of the transformer's bushings on the measurement results of the test.

Table 12-66: Manual Tan Delta test – Measurements

Option	Description
Table	
Measurement	Text field for description or comment
Test mode	► Select a test mode from the drop-down list.
V test	Test voltage
Freq.	Test frequency
V out	Measured output voltage

Table 12-66: Manual Tan Delta test – Measurements (continued)

Option	Description
I out	Measured output current
Watt losses	Measured losses
PF ¹ meas	Measured power factor
PF ¹ corr	Corrected power factor
Cap. meas	Measured capacitance
Assessment	Measurement assessment

1. Term depends on the **Profile** selected in **Settings** (see "Profiles" on page 112).

12.24 Manual Vector Group Check

The **Vector group check** comprises a three-phase turns ratio measurement, neutral detection and a series of single-phase measurements to determine the vector group.

Table 12-67: Manual vector group check – Settings and conditions

Option	Description
Measurement settings	
Test voltage	Maximum output voltage ► Perform the vector group check using the default value. ► If there is no conclusive result, try increasing the test voltage.
Test frequency	► Enter the mains frequency

After the check is completed, *PTM* displays the detected vector group(s) in the **Measurements** section.

► If there is no conclusive result, try increasing the test voltage.

12.25 Quick test

Quick is the most basic mode to operate all of the *TESTRANO 600* outputs in a manual-like mode using *Primary Test Manager*.




Figure 12-17: Quick test view

Table 12-68: Quick test – Settings and conditions

Option	Description
Output	
Signal mode	► Set AC or DC as output signal.
Output mode	► Select 1-phase or 3-phase voltage (V) or current (A) control from the drop-down list.
Selected output	► Select the <i>TESTRANO 600</i> output: HV (red) or LV (yellow). ► See 3.1.5 " <i>TESTRANO 600</i> measuring cables" on page 20
Magnitude	
Equal magnitude	► Activate the check box for magnitude distribution to all three phases (phase shift = 120°)
Test frequency	Output frequency during the test

Table 12-68: Quick test – Settings and conditions (continued)

Option	Description
Measurement	
Phase	Number of phases
HV	▶ Choose the cable pair for the measurement.
LV	▶ Choose between line-to-line (L-L) and line-to-neutral (L-N) voltage.

Quick test – Measurements

In the **Measurement** view, you can add up to three calculations based on the measured current, voltage and frequency values.

- ▶ Choose two **Channels** and the **Calculation type** for each calculation.
- ▶ Press **Reset calculation** to delete your settings.

12.26 Manual Cooldown test

Note: The Manual Cooldown test can only be executed with the *TESTRANO 600* display variant. After you have configured the test with *Primary Test Manager*, save the job, and then load it to the *TESTRANO 600* with *TouchControl*. When the test has finished, you can load the results to *Primary Test Manager* and process them.

The Manual Cooldown test is performed to determine the winding temperature at the end of the heat run procedure by means of a winding resistance measurement.




Figure 12-18: Manual Cooldown test

Table 12-69: Manual Cooldown test – Asset data

Option	Description
Vector group	
Phases	▶ Set the number of transformer phases.
Auto transformer	▶ Select the check box if you are testing an auto transformer.
Edit Vector Group	▶ Click the Edit Vector Group button to set the vector group.
Transformer rating	
Rated current	▶ Select the value you want to specify for Primary and Secondary .
Rated voltage	

Table 12-69: Manual Cooldown test – Asset data (continued)

Option	Description
Primary	▶ Enter the transformer's rated current/voltage on the primary side.
Secondary	▶ Enter the transformer's rated current/voltage on the secondary side.
Tap changer data	
OLTC	▶ Select the tap changer and enter the corresponding data.
DETC	
Winding	▶ Select the tap changer's position.
Tap scheme	▶ Select the notation scheme for tap identification from the drop-down box.
No. of taps	▶ Enter the number of taps.
Current tap position	▶ Select the currently active tap.
Voltage table	
Voltage	▶ Enter the reference voltage for each tap or use the calculation.
Calculate	▶ Refer to " Specifying an on-load tap changer (OLTC) " on page 138.

Table 12-70: Manual Cooldown test – Settings and conditions

Option	Description
Tap changer under test	▶ Select which tap changer to include in the measurement if both an OLTC and a DETC have been defined.
DETC position	Current tap position of the DETC
OLTC position	Current tap position of the OLTC
Selected tap	Current tap position of the tap changer under test
Output mode	50 A @ 120 V Fast magnetization with elevated voltage
	100 A @ 56 V For assets with expectedly very low resistances
Test current	Current output during the test
Measurement on cool transformer	
Winding material	Material of transformer winding
T ref.	Reference temperature of transformer winding
R 1 at T ref.	Resistance 1 of transformer winding at reference temperature
R 2 at T ref.	Resistance 2 of transformer winding at reference temperature
Timer	
Measurement interval	Sampling time interval at which the winding resistance is measured
Recording	Total measurement time

Table 12-71: Manual Cooldown test – Measurement

Option	Description
Time	Time elapsed since the timer was started
R dev	Percentage deviation of the resistance 1 among the last 20 values measured (same as of the resistance 2 due to common transformer core)
R meas 1	Measured resistance 1
Temp. 1	Temperature of the resistance 1
R meas 2	Measured resistance 2
Temp. 2	Temperature of the resistance 2
I DC	Measured current
V DC 1	Measured voltage across the resistance 1
V DC 2	Measured voltage across the resistance 2

- To view graphical diagrams of the measurement results, click the **Plot** tab in the **Measurements** section.

13 PTM Bushing tests

This chapter lists the bushing tests available for *TESTRANO 600*.

- ▶ For details on safely performing tests, refer to chapters 1 "Safety instructions" on page 8 and 5 "Application" on page 27.

Note: The chapters list the available options and settings for the tests. Depending on the individual asset and the general *Primary Test Manager* settings, not every test displays all listed items.

13.1 Spare bushing tests

Note: Some test names depend on the **Profile** selected in the **Settings** (see "Profiles" on page 112). For your convenience, you can use your preferred naming to, for example, match regional conventions:

- IEEE standard: **Power factor (PF)** for the loss indicator
- IEC standard: **Dissipation factor (DF)** for the loss indicator
- Custom profiles: **Power factor (PF)**, **Dissipation factor (DF)** or **Tangent delta (Tan δ)** for the loss indicator

The dissipation factor and the tangent delta are identical characteristics of the primary asset under test.

The following Spare Bushing tests are available for *TESTRANO 600*:

- Spare Bushing PF & CAP – Overall¹
- Spare Bushing PF & CAP – C1¹
- Spare Bushing PF & CAP – C2¹
- Spare Bushing – Energized Collar

1. Test name depends on the Profile selected in Settings (see "Profiles" on page 112).




Figure 13-1: Bushing C1 test

The following table describes the parameters for spare bushing tests.

Note: Some tests do not comprise all parameters listed below.

Table 13-1: Spare Bushing test – Settings and conditions

Setting	Description
Measurement settings	
Test frequency	Test frequency
Sweep settings	
Frequency sweep	Sweep profile: None, OMICRON expertise (recommended), or CPC template <ul style="list-style-type: none"> • None: no frequency sweep • OMICRON expertise: sweep frequencies dynamically distributed within the <i>CPC 100</i> frequency range for optimum results • CPC template: sweep frequencies specified by the <i>CPC 100</i> test templates

Table 13-1: Spare Bushing test – Settings and conditions (continued)

Setting	Description
Voltage sweep (tip-up)	<p>Sweep profile: None or OMICRON expertise</p> <ul style="list-style-type: none"> • None: no voltage sweep • OMICRON expertise: sweep voltages dynamically distributed within the asset-dependent voltage range for optimum results
 Sweep profiles	<ul style="list-style-type: none"> ▶ Click the pen button  to create a frequency or voltage sweep profile. ▶ Add up to 30 measurement points with individual output voltages or frequencies. Double-click a value to change it. ▶ Mark a favorite  to use it as the default sweep profile for future tests. <p>Note: The predefined profiles None, OMICRON expertise and CPC template cannot be edited or deleted.</p> <p>The default sweep profiles for this test are:</p> <ul style="list-style-type: none"> • Frequency sweep: OMICRON expertise • Voltage sweep: none
Noise suppression settings	
Averaging (no. points)	Number of averaged measurements
Bandwidth	CP TD filter bandwidth
Device settings	
Enable shield check	▶ Activate the check box if you want <i>TESTRANO 600</i> to check whether the shield of the high-voltage cable is connected.
Use beeper	▶ Activate the check box to activate the <i>CP TD</i> beeper during the measurement.
Test conditions	
Custom test conditions	▶ Activate the check box to set test conditions differing from the global test conditions.
Top oil temperature	▶ Enter the temperature of the oil from the top of the transformer tank.
Ambient temperature	▶ Enter the ambient temperature on site.
Humidity	▶ Enter the relative ambient humidity on site.
Weather	▶ Select the weather conditions during the test.

Table 13-1: Spare Bushing test – Settings and conditions (continued)

Setting	Description
Correction factors	
Temperature correction	▶ Activate the check box to use temperature correction for this test.
Correction factor	Temperature correction factor
Use reference voltage	▶ Activate the check box to extrapolate the I out and Watt losses results for the specified reference voltage.
Reference voltage	Reference voltage for extrapolation of the measurement results

The following table describes the Spare Bushing test measurement data.

Table 13-2: Spare Bushing test – overall measurement data

Data	Description
No.	Number of the measurement
Measurement	Arrangement of the measurement
Test mode	Test mode according to the IEEE Std 62-1995
Sweep	Swept variable: frequency, voltage, or none
V test	Test voltage
Freq.	Test frequency
V out	Measured output voltage
I out	Measured output current
Watt losses	Measured losses
PF meas ¹	Measured power factor
PF corr ¹	Corrected measured power factor
Cap. meas	Measured capacitance
Assessment	Measurement assessment

1. Term depends on the **Profile** selected in the **Settings** (see "Profiles" on page 112).

14 Device-independent PTM tests

This chapter lists device-independent tests available in *Primary Test Manager*.

- For details on safely performing tests, refer to chapters 1 "Safety instructions" on page 8 and 5 "Application" on page 27.

Chapter	Page
14.1 Oil Analysis	248
14.2 Insulation Resistance test	254
14.3 Inspection	255

14.1 Oil Analysis

The Oil analysis test is used to add the results of oil analyses performed by an oil laboratory or using a mobile DGA test instrument. The values can be entered directly or imported from an Excel file.

For the dissolved gas in oil values the standard assessments and visualization according to IEEE C57.104-2008 and IEC 60599-2007-05 Edition 2.1. are performed.

The following table describes the Oil analysis test settings.

Table 14-1: Oil analysis – Settings and conditions

Setting	Description
Asset	
Asset	Asset under test – set in the asset data (see chapter 11 "PTM Asset data" on page 167)
Tank type	Type of transformer tank
Insulation medium	Insulation medium of the transformer – set in the asset data (see chapter 11 "PTM Asset data" on page 167) Note: The DGA is only valid for the insulation medium Mineral oil .
Oil type	Type of transformer oil
Test conditions	
Sample date	Date of sample collection
Oil sample temperature	Oil temperature at the time of sampling

Table 14-1: Oil analysis – Settings and conditions (continued)

Setting	Description
Measurement	
Analyzed by	Information on how the sample was analyzed <ul style="list-style-type: none"> • Oil lab: The sample was analyzed by a laboratory. After selecting Oil lab, you can enter the Name and Address of the laboratory. • Mobile DGA: The sample was analyzed using a mobile DGA device. After selecting Mobile DGA, you can enter the device Manufacturer/Type and its Serial number. • Online DGA: The sample was analyzed using a permanently installed monitoring device. After selecting Online DGA, you can enter the device Manufacturer/Type and its Serial number.
Use C3 hydrocarbons	Activate the Use C3 hydrocarbons check box to add C ₃ H ₆ and C ₃ H ₈ to the list of Gas in oil values , and to activate ratio assessment according to the MSS scheme.
Sampling point	Sampling point on the transformer tank: <ul style="list-style-type: none"> • Top • Middle • Bottom

The following table describes the gas-in-oil values.

Table 14-2: Oil analysis – Gas-in-oil values

Data	Description
TDCG	Total dissolved combustible gas
TDG	Total dissolved gas
TCGe	Estimation of the percentage of total combustible gas in the gas space. It will only correspond to the actually measured value if there is a balance between the gas blanket and the oil.
Lab. result	Assessment result of the laboratory according to the IEEE or IEC standard.
Assessment	Manual Gas-in-oil analysis assessment: <ul style="list-style-type: none"> • Manual pass • Manual fail • Manual investigate • Not assessed


Assessment Summary

The results are assessed using the following interpretation methods:


- Duval's triangles (see Table 14-3 below)
- IEC basic gas ratios
- Roger's ratios
- Doernenburg's ratios
- Key gases according to IEEE C57.104 and IEC 60599 (see Table 14-3 below)
- MSS scheme

Table 14-3: Examples of result visualization in the **Assessment Summary** section


Key gas ranges and conditions according to IEEE C57.104



Duval's triangle 1



Key gas ranges and conditions according to IEC 60599, visualized in 3D



Assessment Details

- The **Table** contains condition ranges and states for individual gases.
- The **Ratio Table** lists all used gas ratios, depending on the selected standard, and provides an **Interpretation** of the recorded values.

Table 14-4: Oil analysis – Assessment Details

Data	Description
Table	
Standard	Standard used for the condition assessment
Overall assessment	Condition fulfilled by the measured value of an individual gas
TDCG units/day	Increase in TDCG per day since the last measurement
Recommendation	Recommended interval for future measurements
Ratio Table	
Sample Date	Date of the sampling

Duval Triangle

Duval's triangles visualize faults in a triangular coordinate system (see Table 14-3).

- Triangle 1: gases formed by faults of low to high energy
- Triangle 4: gases formed more specifically by faults of low energy or temperature
- Triangle 5: gases formed more specifically by faults of high temperature

Pattern

The key gas results are visually compared to four reference patterns. If a reference graph matches the measured value, it is highlighted.

Physico-chemical oil analysis

The following table describes the physico-chemical oil analysis data.

Table 14-5: Oil analysis – Physico-chemical oil analysis data

Data	Description
Water content	
H ₂ O meas.	Measured water content in oil
H ₂ O @ 20 °C	Calculated water content in oil
Relative saturation	Relative water saturation
Assessment	Water content assessment
DC conductivity	
Meas. value	Measured DC conductivity
Test temperature	Temperature of the oil during DC conductivity test

Table 14-5: Oil analysis – Physico-chemical oil analysis data (continued)

Data	Description
Field strength	Field strength
Assessment	DC conductivity assessment
Power factor¹	
Standard	Standard underlying the power factor analysis
Meas. value @ 25 °C	Power factor measured at 25 °C
Meas. value @ 100 °C	Power factor measured at 100 °C
Assessment	Power factor assessment
Dielectric breakdown voltage	
Standard	Standard underlying the dielectric breakdown voltage analysis
Meas. value	Measured dielectric breakdown voltage
Test temperature	Oil temperature during dielectric breakdown voltage test
Assessment	Dielectric breakdown voltage assessment
Chemical	
Interfacial tension	Interfacial tension of the oil
Neutralization value	Neutralization value of the oil
Particle count	Particle count of the oil
Color	Color of the oil
Assessment	Chemical assessment

1. Term depends on the **Profile** selected in **Settings** (see "Profiles" on page 112).

The following table describes the test status that can be set in the **Oil Analysis** test:

Table 14-6: Test status

Status	Description
Partially executed	At least one measurement of the test has been executed.
Executed	All measurements of the test have been executed.

Note: The test status set in the **Oil Analysis** test is displayed in the job overview (see 9.7.2 "Job overview" on page 128) under **Tests**. If you do not set the test status to **Partially executed** or **Executed** in the **Oil Analysis** test, the test status **Not executed** is displayed in the job overview.

14.2 Insulation Resistance test

The Insulation Resistance test is used to import or enter data from an insulation testing device.

Table 14-7: Insulation Resistance – Settings and conditions

Setting	Description
Test conditions	
Test object temperature	Temperature of the test object
Custom test conditions	Activate the Custom test conditions check box to set test conditions differing from the global test conditions.
Ambient temperature	Ambient temperature on site
Humidity	Relative ambient humidity
Calculations	
PI calculation	Calculation of polarization index
Time 1	In the standard PI calculation, the testing device is applied and insulation resistance measurements are taken after 60 seconds (Time 1) and 600 seconds (Time 2). The polarization index (PI) is calculated as follows: $PI = \frac{R_{600}}{R_{60}}$
Time 2	
DAR calculation	Calculation of dielectric absorption ratio
Time 1	In the standard DAR calculation, the testing device is applied and insulation resistance measurements are taken after 30 seconds (Time 1) and 60 seconds (Time 2). The dielectric absorption ratio (DAR) is calculated as follows: $DAR = \frac{R_{60}}{R_{30}}$
Time 2	
Correction factors	
Temperature correction	Select the Temperature correction check box to activate temperature correction.
Correction temp.	Temperature correction factor

Table 14-8: Insulation Resistance – Measurements

Setting	Description
Test data	To import a file containing test data: <ul style="list-style-type: none"> ▶ Click the Add button + to browse your PC and add data from a file. To directly import data from a measurement file: <ul style="list-style-type: none"> ▶ Open the file on your computer. ▶ In the file press CTRL+A to mark all content, then press CTRL+C to copy. ▶ In <i>Primary Test Manager</i> press Paste from clipboard. The results may take a few seconds to load.
Measurement	Name or number of the measurement
PI	Polarization index
DAR	Dielectric absorption ratio
Time	Time at which the given values were recorded
Voltage	Voltage and current values recorded at the Time specified in the first column
V DC	
I DC	

14.3 Inspection

Inspection is used to add the results of (visual) inspections of assets performed before measurements. The input fields in the Test results section of the test can be user-defined and saved as asset-specific templates.

The following table describes the Inspection settings.

Table 14-9: Inspection – Settings and conditions

Setting	Description
Test template	<ul style="list-style-type: none"> ▶ Select a saved Inspection template. <p>Note: Only templates fitting the selected Asset kind and Asset type (where applicable) are shown here.</p>
	Opens the Inspection template dialog box
Assessment	Manual Inspection assessment: <ul style="list-style-type: none"> • Manual pass • Manual fail • Manual investigate • Not assessed

The following table describes the Inspection template dialog box.

Table 14-10: Dialog box – Inspection templates

Setting	Description
+ Add Template	▶ Create a new Inspection template.
 Edit Template	▶ Edit the currently selected Inspection template.
✕ Remove Template	▶ Remove the currently selected Inspection template from the template list
 Import Template	▶ Import a Inspection template from a file
 Export Template	▶ Export a Inspection template as a file
Templates	Shows a list of the stored Inspection templates
Preview	Shows a preview of the currently selected Inspection template

The following table describes the Inspection template creation/editing dialog box.

Table 14-11: Dialog box – Inspection template creation and editing

Setting	Description
 Save	▶ Save the template
 Add Insp. point	▶ Add a new inspection point to a group of inspection points.
 Add Group	▶ Add a new group of inspection points.
 Duplicate	▶ Duplicate the currently selected group or inspection point
✕ Remove	▶ Remove the element currently selected in the checklist (see below)
Template name	Name of the Inspection test template
Author	Author of the Inspection test template
Asset	Asset
Asset type	Asset type (where applicable)

15 Technical data

At the time of factory adjustment all units are within the typical accuracy values specified in this document.

Typical accuracy means that 98 % of all units meet the specified values at $23\text{ °C} \pm 5\text{ °C}/73\text{ °F} \pm 10\text{ °F}$, after a warm-up time of more than 25 min., and in a frequency range of 45 Hz to 65 Hz or DC.

The typical accuracy values multiplied by 3 are guaranteed at an ambient temperature of $23\text{ °C} \pm 5\text{ °C}/73\text{ °F} \pm 10\text{ °F}$, after a warm-up time more than 25 min., and in a frequency range of 45 Hz to 65 Hz or DC.

Accuracy values indicate that the error is smaller than:

$\pm (\text{value read} \times \text{reading error [rd]} + \text{full scale of range} \times \text{range error [rg]})$.

For mains voltages below 190 V AC the system is subject to power restrictions.

OMICRON suggests that you send in your unit for calibration at least once a year.

Technical data are subject to change without notice.

CAT level

The CAT level required depends on the *TESTRANO 600* application. All CAT ratings are defined for sea levels below 2000 m. There are some limitations between 2000 m and 5000 m from sea level (see section 15.8 "Environmental conditions" on page 274).

CAT I is required when the measured voltage is generated by the test set itself. No voltages from other sources are measured.

CAT II is required when measuring within electrical devices or between mains supply and devices.

CAT III is required when measuring in electrical installations such as control cubicles that are still connected to the station battery or mains. The electrical installations are protected by a fuse.

15.1 Output specifications

Table 15-1: General output specifications

Characteristic	Rating		
Frequency	DC or 15 Hz ... 599 Hz		
Power	V _{mains}	P _{30 s}	P _{continuous}
	>100 V _{RMS}	1500 W	1000 W
	>190 V _{RMS}	4000 W	2400 W

Table 15-2: Voltage source (HV and LV connectors)

Source	Range	I _{max, continuous}
DC high range	3 × 0 ... ±113 V _{DC} ¹	16 A _{DC}
	1 × 0 ... ±340 V _{DC} ²	
DC low range	3 × 0 ... ±56 V _{DC} ¹	33 A _{DC}
	1 × 0 ... ±170 V _{DC} ²	
AC high range low current	3 × 0 ... 230 V _{RMS} (LN) ³	100 mA _{RMS}
AC high range	3 × 0 ... 80 V _{RMS} (LN) ⁴	16 A _{RMS}
	1 × 0 ... 240 V _{RMS} ⁵	
AC low range	3 × 0 ... 40 V _{RMS} (LN) ⁵	33 A _{RMS}
	1 × 0 ... 120 V _{RMS}	

1. See Figure 15-3: "Permitted operating range 3 x DC 113 V 16 A" on page 261
2. See Figure 15-1: "Permitted operating range 1 x DC 340 V 16 A" on page 260
3. See Figure 15-5: "Derating of output power and output voltage 3 x 230 V_{RMS}" on page 262
4. See Figure 15-4: "Permitted operating range 3 x AC 80 V 16 A" on page 261
5. See Figure 15-2: "Permitted operating range 1 x AC 240 V 16 A" on page 260

Table 15-3: Voltage source accuracy

Characteristic	Accuracy ¹
Voltage accuracy DC	0.033 % rd ± 0.017 % range
Voltage accuracy AC (50 Hz) at burden open load	0.33 % rd ± 0.17 % range
Phase accuracy AC (50 Hz) burden open load, V>20 V _{RMS}	± 0.36°

1. Typical accuracy at 23 °C ±5 K

Table 15-4: Current source (HV and LV)

Source	Range	V _{max, continuous}
DC source high range	3 × 0 ... ±33 A _{DC} ¹ or 1 × 0 ... ±100 A _{DC} (3 × 33.33 A _{DC})	56 V _{DC}
	1 × 0 ... ±33 A _{DC} ²	170 V _{DC}
DC source low range	3 × 0 ... ±16 A _{DC} ¹	113 V _{DC}
	1 × 0 ... ±50 A _{DC} (3 × 16.66 A _{DC}) ¹	
	1 × 0 ... ±16 A _{DC} ²	340 V _{DC}
AC source high range	3 × 0 ... 33 A _{RMS} (LN) ³	40 V _{RMS}
	1 × 0 ... 33 A _{RMS} ⁴	120 V _{RMS}
AC source low range	3 × 0 ... 16 A _{RMS} (LN) ³ or 1 × 0 ... 50 A _{RMS} (3 × 16.66 A _{RMS})	80 V _{RMS}
	1 × 0 ... 16 A _{RMS} ⁴	240 V _{RMS}

1. See Figure 15-3: "Permitted operating range 3 x DC 113 V 16 A" on page 261
2. See Figure 15-1: "Permitted operating range 1 x DC 340 V 16 A" on page 260
3. See Figure 15-4: "Permitted operating range 3 x AC 80 V 16 A" on page 261
4. See Figure 15-2: "Permitted operating range 1 x AC 240 V 16 A" on page 260

Table 15-5: Current source accuracy

Characteristic	Accuracy ¹
Current accuracy DC	0.033 % rd ± 0.017 % range
Current accuracy AC 50/60 Hz at burden 0.1 Ω	0.33 % rd ± 0.17 % range

1. Typical accuracy at 23 °C ±5 K

Table 15-6: Voltage source (Booster)

Source	Range	I _{max, cont.} ¹	I _{max, 30 s} ¹
Power	–	3 kVA	4.4 kVA
AC high voltage	1 × 0 ... 240 V _{RMS}	16 A _{RMS}	20 A _{RMS}
Characteristic	Rating		
Channels	1		
Voltage accuracy ² AC (50/60 Hz) at burden open load	0.33 % rd ± 0.16 % range		

1. Within the above specified power limit
2. Typical accuracy at 23 °C ±5 K

The following figures display the output characteristics of *TESTRANO 600*.




Figure 15-1: Permitted operating range 1 x DC 340 V 16 A




Figure 15-2: Permitted operating range 1 x AC 240 V 16 A




Figure 15-3: Permitted operating range 3 x DC 113 V 16 A




Figure 15-4: Permitted operating range 3 x AC 80 V 16 A




Figure 15-5: Derating of output power and output voltage 3 x 230 V_{RMS}




Figure 15-6: Derating of continuous output current

15.2 Input specifications

Table 15-7: Voltage inputs (HV and LV) 3 phase

Range name	Range value	Accuracy ¹
AC		
300 mV _{RMS}	0 ... 300 mV _{RMS}	0.01 % rd + 0.003 % range
3 V _{RMS}	0 ... 3 V _{RMS}	0.01 % rd + 0.003 % range
30 V _{RMS}	0 ... 30 V _{RMS}	0.01 % rd + 0.003 % range
300 V _{RMS}	0 ... 300 V _{RMS}	0.012 % rd + 0.003 % range
DC		
42.4 mV _{DC}	0 ... 42.4 mV _{DC}	0.022 % rd + 0.032 % range
424 mV _{DC}	0 ... 424 mV _{DC}	0.01 % rd + 0.017 % range
4.24 V _{DC}	0 ... 4.24 V _{DC}	0.007 % rd + 0.012 % range
42.4 V _{DC}	0 ... 42.4 V _{DC}	0.01 % rd + 0.017 % range
424 V _{DC}	0 ... 424 V _{DC}	0.007 % rd + 0.012 % range

1. Typical accuracy at 23 °C ±5 K

Typical phase accuracy at 50/60 Hz, V>30 % of used range: 0.017°

Table 15-8: Voltage input (Booster)

Range name	Range value	Accuracy ¹
280 V _{RMS}	0 ... 280 V _{RMS}	0.012 % rd + 0.003 % range

1. Typical accuracy at 23 °C ±5 K

Typical phase accuracy at 50/60 Hz, V>30 % of used range: 0.017°

Table 15-9: Current inputs (internal)

Range name	Range value	Accuracy ¹
AC		
4 A _{RMS}	0 ... 4 A _{RMS}	0.036 % rd + 0.0033 % range
40 A _{RMS}	0 ... 40 A _{RMS}	0.023 % rd + 0.013 % range
DC		
0.56 A _{DC}	0 ... 0.56 A _{DC}	0.01 % rd + 0.023 % range
5.6 A _{DC}	0 ... 5.6 A _{DC}	0.037 % rd + 0.026 % range
56 A _{DC}	0 ... 56 A _{DC}	0.008 % rd + 0.01 % range

1. Typical accuracy at 23 °C ±5 K

Typical phase accuracy at 50/60 Hz, I>30 % of used range: 0.017°

Table 15-10: On-load tap changer measurement (tap changer connector)

Characteristic	Rating
Voltage	300 V _{RMS}
Accuracy ¹ AC (50/60 Hz)/DC	0.07 % rd + 0.07 % range
Current clamp input	3 V _{RMS}
Tap up/down switch current	300 mA continuous, 9 A for 0.7 s (AC permitted only)
Tap up/down switch voltage	300 V _{RMS} (AC permitted only)

1. Typical accuracy at 23 °C ±5 K




Figure 15-7: Filter characteristic of frequency-selective measurements (example at 50 Hz)

15.3 Interfaces

The types and number of connectors on *TESTRANO 600* are listed below.

Table 15-11: Connector overview

Interface	Rating
Digital	1 x EtherCAT® ¹ 1 x Ethernet 1 x Serial 2 x Safety
Analog	6 x Configurable outputs: – (HV) 3 x analog output – (LV) 3 x analog output
	6 x Configurable inputs: – (HV) 3 x analog input – (LV) 3 x analog input
	On-load tap changer interface: – 2 x internal switch – 1 x voltage measurement – 1 x current clamp measurement
	1 x Booster interface

1. EtherCAT® is registered trademark and patented technology, licensed by Beckhoff automation GmbH, Germany.

15.4 SAFETY connectors

TESTRANO 600 has two SAFETY connectors: SAFETY 1 (primary) and SAFETY 2 (secondary) for connecting optional OMICRON safety accessories (for more information see OMICRON document named "Safety Accessories Supplementary Sheet"). Both connectors have as default a removable Safety Connector Dongle connected to it. Removing either one or both Safety Connector Dongles will open the emergency stop circuit loop inside *TESTRANO 600* preventing the operation of the device.

Using Safety Accessories

OMICRON offers several Safety Accessories designed to enhance the safety awareness and/or safety when using the *TESTRANO 600*. The use of a Safety Accessory typically requires the removal of one of the Safety Connector Dongles to allow the Safety Accessory to be plugged in. Some Safety Accessories themselves contain a SAFETY OUT connector to allow daisy-chaining Safety Accessories with each other. If the connected (or the last daisy-chained) Safety Accessory itself also contains a SAFETY OUT connector, the Safety Connector Dongle initially removed from *TESTRANO 600* SAFETY 1 or SAFETY 2 connector must be attached to it to close the emergency stop loop circuit.

SAFETY 1 and SAFETY 2 connector pin-outs


SAFETY 1 and SAFETY 2 connector pin-outs differ slightly (see Table 15-12: on page 267, Figure 15-8: "SAFETY 1 (primary) connector schematics" on page 268 and Figure 15-9: "SAFETY 2 (secondary) connector schematics" on page 268).

External START button connection

SAFETY 1 (primary) connector can be used to connect an external START button to allow remote control of *TESTRANO 600*. If an external START button is used, the switch must fulfill these requirements:

- R_{off} (open resistance) > 1 M Ω
- R_{on} (close resistance) < 10 Ω
- I_{switch} (switching current) < 1.5 mA
- V_{switch} (switching voltage) < 15 V

Table 15-12:

Connector	Pin no.	SAFETY 1 (primary)	SAFETY 2 (secondary)
	1*	Warning light green	Warning light green
	2*	Warning light red	Warning light red
	3	Start button IN (n/o)	Start button OUT (n/o)
	4	Common start (n/o) + emergency stop	Common start n/o + emergency stop
	5	Emergency stop	Emergency stop
	6	Ground	Ground
	7	Ground	Ground
	8	Start button IN (n/c)	Start button OUT (n/c)
	9	Ground	Ground

* Typical output for pin 1 and 2 for both SAFETY 1 and SAFETY 2 connectors: 10 ... 14 V max. 400 mA.




Figure 15-8: SAFETY 1 (primary) connector schematics




Figure 15-9: SAFETY 2 (secondary) connector schematics

15.4.1 Safety Connector Dongle

More information concerning Safety Accessories and the use of the SAFETY connectors and the Safety Connector Dongle can be found in an OMICRON document named "Safety Accessory Supplementary Sheet".



Figure 15-10: Safety Connector Dongle

15.5 Display

Table 15-13: Display

Characteristic	Rating
Size	26.9 cm / 10.6 in
Resolution	1280 x 768 WXGA
Type	Color touch TFT LCD
Contrast ratio	1000:1
Luminance	800 cd/m ²
Viewing angle (CR ≥ 10)	85° (H), 85° (V)

15.6 Combined values

Table 15-14: Resistance measurement AC

Range name	Current	Range	Accuracy ¹
40 A _{RMS}	30 A _{RMS}	1 Ω ... 10 Ω	0.053 % rd + 0.033 % range
		0.1 Ω ... 1 Ω	0.053 % rd + 0.033 % range
		10 mΩ ... 100 mΩ	0.053 % rd + 0.033 % range
		1 mΩ ... 10 mΩ	0.053 % rd + 0.033 % range
		100 μΩ ... 1000 μΩ	0.063 % rd + 0.033 % range
4 A _{RMS}	3 A _{RMS}	10 Ω ... 100 Ω	0.053 % rd + 0.037 % range
		1 Ω ... 10 Ω	0.053 % rd + 0.037 % range
		0.1 Ω ... 1 Ω	0.053 % rd + 0.037 % range
		10 mΩ ... 100 mΩ	0.053 % rd + 0.037 % range
		1 mΩ ... 10 mΩ	0.067 % rd + 0.037 % range

1. Typical accuracy at 23 °C ±5 K

Table 15-15: Resistance measurement DC

Range name	Current	Range	Accuracy ¹
4 A _{RMS}	3 A _{DC}	10 Ω ... 100 Ω	0.1 % rd + 0.18 % range
		1 Ω ... 10 Ω	0.1 % rd + 0.267 % range
		0.1 Ω ... 1 Ω	0.1 % rd + 0.18 % range
		10 mΩ ... 100 mΩ	0.1 % rd + 0.267 % range
		1 mΩ ... 10 mΩ	0.113 % rd + 0.433 % range
40 A _{RMS}	30 A _{DC}	1 Ω ... 10 Ω	0.037 % rd + 0.017 % range
		0.1 Ω ... 1 Ω	0.04 % rd + 0.027 % range
		10 mΩ ... 100 mΩ	0.033 % rd + 0.017 % range
		1 mΩ ... 10 mΩ	0.037 % rd + 0.027 % range
		100 μΩ ... 1000 μΩ	0.05 % rd + 0.043 % range
120 A _{RMS}	100 A _{DC}	30 mΩ ... 300 mΩ	0.04 % rd + 0.027 % range
		3 mΩ ... 30 mΩ	0.033 % rd + 0.017 % range
		300 μΩ ... 3000 μΩ	0.037 % rd + 0.027 % range
		30 μΩ ... 300 μΩ	0.05 % rd + 0.043 % range
		3 μΩ ... 30 μΩ	0.07 % rd + 0.44 % range

1. Typical accuracy at 23 °C ±5 K

Table 15-16: Ratio measurement

Range name (LV voltage range)	Voltage at HV	Range ¹	Accuracy ²
300 V _{RMS}	230 V _{RMS} HV (LN)	$\frac{1}{1 \dots 10}$	0.03 % rd + 0.043 % range
30 V _{RMS}		$\frac{1}{10 \dots 100}$	0.027 % rd + 0.043 % range
3 V _{RMS}		$\frac{1}{100 \dots 1000}$	0.027 % rd + 0.043 % range
300 mV _{RMS}		$\frac{1}{1000 \dots 10000}$	0.027 % rd + 0.043 % range
300 mV _{RMS}		$\frac{1}{10000 \dots 50000}$	0.027 % rd + 0.22 % range

1. Range = $\frac{LV}{HV}$

2. Typical accuracy at 23 °C ±5 K

15.7 Power supply specifications

Table 15-17: Power supply specifications

Characteristic		Rating
Voltage	Nominal	100 V ... 240 V _{AC}
	Permitted	85 V ... 264 V _{AC}
Current	Nominal	16 A
Frequency	Nominal	50 Hz/60 Hz
	Permitted	45 Hz ... 65 Hz
Power fuse		Automatic circuit breaker with magnetic overcurrent tripping at I >16 A
Power consumption	Continuous	<3.6 kW
	Peak	<5.0 kW
Current consumption, continuous		<16 A _{AC}
Connector type		IEC320/C20, 1 phase

15.8 Environmental conditions

Table 15-18: Climate

Characteristic		Rating
Temperature	Operating	-10 °C ... +55 °C/+14 °F...+131 °F
	Storage	-30 °C ... +70 °C/-22 °F...+158 °F
Max. altitude	Operating	2000 m/6550 ft, up to 5000 m/16400 ft with limited specifications ¹
	Storage	12 000 m/40 000 ft

1. Output **TAP CHANGER (CAT III / 300 V)**: from 2000 m/6550 ft to 5000 m/16400 ft altitude only CAT II compliance or CAT III compliance with half voltage

15.9 Mechanical data

Table 15-19: Mechanical data

Characteristic		Rating
Dimensions (w × h × d)	With cover, without handles	464 × 386 × 229 mm 18.3 × 15.2 × 9 in
	With cover, with handles	580 × 386 × 229 mm 22.8 × 15.2 × 9 in
Weight	Device with display	20.6 kg/45.5 lb
	Device without display	19.5 kg/43 lb

15.10 Standards

Table 15-20: Standards conformity

EMC, safety	
EMC	IEC/EN 61326-1 (industrial electromagnetic environment) FCC subpart B of part 15, class A
Safety	IEC/EN/UL 61010-1, IEC/EN/UL 61010-2-30
  	
Other	
Shock	IEC/EN 60068-2-27 (15 g/11 ms, half-sinusoid, 3 shocks in each axis)
Vibration	IEC/EN 60068-2-6 (frequency range 10 Hz...150 Hz, acceleration 2 g continuous (20 m/s ² /65 ft/s ²), 20 cycles per axis)
Humidity	IEC/EN 60068-2-78 (5 % ... 95 % relative humidity, no condensation), tested at 40 °C/104 °F for 48 hours

Support

When you are working with our products we want to provide you with the greatest possible benefits. If you need any support, we are here to assist you!



24/7 Technical support – get support

www.omicronenergy.com/support

At our technical support hotline, you can reach well-educated technicians for all of your questions. Around the clock – competent and free of charge.

Make use of our 24/7 technical support hotlines:

Americas: +1 713 830-4660 or +1 800-OMICRON

Asia-Pacific: +852 3767 5500

Europe / Middle East / Africa: +43 59495 4444

Additionally, you can find our Service Center or Sales Partner closest to you at www.omicronenergy.com.



Customer Portal – stay informed

www.omicronenergy.com/customer

The Customer Portal on our website is an international knowledge exchange platform. Download the latest software updates for all products and share your own experiences in our user forum.

Browse through the knowledge library and find application notes, conference papers, articles about daily working experiences, user manuals and much more.



OMICRON Academy – learn more

www.omicronenergy.com/academy

Learn more about your product in one of the training courses offered by the OMICRON Academy.

